Monitoring Report for CSMRI Site First Quarter 2009

Prepared for:

Colorado School of Mines Golden, Colorado

Prepared by:

The S.M. Stoller Corporation Broomfield, Colorado

June 2009

TABLE OF CONTENTS

1.	. INTRODUCTION	1
2.	. SAMPLING AND ANALYSIS	1
	2.1 GROUNDWATER SAMPLING	1
	2.2 Surface Water Sampling	
	2.3 ANALYSES	3
	2.3.1 Groundwater Quality Analyses	3
	2.3.2 Surface Water Analyses	4
	2.4 HEALTH AND SAFETY PROGRAM	4
3.	. RESULTS	4
	3.1 GROUNDWATER CONDITIONS	5
	3.2 GROUNDWATER QUALITY	5
	3.2.1 Ionic Balance Evaluation	6
	3.2.2 Comparison of Upgradient and Downgradient Groundwater Quality	6
	3.2.3 Comparison with Previous Groundwater Quality Analyses	7
	3.2.4 Comparison with Colorado Groundwater Standards	7
	3.3 SURFACE WATER QUALITY	8
4.	. ACTIVITIES FOR FIRST QUARTER 2009	8
5.	REFERENCES	8

LIST OF TABLES

TABLE 2-1 SUMMARY OF RADIOISOTOPES IN GROUNDWATER	9
TABLE 2-2 SUMMARY OF METALS IN GROUNDWATER	9
TABLE 2-3 SUMMARY OF ANIONS AND CATIONS IN GROUNDWATER	10
TABLE 2-4 SUMMARY OF RADIOISOTOPES IN SURFACE WATER	10
TABLE 2-5 SUMMARY OF METALS IN SURFACE WATER	10
TABLE 2-6 SUMMARY OF ANIONS AND CATIONS IN SURFACE WATER	11
TABLE 2-7 CSMRI HISTORICAL GROUNDWATER DATA (PREVIOUS CONSULTANTS)	11

LIST OF FIGURES

FIGURE 1	MONITORING WELL LOCATIONS AND GROUNDWATER ELEVATION MAP
FIGURE 2	CSMRI ALL MONITOR WELLS HYDROGRAPH
FIGURE 3	CSMRI-2 Hydrograph
FIGURE 4	CLEAR CREEK GAUGING GRAPH (JANUARY – MARCH 2009)
FIGURE 5	CSMRI-2 SUM OF RA-226 AND RA-228
FIGURE 6	CSMRI-4 HISTORICAL TOTAL URANIUM CONCENTRATION (1990 – 2009)
FIGURE 7	CSMRI -4 TOTAL URANIUM CONCENTRATION AND POTENTIOMETRIC ELEVATION
FIGURE 8	CSMRI-8 TOTAL URANIUM CONCENTRATION AND POTENTIOMETRIC ELEVATION

LIST OF APPENDICES

GROUNDWATER SAMPLING PROCEDURES
SAMPLE COLLECTION FORMS
SURFACE WATER SAMPLING PROCEDURES
DATA VALIDATION REPORTS
RESULTS OF ANALYSES ON CD
CHAIN-OF-CUSTODY DOCUMENTATION
HISTORICAL SUMMARY TABLES
ANION AND CATION BALANCES AND PIPER DIAGRAM

1. Introduction

This report presents the first quarter (January, February, March) 2009 results for groundwater monitoring and surface water monitoring conducted at the Colorado School of Mines Research Institute (CSMRI) site in Golden, Colorado. The monitoring was conducted by the S.M. Stoller Corporation (Stoller).

2. Sampling and Analysis

Stoller obtained quarterly samples of groundwater and surface water on March 16, 17, and 18, 2009 from eight groundwater monitoring wells and two surface water sample locations. Groundwater quality samples were obtained on March 16 (CSMRI-9 and CSMRI-10), March 17 (CSMRI-1, CSMRI-4, and CSMRI-5), and March 18 (CSMRI-1B, CSMRI-2, and CSMRI-8). Several monitor wells require purging on one day and sample collection on subsequent visits over the following days. Monitor well CSMRI-1B was visited three times over the course of three days to provide sufficient volume of water for sampling. Monitor well CSMRI-7B was dry at the time of sample collection.

No groundwater samples were collected from replacement monitor wells CSMRI-11B and CSMRI-6C during this quarterly sampling event. These two wells were installed on December 1, and 2, 2008 respectively, and at the time of sampling the wells were dry. The precursors to these wells (11 and 6B, respectively) were abandoned in July 2008 due to construction activities associated with the Colorado School of Mines (CSM) soccer field. Monitor well CSMRI-6C is located approximately 27.2 feet to the south of the location of former well 6B, and monitor well CSMRI-11B is located approximately 51.5 feet to the northeast of the location of former well 11.

Surface water samples were collected on March 16, 2009, from SW-1 and SW-2. All aqueous samples were placed in iced coolers and couriered to Paragon Analytics Laboratory, Inc. of Fort Collins, Colorado or to TestAmerica, Inc. of Arvada, Colorado for analysis.

Figure 1 presents the monitor well and surface water sample locations. The figure also presents the groundwater potentiometric surface elevations based on depth to groundwater relative to the surveyed top-of-casing for the time periods of March 16 through March 18, 2009. The elevations of the groundwater potentiometric surface at the time of sampling are posted adjacent to each monitor well location. Historically the figure indicates a northeasterly component of flow for groundwater located on the bench terrace above the Clear Creek flood plain.

2.1 Groundwater Sampling

Water quality samples were collected following the procedures outlined in Appendix A, Groundwater Sampling Procedures. All monitor wells have depth-to-water measured to the nearest 1/100th of a foot (0.01) prior to sample purging. Graphs of water table elevation are presented as Figure 2 for monitor wells CSMRI-1, CSMRI-1B, CSMRI-4, CSMRI-5, CSMRI-6B (abandoned July 2008), CSMRI-7B (dry after December 2007), CSMRI-8, CSMRI-9, CSMRI-10, and CSMRI-11 (abandoned July 2008). Figure 2 monitor wells are all located within the CSMRI site proper and illustrates historical trends in changes to the potentiometric surface throughout the site.

The Figure 3 hydrograph of monitor well CSMRI-2, located near the southeast corner of the freshman parking lot on West Campus Drive and the Welch Ditch, is located upgradient of the CSMRI site and historically is used to provide background groundwater quality conditions. The hydrograph initially reflected the use of and leakage from the hearby irrigation ditch during the summer months in 2005 and 2006 by a seasonal rise in the potentiometric surface. Through late 2006 and 2007, the water level has remained elevated and only recently has shown a seasonal pattern of rising and falling.

Sample collection field forms that record the water quality parameters of the monitor well groundwater as it is purged and the volume removed are provided in Appendix B, Sample Collection Forms. After parameter stabilization, the water samples are filtered through a 0.45 micron (μ) filter, collected in laboratory-provided containers, and preserved in the field as appropriate for the analyte and analytical method. Some monitor wells require multiple trips in order to collect sufficient sample volume due to slow recharge.

After conferring with the Colorado Department of Public Health and Environment (CDPHE), CSM was allowed to remove select analytes from the March, September, and December quarterly sampling events. Specific analytes removed from the parameter analytical list included metals (arsenic, barium, cadmium, chromium, lead, mercury, selenium, silver, and vanadium) and radioisotopes (thorium 228, 230, and 232). These parameters will be sampled only once per year during the June (second quarter) sampling event. Analytes that have been added to the sampling program for all sampling events include anions (bicarbonate, carbonate, chloride, nitrate, nitrite, and sulfate); cations (calcium, magnesium, potassium, and sodium); plus ferrous/ferric iron (flood plain wells).

2.2 Surface Water Sampling

Surface water samples from Clear Creek were collected on March 16, 2009 from two locations: one upstream of the site (SW-1) and one downstream of the site (SW-2) as shown on Figure 1. The surface water samples were collected following the procedures outlined in Appendix C, Surface Water Sampling Procedures. Surface water samples are filtered through a 0.45μ filter, collected in laboratory-provided containers, and preserved in the field as appropriate for the analyte and analytical method.

As with the groundwater samples described above, sampling for select metals from the surface water sampling program has been reduced to once per year (June), and the anions, cations, and iron speciation has been added.

Discharge data of stream flow of Clear Creek, as measured by the United States Geological Survey, Golden, Colorado Clear Creek gauging station (#06719505 USGS Surface Water Online Database) during the first quarter from January 1, 2009 through March 31, 2009 are presented as Figure 4. Tabular representation of the data indicates provisional values of stream flow of 43, 44, and 46 cubic feet per second (cfs) during the sample dates of March 16, March 17, and March 18, respectively.

2.3 Analyses

All samples collected were analyzed using a Comprehensive Environmental Response, Compensation and Liability Act (CERCLA)-certified analytical laboratory. The results received from the laboratory were evaluated based on the following parameters:

- Data completeness
- Holding times and preservation
- Instrument initial calibrations
- Instrument performance checks
- Preparation blanks
- Duplicate sample results
- Laboratory control samples results
- Compound quantization and reporting limits (full validation only)

As a quality control/quality assurance (QA/QC) check, an equipment blank sample was collected in the field by pouring distilled water through a sample bailer and submitting the filtered aqueous sample for the identical analytical parameters as the groundwater and surface water samples. The results of the equipment blank analyses did not identify any interferences or anomalies in the laboratory data.

Results of the QA/QC check indicate the SW-1 sample was analyzed for Ra-228 on detector A3, which failed the daily performance check and there is a potential low bias of 7.2 percent for the reported result of 0.73 ± 0.54 pCi/l. Even though this sample had been prepped in duplicate and the duplicate was counted on a passing detector with both detectors yielding a non-detect result, the reported result for sample SW-1 is qualified as Rejected [R].

Data validation results are presented in Appendix D.

2.3.1 Groundwater Quality Analyses

Summaries of groundwater results for radioisotopes, metals, and inorganic anion and cations are presented in Table 2-1, Table 2-2, and Table 2-3, respectively. Groundwater parameters are reported as picoCuries per liter (pCi/l) for radioisotopes, micrograms per liter (μ g/l) for uranium, and milligrams per liter (mg/l) for metals.

Paragon Analytics Laboratory, Inc. of Ft. Collins, Colorado and TestAmerica Laboratories, Inc. of Arvada, Colorado conducted laboratory analyses of the aqueous samples. Analytical parameters submitted to Paragon included radium isotopes (Ra-226 and Ra-228), uranium (U), calcium (Ca), potassium (K), magnesium (Mg), sodium (Na), phosphorus (P), chloride (Cl), sulfate (SO₄), carbonate as calcium carbonate (CO₃), bicarbonate as calcium carbonate (HCO₃), dissolved organic carbon (DOC), and total phosphorous.

Analytical parameters submitted to TestAmerica include nitrate (NO₃), nitrite (NO₂), and ferrous (Fe²) and ferric (Fe³) iron. TestAmerica was selected to conduct the short holding time analyses because of their proximity to the CSMRI site.

Groundwater samples were measured onsite for purged volume, temperature, pH, specific conductance, dissolved oxygen (DO), oxygen reduction potential (ORP), and turbidity as nephlometer turbidity units (NTU) during the purging and sampling process. Onsite measurement parameters are presented on the sample collection forms in Appendix B.

Since the first quarter of monitoring in February 2005, the concentration of total uranium in mg/l had been analyzed using Paragon method 714R9. In this method, the concentration of uranium is calculated based on the activity of the uranium isotopes U-234, U-235, and U-238. Effective with the first quarter 2007 sampling event, the concentration of uranium is now analyzed using mass spectrometry method EPA 6020, which analyzes for total isotopic uranium and not for the activity of the individual isotopes.

Analytical data from Paragon and from TestAmerica as an electronic data deliverable (EDD) are presented in Appendix E on a compact disk as a series of Excel spreadsheets. Appendix F presents copies of the chain-of-custody for the CSMRI samples.

2.3.2 Surface Water Analyses

A summary of Clear Creek surface water results for radioisotopes, metals, and anions and cations are presented in Table 2-4, Table 2-5, and Table 2-6, respectively. Surface water parameters are reported as pCi/l for radioisotopes, μ g/l for uranium, and mg/l for metals. Surface water samples were measured onsite for temperature, pH, specific conductance, DO, ORP, and NTU as the sampling was conducted. Onsite measurement parameters are presented on the sample collection forms in Appendix B.

2.4 Health and Safety Program

Stoller developed a program to protect the health and safety of field personnel for implementation of the environmental monitoring at the CSMRI site. This program has been developed in accordance with requirements of 29 CFR 1910.120.

3. Results

Groundwater analytical results from samples collected from the CSMRI site during the first quarter 2009 for radioisotopes, metals, and anions and cations are summarized on Table 2-1, Table 2-2, and Table 2-3, respectively. Surface water analytical results from samples collected from the CSMRI site during the first quarter 2009 for radioisotopes, metals, and anions and cations are summarized on Table 2-4, Table 2-5, and Table 2-6, respectively. Table 2-7 presents historical data collected by previous consultants for select contaminants of potential concern in groundwater at the site. The historical uranium data presented in Table 2-7 are presented in pCi/l as "activity" yet recent (2005 through 2008) analytical data are presented in µg/l as "mass concentration." The December 7, 2000 Federal Register discusses the final uranium maximum contaminant level (MCL) and presents a conversion factor of a geometric average mass:activity ratio of 0.9 pCi/g for values near the National Primary Drinking Water Standards MCL, based on data from the National Inorganics and Radionuclides Survey.

Tables G-1 and G-2 in Appendix G present the quarterly historical groundwater radioisotopic and metals sample results, respectively, collected by Stoller since February 2005. Tables G-3

and G-4 in Appendix G present the quarterly historical Clear Creek surface water radioisotopic and metals sample results, respectively, collected by Stoller since February 2005.

3.1 Groundwater Conditions

Groundwater monitor wells are located in areas likely to detect impacts, if any, to groundwater emanating from the site as well as locations that represent background water quality. Monitor Wells CSMRI-4 and CSMRI-5 are located downgradient from the site in the Clear Creek flood plain. Well CSMRI-1 is located along Clear Creek upstream from the site, and well CSMRI-2 is located offsite on the southeast corner of the freshman parking lot on West Campus Drive. In February 2007, seven new groundwater monitor wells were installed to assess the effectiveness of the source excavation and stockpile creation that were conducted during the summer of 2006. Monitor well CSMRI-8 is located along Clear Creek within the flood plain area; and monitor wells CSMRI-1B, CSMRI-6B, CSMRI-7B, CSMRI-9, CSMRI-10, and CSMRI-11 are located on the upland areas and essentially encircle the CSMRI site.

In July 2008, two monitor wells (CSMRI-6B and CSMRI-11) were abandoned due to construction activities at the CSMRI site. These two wells were replaced in December 2008 with CSMRI-6C and CSMRI-11B, respectively.

3.2 Groundwater Quality

Groundwater samples were collected from eight monitor wells and tested for the presence of metals and radioisotopes as identified in Section 2.3.1. Groundwater samples were not collected from monitor wells CSMRI-6C, CSMRI-7B, and CSMRI-11B due to no water in the wells at the time of sampling.

The sum of the detected activities of Ra-226 $(2.37 \pm 0.81 \text{ pCi/l})$ and Ra-228 $(2.68 \pm 0.96 \text{ pCi/l})$ at monitor well CSMRI-2 exceeded the MCL standards of 5 pCi/l. In all other wells the detected activities of Ra-226 and Ra-228 were below the MCL standards as shown on Table 2-1. Figure 5 presents the historical activity results of CSMRI-2 for the summing of the Ra-226 and Ra-228. The graph indicates that since 2005 the activity results have been below the MCL until the most recent sampling event.

Uranium was detected in monitor wells CSMRI-4 at 80 μ g/l, CSMRI-8 at 980 μ g/l, and CSMRI-9 at 34 μ g /l at concentrations exceeding the MCL of 30 μ g /l. Uranium was also detected in the remaining six groundwater monitor wells but at concentrations below the MCL.

The detected concentration of uranium in CSMRI-9 at 34 μ g/l is higher than the initial February 2007 sampling at this location indicated a concentration of 7.9 μ g/l. The concentration of uranium then spiked to 35 μ g/l but until the March 2009 sampling event has fluctuated slightly above 20 μ g/l in the past five quarterly sampling events. This monitor well is located at the top of the bench terrace that rises above the flood plain.

In the flood plain area, uranium was detected in monitor wells CSMRI-4 at 80 μ g/l, CSMRI-5 at 11 μ g/l, and CSMRI-8 at 980 μ g/l. Uranium in monitor well CSMRI-4 has historically had elevated concentrations of uranium, but the values had been declining since 1991 until the last several quarterly sampling events as shown on Figure 6. Historically, the concentration of

uranium in this monitor well has spiked; once in 1999 and then again in 2003. The spike in the concentration of uranium in 2003 was attributed to precipitation effects at the CSMRI site and removal of the site asphalt and concrete as discussed in Section 4.2.2 of the New Horizons RI-FS (New Horizons 2004). Soil remediation activities in the flood plain area in December 2006 may have affected the recent rise in the concentration of uranium in this monitor well.

Figure 7 presents the potentiometric surface elevation of the groundwater in CSMRI-4 (left Y axis) and the concentration of uranium (right Y axis) from 2005 through the first quarter 2009. The figure indicates the concentration of uranium had previously been fluctuating seasonally slightly above to slightly below the MCL of 30 μ g/l for seven quarterly sampling events in 2005 and 2006. Since 2007 the concentration of uranium in this well has increased after the 2006 surface soil remediation activities. An ice chest from the fourth quarter 2007 (December) sampling event was lost by the courier service resulting in a gap in the analytical data for CSMRI-4.

The concentration of uranium detected in CSMRI-8 decreased to 980 μ g/l from the previous quarterly value of 1,900 μ g/l. Monitor well CSMRI-8 was installed in February 2007. Figure 8 presents the potentiometric surface elevation of the groundwater at this well (left Y axis) and the concentration of uranium (right Y axis) from 2007 through the first quarter 2009. quarterly monitoring will be continued to document seasonal variability and trends in the concentration of uranium at this location.

The groundwater at the CSMRI site will be monitored on a quarterly basis and the exceedances of uranium in monitoring wells CSMRI-4, CSMRI-8, and CSMRI-9 will continue to be evaluated as more data are made available. The relationship between the seasonal stream flow of Clear Creek and the exceedances of uranium for the monitor wells located on the flood plain will be assessed.

3.2.1 Ionic Balance Evaluation

Groundwater and surface water samples were collected and tested for major anions and cations, dissolved organic carbon, and at select locations (CSMRI-1, CSMRI-4, CSMRI-5, and CSMRI-8) ferric and ferrous iron. Analytical results for these parameters are presented in Table 2-3 for groundwater and Table 2-6 for surface water. Ionic balance calculations between the anions and cations for all samples indicate good results for most samples (less than 5 percent difference). Summary sheets from the AqQA® geochemical software for each of the water samples are presented in Appendix H. Dominant water types identified at the CSMRI site include Ca-Cl (CSMRI-1); Ca-HCO₃ (CSMRI-2, CSMRI-5, CSMRI-9, and CSMRI-10); and Ca-SO₄ (CSMRI-4, CSMRI-8, SW-1, and SW-2).

A Piper quadrilateral diagram is included in Appendix H and presents the overall chemical properties and water types for each water sample.

3.2.2 Comparison of Upgradient and Downgradient Groundwater Quality

Monitor wells CSMRI-4, CSMRI-5, and CSMRI-8 are downgradient from the site and are located on the Clear Creek flood plain. Monitor wells CSMRI-7B, CSMRI-9, and CSMRI-10 are located downgradient of the CSMRI site at the top of a topographical slope above the flood

plain. Monitor well CSMRI-11B is located at the eastern edge of the site, and monitor wells CSMRI-1B and CSMRI-6C are located upgradient to the site.

Metals concentrations that are above detection limits vary widely regarding upgradient versus downgradient wells. The analytical data indicate the influence of Clear Creek to CSMRI-1 where Ca was detected in SW-1, SW-2, and CSMRI-1 at concentrations of 35 mg/l, 37 mg/l, and 46 mg/l, respectively. The analytical results indicate the presence of Ca at a concentration of 250 mg/l in monitor well CSMRI-8, over twice the concentration of most of the other monitor wells. The same observation for elevated concentrations of K, Na, Mg, and sulfate in monitor well CSMRI-8 applies when compared to other monitor well analytical data.

Uranium was detected in monitor wells CSMRI-9 at a concentration of $34 \mu g / l$, CSMRI-4 at a concentration of $80 \mu g/l$, and in CSMRI-8 at a concentration of $980 \mu g/l$, which exceed the MCL of $30 \mu g/l$. As shown on Figure 7, until the last several rounds of sampling, there appeared to be a seasonal correlation between fluctuations of the water table elevation and the concentration of uranium in monitor well CSMRI-4. The recent rise in the concentration of uranium in CSMRI-4 will continue to be monitored to assess the variability of uranium in this monitor well and the interaction with the seasonal fluctuations of Clear Creek.

Quarterly monitoring will be continued at monitor well CSMRI-8 to document the seasonal variability and trends of the presence of uranium at this location.

3.2.3 Comparison with Previous Groundwater Quality Analyses

Table 2-7 presents groundwater analytical results from past sampling events dating back to 1991 for radioisotopes of concern. The data indicate a slight decreasing trend in contaminant concentrations over time, indicating improving groundwater quality.

As additional data are collected and trends become more defined, graphs of concentration versus time will be produced and presented. This analytical data will be incorporated to show long-term trends and correlation between the detected concentration of uranium in groundwater, the fluctuating water table, and seasonal variability if present.

3.2.4 Comparison with Colorado Groundwater Standards

The statewide activity standard of 5 pCi/l for the sum of Ra-226 and Ra-228 in drinking water was exceeded in monitoring well CSMRI-2. No exceedances of the MCL for tested metals were identified in any of the groundwater and surface water samples.

The MCL for uranium in drinking water was exceeded in monitor wells CSMRI-9 at a concentration of 34 μ g /l, CSMRI-4 at a concentration of 80 μ g/l, and in CSMRI-8 at a concentration of 980 μ g/l, which exceed the MCL of 30 μ g/l. In January 2008, CDPHE Water Quality Control Commission adopted the surface water quality standard of 30 μ g/l as the groundwater quality standard in an effort to keep both uranium standards consistent.

The spikes in the concentration of uranium in CSMRI-4 shown in Figure 7 may be attributed to the increased precipitation during the months of December 2006 through February 2007 and surface soil remediation activities in the flood plain. This monitor well exhibited the same trend

in 2003 during a prolonged high precipitation time period and when the asphalt cover and buildings associated with CSMRI had been removed.

The concentration of uranium at 980 μ g/l at monitoring well CSMRI-8 may be due to the following factors:

- The well contains residual uranium from the former pond area on the flood plain.
- Uranium was disturbed and introduced into the monitor well during installation.
- The well contains residual uranium from the former Building 101 area at the top of the slope above the flood plain.
- Uranium is naturally occurring in the Fox Hills bedrock formation.
- The well is located in a zone where strong mixing between Clear Creek water and groundwater occurs, and the oxidizing conditions associated with creek water causes uranium to dissolve more readily.

Monitoring well CSMRI-8 will continue to be sampled on a quarterly basis along with the other site wells, and the reason for the elevated level of uranium will be evaluated.

3.3 Surface Water Quality

Surface water samples are collected from two locations at the site. Location SW-1 is located upstream from the site and the second location, SW-2, is downstream from the site. The metals detected above their respective detection limits include: Ca, K, Mg, and Na. The upstream and downstream surface-water concentrations of all metals and radionuclides detected at the CSMRI site from stations SW-1 and SW-2 are similar. No established MCLs were exceeded.

4. Activities for First Quarter 2009

The artificial turf soccer field that overlies the former CSMRI site and the artificial turf football practice field to the south are in-place and construction is nearing completion. Both fields overlie drain beds with perimeter drains that collect any direct precipitation onto the fields and discharge the water to the flood plain area. The affect of the drains in reducing the contribution of precipitation to the groundwater at the former CSMRI site will be monitored.

5. References

Colorado Department of Public Health and Environment, Water Quality Control Commission, Regulation No. 41, *The Basic Standards for Ground Water*. Amended: January 14, 2008, Effective: May 31, 2008.

New Horizons Environmental Consultants, Inc. Remedial Investigation/Feasibility Study and Proposed Plan, Colorado School of Mines Research Institute Site, Golden, CO, January 21, 2004.

Stoller, Final Site Characterization Work Plan, May 2006.

USGS Surface Water website: http://nwis.waterdata.usgs.gov

			a-226 oCi/l)	Ra (I	Total U (µg/l)	
Sample Station	Sample Date	Result	Uncertainty	Result	Uncertainty	Result
CSMRI-1	3/17/09	0.09	0.19	0.96	0.52	2
CSMRI-1B	3/18/09	0.2	0.19	1.15	0.59	8.1
CSMRI-2	3/18/09	2.37	0.81	2.68	0.96	0.77
CSMRI-4	3/17/09	0.54	0.31	0.56	0.6	80
CSMRI-5	3/17/09	0.29	0.28	1.24	0.6	11
CSMRI-6C	DRY	NT	NT	NT	NT	NT
CSMRI-7B	DRY	NT	NT	NT	NT	NT
CSMRI-8	3/18/09	0.31	0.26	0.69	0.47	980
CSMRI-9	3/16/09	0.17	0.18	0.45	0.47	34
CSMRI-10	3/16/09	.15	0.19	1.01	0.54	16
CSMRI-11B	DRY	NT	NT	NT	NT	NT
M	CL*		30			

Table 2-1Summary of Radioisotopes in Groundwate

*Maximum Contaminant Level – National Primary Drinking Water Regulations

**5 CCR 1002-41 Reg 41 – Colorado Groundwater Standards

NT - Not Tested

					Summa	ry of Metals	s in Ground	lwater			
Sample Station	Sample Date	Ag	As	Ва	Са	Cd	Cr	Hg	к	Mg	Na
CSMRI-1	3/17/09	NT	NT	NT	46	NT	NT	NT	3	14	27
CSMRI-1B	3/18/09	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT
CSMRI-2	3/18/09	NT	NT	NT	76	NT	NT	NT	6.4	34	19
CSMRI-4	3/17/09	NT	NT	NT	100	NT	NT	NT	9.3	45	63
CSMRI-5	3/17/09	NT	NT	NT	110	NT	NT	NT	4.4	40	44
CSMRI-6C	DRY	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT
CSMRI-7B	DRY	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT
CSMRI-8	3/18/09	NT	NT	NT	250	NT	NT	NT	13	74	97
CSMRI-9	3/16/09	NT	NT	NT	100	NT	NT	NT	4.7	49	45
CSMRI-10	3/16/09	NT	NT	NT	110	NT	NT	NT	4.5	43	43
CSMRI-11B	DRY	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT
Detection	n Limits	0.01	0.01	1	1	0.005	0.01	0.0002 (B)	1	1	1
MCL*		NE	0.010	NE	NE	0.005	0.1	0.002 (B)	NE	NE	NE

Table 2-2Summary of Metals in Groundwater

*Maximum Contaminant Level – National Primary Drinking Water Regulations

**5 CCR 1002-41 Reg 41 – Colorado Groundwater Standards

NE - Not Established

NT – Not Tested – Scheduled for June only (2nd Quarter)

Pb	v
NT	NT
0.003	0.01
0.015	NE

Sample Station	Sample Date	Bicarbonate as CaCO₃ (mg/l)	Carbonate as CaCO₃ (mg/l)	Total Alkalinity as CaCO₃ (mg/l)	Chloride (mg/l)	Dissolved Organic Carbon	Ferric Iron (mg/l)	Ferrous Iron (mg/l)	Total Iron (ug/l)	Nitrate (mg/l)	Nitrite (mg/l)	Dissolved Phosphorous (mg/l)	Sulfate (mg/l)
CSMRI-1	3/17/09	67	10	67	76	1	ND	ND	ND	0.78	ND	ND	81
CSMRI-1B	3/18/09	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT
CSMRI-2	3/18/09	310	20	310	13	1	NT	NT	NT	ND	ND	ND	62
CSMRI-4	3/17/09	260	20	260	120	3.7	ND	ND	ND	2.1	ND	0.083	190
CSMRI-5	3/17/09	230	20	230	120	2.1	ND	ND	ND	6.5	ND	ND	130
CSMRI-6C	DRY	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT
CSMRI-7B	DRY	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT
CSMRI-8	3/18/09	350	20	350	180	3.6	ND	ND	ND	ND	ND	ND	530
CSMRI-9	3/16/09	240	20	240	130	1.7	NT	NT	NT	7.5	ND	ND	110
CSMRI-10]3/16/09	250	20	250	110	1.8	NT	NT	NT	9.9	ND	ND	120
CSMRI-11B	DRY	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT
Reporti	ng Limits	5 or 20	5 or 20	5 or 20	1, 2 or 4	1	0.20	0.20	100	0.50	0.50	0.05	1, 10 or 20

 Table 2-3

 Summary of Anions and Cations in Groundwater

ND - Non Detect

NT – Not Tested

Table 2-4Summary of Radioisotopes in Surface Water

Sample	Sample	Ra-226	i (pCi/l)	Ra-228	Total U (µg/l)	
Station	Date	Result	Uncertainty	Result	Uncertainty	Result
SW-1	3/16/09	0.14	0.16	0.73	0.54	1.9
SW-2	3/16/09	0.2	0.22	0.29	0.47	1.9
M	CL*		Total I	Ra = 5		30

*Maximum Contaminant Level - National Primary Drinking Water Regulations

**5 CCR 1002-31 Reg 31 – Colorado Surface Water Standards

NE – Not Established

Table 2-5 Summary of Metals in Surface Water (All results in milligrams per liter)

Sample Station	Sample Date	Ag	As	Ba	Ca	Cd	Cr	Hg	K	Mg	Na	Pb	V
SW-1	3/16/09	NT	NT	NT	35	NT	NT	NT	3.1	8.9	17	NT	NT
SW-2	3/16/09	NT	NT	NT	37	NT	NT	NT	3.5	9.7	19	NT	NT
Detecti	on Limits	0.01	0.01	0.1	1	0.005	0.01	0.0002	1	0.01	1	0.003	0.01
MCLs*		0.01	0.010	2	NE	0.005	0.1	0.002	NE	NE	NE	0.015	NE

*Maximum Contaminant Level - National Primary Drinking Water Regulations

ND - Non Detect

NE – Not Established

NT – Not Tested - Scheduled for June only (2nd Quarter)

Sample Station	Sample Date	Bicarbonate as CaCO ₃ (mg/l)	Carbonate as CaCO₃ (mg/l)	Total Alkalinity as CaCO₃ (mg/l)	Chloride (mg/l)	Dissolved Organic Carbon (mg/l)	Ferric Iron (mg/l)	Ferrous Iron (mg/l)	Total Iron (mg/l)	Nitrate (mg/l)	Nitrite (mg/l)	Total Phosphorous (mg/l)	Sulfate (mg/l)
SW-1	3/16/09	47	5	50	30	1.3	NT	NT	NT	ND	ND	ND	83
SW-2	3/16/09	53	5	53	34	1.5	NT	NT	NT	ND	ND	ND	86
Reporti	Reporting Limits		5	5	0.4	1				0.50	0.50	0.05	1

Table 2-6 Summary of Anions and Cations in Surface Water

ND = Not Detected at or above the Reporting Limits

NT = Not Tested

Table 2-7
CSMRI Historical Groundwater Data (Previous Consultants)
(All regults in pigeCuries per liter)

Well ID (d)	Analyte	1/1991 (a)	6/1991 (a)	3/1999 (b)	6/1999 (b)	10/1999 (b)	2/2003 (c)	4/2003 (c)	7/2003 (c)	10/2003 (c)
CSMRI-1	Ra-226			0.1	0.3	0.2	<0.55	<0.45	ND (<0.38)	ND (<0.31)
	U Total			2.09	2.59	1.44	2.4	2.9	0.87	1.4
	Th-230			0.4	0.2	0.2	<0.19	0.21	ND (<0.13)	<0.15
CSMRI-2	Ra-226		1.9	1.9	1.4	1.4	1.4	2.8	2.1	1.7
	U Total	11	5.7	0.55	1.46	0.71	1.5	1.3	1.9	1.3
	Th-230		0	0.1	0.1	0.9	<0.17	0.43	0.20	0.31
CSMRI-3	Ra-226		0.6	1.5	1.2	1.6	<0.75	<0.81	ND (<0.49)	<0.98
	U Total	17	10.4	8.41	12.4	10	12	12	9	10
	Th-230		0	0.3	0.3	1.1	<0.12	ND (<0.15)	ND (<0.17)	ND (<0.14)
CSMRI-4	Ra-226		1	<0.4	0.6	0.4	<0.85	< 0.42	<0.32	ND (<0.64)
	U Total	86	57.3	23.4	58.6	33.7	16	34.2	53	19
	Th-230		0	0.7	0.3	0.4	<0.099	ND (<0.15)	ND (<0.17)	ND (<0.12)
CSMRI-5	Ra-226		0.6	2.4	3.3	2.7	ND (<0.49)	1.1	2.6	1.59
	U Total	14	16.8	3.6	3.6	4	2.8	2.3	2.7	3.3
	Th-230		0	0.2	0.2	1.4	0.062	ND (<0.14)	ND (<0.19)	ND (<0.13)

Notes: ND = Not Detected

a - Samples collected by Grant and Associates and analyzed by Barringer Labs
b - Samples collected by URS Greiner Woodward Clyde and analyzed by CORE Labs
c - Samples collected by New Horizons Environmental Consultants and analyzed by Paragon Analytics; Total U activity (pCi/l) calculated from concentration (μg/l) reported by Paragon.
d - Well Identification numbers changed from the 1991 data to the 1999 data. Data presented account for this change





Figure 2 CSMRI All Monitor Wells Hydrograph






Figure 4 Clear Creek Gauging Graph January – March 2009





Figure 5 CSMRI-2 Sum of Ra-226 and Ra-228



Only activity results are presented.

Total propagated uncertainty (TPU +/-) activity results are not presented.




Figure 6 CSMRI-4 Historical Total Uranium Concentration (1990 - 2009)

Date

Figure 7 CSMRI-4 Total Uranium Concentration and Potentiometric Elevation





Figure 8 CSMRI-8 Total Uranium Concentration and Potentiometric Elevation



Appendix A Groundwater Sampling Procedures

Groundwater Sampling

1.0 Purpose

This procedure describes actions to be used to sample groundwater from monitoring wells and piezometers. Monitoring wells are generally sampled on a semiannual, quarterly, or monthly basis, or by special request in support for specific projects. All wells are to be sampled using this procedure unless superseded by specific site, facility, or client procedures.

This procedure describes equipment decontamination and transport, site preparation, detection and sampling of immiscible layers, water level measurements, well purging, sample collection, field and analytical parameters, quality assurance/quality control (QA/QC) requirements, and documentation that shall be used for field data collection.

2.0 Scope

This document describes acceptable methods for the sampling of wells and piezometers.

3.0 Responsibilities and Qualifications

Personnel performing groundwater sampling procedures are required to have completed the initial 40-hour OSHA classroom training that meets the Department of Labor requirements at 29 CFR 1910.120(e)(3)(i), and must maintain a current training status by completing the appropriate annual 8-hour OSHA refresher courses. Personnel must also have read the appropriate project, site, or facility Health and Safety Plan(s). Prior to engaging in groundwater sampling activities, personnel must have a complete understanding of the procedures described within this procedure and, if necessary, will be given specific training regarding these procedures by other personnel experienced in the methods described within this procedure.

4.0 Groundwater Sampling Procedures

4.1 Introduction

Many monitoring wells are constructed of either 2-inch stainless steel, or 2- or 4-inch flush threaded PVC casing. Some piezometers are completed as monitoring wells, and they are usually constructed of ³/₄-inch inside diameter, flush threaded PVC casing. Some wells have been constructed to incorporate a sump below the well screen. Because these vary in length, the well construction diagrams should be consulted to determine the sump lengths for specific wells. Most piezometers are constructed with a flush threaded cap at the bottom of the well screen. However, the well construction diagrams should also be consulted for information about specific piezometers.

Procedures for groundwater sampling are designed to obtain a sample that is representative of the formation water beneath the site in question. Since an analysis of the quality of formation water is desired, standing water within the well must be purged before sampling. Also, a measure of the static water elevations is important to determine the effect of seasonal horizontal and vertical flow gradient changes during site characterization activities.

Groundwater sampling procedures can be initiated after sampling personnel take the required water level measurements and purge the well in accordance with this procedure. Methods for accomplishing each of these activities are included in this procedure in the following sequence:

- Collection of immiscible layers samples, if present
- Well purging
- Groundwater sampling using a bailer

- Groundwater sampling using a peristaltic pump
- Groundwater sampling with a bladder pump

4.2 General Equipment Requirements

Down-hole sampling equipment shall be constructed of inert material such as polytetrafluoroethylene (Teflon[®]) or stainless steel. This equipment shall be assessed on an individual basis prior to use in the field.

The following is a primary list of well sampling and associated equipment:

- Bailers Teflon[®], stainless steel, or other appropriate inert materials
- Teflon³⁰ coated stainless steel cable with reels
- Peristaltic pumps and tubing
- Water level measuring devices sufficiently accurate to measure water levels to the nearest 0.01 foot
- Graduated purge water containers
- Plastic sheeting
- Distilled or deionized water
- Decontamination equipment and supplies
- Organic vapor detector (OVD)
- Gloves (nitrile)
- Calculator and watch
- Sample containers precleaned to EPA specifications
- pH paper
- Custody tape
- Coolers with sufficient blue ice to cool samples to 4°C
- Preservatives (trace metals grade)
- Disposable in-line 0.45-micron membrane filters
- Logbooks and field forms
- Black waterproof pens
- Portable laboratory equipment for measuring field parameters for pH, temperature, specific conductance, and turbidity
- Total alkalinity reagent
- Beakers and graduated cylinders

Additional equipment may be required to meet project or client health and safety standards, to perform specialized sampling, or to meet personnel and equipment decontamination requirements.

4.3 Equipment Decontamination and Transport

Equipment associated with the tasks involved in groundwater sampling shall be decontaminated upon arrival at the sampling location. All sampling equipment shall be decontaminated between

sample locations. Decontamination frequency shall be increased appropriately as field conditions dictate.

Transportation of all equipment shall be performed in a manner that eliminates any possibility of cross-contamination. Calibration solutions, fuel, decontamination solutions and wastewater, and all other sources of contamination shall be segregated from sampling equipment during transport. Purge water being transported to holding areas shall be kept in closed containers.

If the decontamination of downhole equipment is not performed at the well, used downhole equipment shall be wrapped in plastic sheeting and/or segregated from clean equipment to eliminate the possibility of cross contamination. The equipment shall then be decontaminated as soon as possible.

4.3.1 Routine Field Decontamination

Decontamination of delicate equipment and the routine decontamination of sampling equipment prior to use at each well shall consist of the following steps:

- Vigorously scrub the equipment with a brush and solution of phosphate-free laboratory grade detergent (e.g., Liquinox) and distilled water.
- Rinse the equipment thoroughly with approved distilled water.
- If the decontaminated equipment is not immediately packaged to eliminate any adhesion of airborne impurities, perform an additional final rinse, or decontamination and rinse, immediately prior to actual sampling operations.

4.3.2 Routine Decontamination of Sampling Pumps

The external surfaces of all non-dedicated pumping equipment shall be decontaminated as described in Subsection 4.3.1. Internal surfaces shall be decontaminated according to the following procedures, except under special situations where the pump(s) must be disassembled and the internal parts cleaned separately (see Subsection 4.3.3). For routine decontamination, the following procedures shall be followed.

- Pump several pump volumes of a solution of a phosphate-free laboratory grade detergent (e.g., Liquinox) and water through the equipment.
- Displace the soap solution immediately by pumping approved distilled water, equivalent to three or more volumes of the pump storage capacity, through the equipment.
- If any detergent solution remains in the pump, continue pumping distilled water through the system until the detergent is no longer visibly present. Sudsing is the common indicator used to determine incomplete rinsing.

4.3.3 Unusual Decontamination Requirements

When equipment becomes grossly contaminated, such as from the collection of immiscible layer samples (see Subsection 4.5), routine decontamination of sampling equipment is not considered sufficient and thus is not allowed. This situation and other unusual equipment decontamination problems shall be reported to the field site supervisor. Under certain circumstances, a pump can be disassembled and the parts cleaned separately using approved solvents (i.e., hexane, alcohol, etc.). If specific instructions are required, the field site supervisor shall consult with a management representative for proper decontamination procedures.

4.3.4 Disposition of Decontamination Water

All water generated during the decontamination of equipment used for the sampling of wells shall be containerized in either a satellite container or in the purge water container in the groundwater sampling vehicle. It will then be disposed of according to the procedure designated in Subsection 4.6.3 of this procedure.

4.4 Site Preparation

Sheet plastic may be used to protect clean equipment from contacting contaminated surfaces. Plastic bags and sheeting, along with the segregation of clean and dirty equipment, can be used to reduce the chances of cross contamination. If a mechanical bailer retrieval system is used, the amount of plastic appropriate for protection of sampling equipment may be lessened. The sampling crew members are responsible for determining the amount of plastic sheeting required.

Disposable nitrile gloves, or gloves made of other approved materials, shall be used at all times when handling sampling equipment. Gloves shall be changed between each site and as often as necessary to ensure the integrity of clean sampling equipment.

4.5 Collection of Immiscible Layer Samples

When specified in the project sampling plan, or when the well to be sampled contains immiscible layers, immiscible phases must be collected before purging activities begin. The method of choice for collecting light non-aqueous phase liquids (LNAPLS) is a bottom valve bailer or peristaltic pump. Dense non-aqueous phase liquids (DNAPL) or "sinkers" shall be collected with a bottom double check valve bailer or peristaltic pump.

In all cases, the bailer shall be carefully lowered into the well so that agitation of the immiscible layer is minimal. Any bailer used to collect immiscible layers shall be dedicated to the well that is sampled. Peristaltic pumps shall be equipped entirely with silicon, or other chemical compatible tubing, when sampling immiscible layers. The project manager shall be responsible for determining the type materials to be used for specific projects. Dedicated equipment used for collecting immiscible layers shall be decontaminated prior to and after use as described in Subsection 4.3 of this procedure, if removed from the well.

Immiscible layer sampling shall be performed as follows.

- Remove dedicated bailers from the well and decontaminate as specified in Subsection 4.3 of this procedure. Decontaminate dedicated pump tubing, if used, prior to use.
- For LNAPLs, carefully lower the bailer intake or sampling port to the midpoint of the immiscible layer and allow it to fill while it is held at this level. The bailer must be lowered into the immiscible layer slowly so that minimal agitation of the immiscible layer occurs. Peristaltic pump intakes must also be lowered to the midpoint of the immiscible layer.
- If a DNAPL layer is being sampled, use either the double check valve bailer or peristaltic pump. Lower the bailer into the well until bottom is encountered. Lower peristaltic pump intakes also to the well bottom. Care must be taken not to immerse the pump intake into accumulated sediments.
- Do not allow the bailer or line to touch the ground at any time or allow the ground to come in contact with other physical objects that might introduce contaminants into the well.
- Decontaminate all equipment immediately after sampling is completed. Suspend dedicated bailers in the well from the well cap above the high water level. Discard silicon tubing used with peristaltic pumps.

4.6 Well Purging

Purging stagnant water from a well is required so that the collected sample is representative of the formation groundwater. The device used (bailer or pump) depends upon aquifer properties, individual well construction, and data quality objectives. Wells that contain immiscible layers will not be purged unless specified in the site-specific work plan. Any well scheduled for purging and sampling that subsequently is found to contain immiscible layers must be reported to the site supervisor or project manager. The project manager shall be notified immediately prior to continued activities.

Before obtaining water level elevations or initiating purge activities, obtain the following information in reference to the well to be sampled, and enter the applicable information on the sample collection log.

- Location code (well number)
- Previous purge volume (information only)
- Depth to top of screen (bailed wells only)
- Well sample number
- Report Identification Number (RIN)
- Sample event number

Record the location code (well number), date, sampling team members, visitors, well condition, and any other pertinent information on the sample collection log. Enter the well number, time well is opened, and other information regarding the field activities on the Field Activity Daily Log.

The field instruments shall be standardized (to check calibration) and the results recorded on the sample collection form.

Measure the depth to the top of the water column and the total depth of the well in order to determine the height of the water column in the well. Calculate the well casing volume using the well casing inner diameter and the height of the water column in the well. The formula for calculating the volume in gallons of water in the well casing is as follows:

 $(\pi r^2 h)$ 7.481 = gallons; where

 $\pi = 3.142$

r = inside radius of the well pipe in feet

h = linear feet of water in well

7.481 =gallons per cubic foot of water

1 gallon = 3785 ml

Calculations of the volume of water in typical well casings may be done as follows:

a. 2" diameter well:

0.16 gal./ft x (linear ft of water) = gallons of water

b. 4" diameter well:

0.65 gal./ft x (linear ft of water) = gallons of water

c. 3/4" diameter well:

87 ml./ft x (linear ft of water) = milliliters of water

4.6.1 Purging Duration

Purging shall be considered complete if any of the following conditions are met.

- Purging is complete if at least three casing volumes of water are removed from the well, and the last three consecutive pH, specific conductance, and temperature measurements do not deviate by more than the following: 1) pH = ±0.1 pH units; 2) Specific Conductance = ±10% and; 3) temperature ±0.5°C. A turbidity measurement will be taken for every other purge sample for wells that are purged using a bailer. For wells that are equipped with a dedicated bladder pump, the turbidity will be measured each time the parameters are taken. The purge rate should be such that the turbidity is maintained at 5 NTU units or less (if possible). If the readings are not stabilized after three volumes, continue purging until stabilization or until five volumes have been removed. Field parameter measurements shall be collected after every half-casing volume (approximate) is removed from the well. When casing volumes are less than 1-liter, parameter measurements will be collected after each whole casing volume is removed. If readings do not stabilize after five well volumes have been recovered, obtain additional guidance from the project manager concerning the proper course of action.
- 2. A well is considered dewatered when only a few milliliters of water (or none) can be recovered each time the bailer is lowered into the well. When this occurs, a 10-minute recharge rate will be calculated (linearly). If, at the end of the 10-minute period, the well has not recovered sufficiently to continue the purge in thirty minutes, the purge is considered completed. If, at the end of the 10-minute period, there is sufficient water to collect the VOA samples, the samples may be collected at that time. If the well has not recovered sufficient water during the 10 minutes, and depending upon the well history, the samplers may elect to return to the well the same day (preferably within two hours), check the water level, and collect the VOA samples (first), and other samples as feasible. If the sample team cannot return the same day, the well will be checked in 24 hours to determine if sample collection is feasible. If an extended period of time is required to collect samples, the procedures in Subsection 4.8.1 shall be followed. The well will not require an additional purge before sampling.

Wells that dewater (have a slow recharge rate as specified in 2 above) will not be restricted by parameter stabilization requirements. Sampling of these wells will follow the protocol established in Subsection 4.8.

4.6.2 Purging Methods

Wells will be purged by either bailing or pumping. When purging a well, the rate of water withdrawal during purging should not exceed the rate of withdrawal at which the well was developed (if known). All purge times (initiation and completion) and the rate of purging will be recorded on the field log sheets.

4.6.2.1 Bailing

Generalized procedures for purging a well with a bailer are as follows.

• Prepare the sampling site as discussed in Subsection 4.4. Use properly decontaminated equipment to determine the static water level of the well. Measure the total depth of the well. Use this information to determine the volume of water in the well casing.

- Decontaminate all dedicated bailers prior to initiating purging as described in Subsection 4.3 of this procedure.
- Use a mechanical reel equipped with Teflon[®] coated stainless steel cable attached to a bailer for bailing and sampling operations. Lower the bailer slowly into the well until water is encountered. Minimize agitation of the well water. Avoid lowering the bailer to the bottom of the well so sediments accumulated in the bottom do not become suspended. For wells that dewater, do not allow the bailer to strike the well bottom with force. Raise and lower the bailer carefully to limit surge energy and ensure that cable does not come in contact with any potentially contaminated surfaces. Do not allow the cable to drag along the well casing or against other objects that will cause fraying. Monitor the amount of water purged.

Wells with significant levels of contamination may have dedicated bailers installed. Dedicated bailer systems shall consist of a Teflon[®] bailer with check valve or double check valve for DNAPLS and a 5-foot leader of Teflon[®] coated stainless steel cable. Bailer sampling attachments and the stainless steel reel cable will not be dedicated to individual wells.

Dedicated bailers will be decontaminated at the conclusion of sampling activities and suspended from the well cap above the high water table. If the well interval above the high water table is not adequate to allow for storage in the casing, the dedicated bailers will be stored in labeled and sealed plastic bags at the equipment trailer.

4.6.2.2 Pumping

Pump designs that meet the following criteria are allowed for purging.

- The pump is constructed of a material that does not introduce a source of contamination to the well.
- The pump drive system does not introduce a source of contamination into the well.
- All downhole parts to the pump can be easily decontaminated.
- A return check system that does not allow pumped water to return to the well is integral in the pump design.
- The pump is easily used and does not require excessive amounts of time to install, use, remove, and decontaminate.

The pumps currently in use to purge groundwater include peristaltic pumps and dedicated submersible bladder pumps. A procedure for the use of each style of pump is specific to its applications. User manuals, which accompany each pump, shall be referenced for operating procedures.

Basic operating procedures common to all pumps are as follows.

- Prepare the sampling site as described in Subsection 4.4 regardless of the type of pump being used.
- Use properly decontaminated equipment to determine the static water level and the total depth of the well. This information is utilized to determine the volume of water in the well casing.

12

- For wells with dedicated pumps, calculate the minimum purge volume using the pump storage volume and the volume of the discharge tubing. A total depth of a 2-inch well cannot be taken without the removal of the pump.
- Position a dedicated pump near the bottom of the well or according to the information on the well construction form. Monitor the discharge rates and the amount of water purged during purging. The pumping rate for purging can be higher than the pumping rate for sampling, however, the water level in the well should be monitored during purging to avoid excessive water level drawdown.
- Ensure that any tubing that enters the well casing is composed of inert material. Disposable silicon tubing will be used in the drive mechanism of peristaltic pumps and discarded after each well is purged. The air supply for all air-driven pumps (dedicated bladder pumps) will be free of oil (i.e., no hydrocarbon containing substances will be added to the compressor).
- 4.6.3 Disposition of Purge Water

All water removed from a well during sampling operations shall be collected either in a satellite container or the purge water collection container in the groundwater sampling vehicle. The water from these containers will then be transferred to another approved collection container on the sampling or project site. When the collection container is filled, or is near capacity, it will be transported for disposition or treatment in accordance with approved project plans.

4.7 Measurement of Field Parameters

The following field parameters will be measured during groundwater purging operations unless otherwise specified by the project manager or the approved project work plans.

Parameter	Relative Precision	Minimum Calibration
рН	0.01 pH units	Daily
Conductivity	$10 \mu\text{S/cm}$	Daily
Temperature	0.1 °C	Weekly
Total Alkalinity (unfiltered)	1 mg/l	None
Turbidity (photometric)	2 FTU (or NTU)	Specified purge samples (bailed wells) Daily (dedicated bladder pump wells)

The measuring equipment shall be stored and handled in a manner that will maintain the integrity of the equipment. Appropriate field manuals will accompany each instrument in the field. Each instrument will also be given an identification number. All logbook and field form references to individual instruments will refer to this number for ease of identification.

Field parameters will be measured at the following intervals.

• Conductivity, pH, temperature, and turbidity shall be measured from the first water removed from the well when initiating well purging procedures. For bailed wells, the initial bail of water will be carefully removed from the well and the water transferred to a sample beaker by decanting the bailer through a bottom control valve. For wells

purged with a peristaltic pump, similarly collect the first water removed in a sample beaker and then measure parameters. For wells with dedicated pumps, measure the parameters of the first recovered water that is collected in the continuous sampler.

- During purging operations, conductivity, pH, and temperature shall be measured for every half-casing volume (one half of the initial casing volume as calculated on the sample collection log form) of water removed from the well (because of the accuracy of the graduated containers for the purge water, the purge volume will be estimated as close as feasible). For wells that have half volumes less than the volume of a sample bailer (approximately 1 liter), only measure parameters after each full casing volume of water is removed from the well. Turbidity will be measured on every other sample recovered for parameters for bailed wells, or wells purged with a peristaltic pump. All parameters, including turbidity, will be measured at predetermined intervals while purging wells with dedicated pumps.
- During purging, if a well is dewatered prior to the measurement of the final required set of parameters, then conductivity, pH, temperature, and turbidity shall be measured immediately before the start of sample collection. These parameters may be delayed until sampling is completed if, at the discretion of the sampling crew, the well recharge has provided insufficient water volume to collect all the samples and also measure parameters. If there is insufficient water for samples and field parameters, the parameters will not be measured.
- Total alkalinity measurements shall be collected only once upon completion of purging. For wells that do not dewater and sample collection proceeds to completion immediately after purging, alkalinity will be measured after the completion of all other final purge field parameters. Wells that dewater and require repeated visits for the collection of samples will have alkalinity measured subsequent to the collection of the sample for inorganic water chemistry. Alkalinity will not be measured if sufficient water is not available.
- For micro purged wells, a purge is considered completed when the parameters have stabilized.
- Whenever a method used to remove well water is changed, a set of field parameters shall be recorded from water removed with the new method.

4.8 Groundwater Sampling

Techniques used to withdraw groundwater samples from a well shall be based on consideration of the parameters of interest. The order of collection, collection techniques, choice of sample containers, preservatives, and equipment are all critical to ensuring that samples are not altered or contaminated. The preferred methods for collection of groundwater samples are either bailing and/or the use of bladder pumps.

Sites shall be prepared prior to sampling as described in Subsection 4.4. All necessary and appropriate information will be recorded on the sample collection log and on the Field Activity Daily Log.

4.8.1 Sample Collection

The following discussion involves collection of groundwater samples using bailers and peristaltic or bladder pumps. Regardless of the collection method, care shall be taken not to alter the chemical nature of the sample during the collection activity by agitating the sample or allowing prolonged contact with the atmosphere. To minimize the potential for

altering the sample and to maximize the available water, the following sample collection sequence is preferred.

- Radiation Screening
- VOC
- Nitrate/Nitrite, as N
- Dissolved Metals TAL, with Cs, Li, Sr, Sn, Mo, Si
- ^{239/240} Plutonium, ²⁴¹ Americium
- ^{233/234}U, ²³⁵U, ²³⁸U
- Gross alpha and beta
- ^{89/}Strontium
- ¹³⁷Cesium
- ^{226,228}Radium
- Tritium
- Total Metals TAL, with Cs, Li, Sr, Sn, Mo, Si
- TDS, CL, F, SO^4 , CO3, HCO^3
- TSS
- BNA
- Pesticides/PCB
- Cyanide
- Orthophosphate

VOC samples shall be collected first and as soon as possible after the well has been purged. If a well is purged using a peristaltic pump, then all other samples shall be collected prior to removing the pump from the well. The VOC sample will then be collected using a bailer.

For wells that dewater, if a sufficient volume of water for VOC sample collection has still not accumulated within 48 hours after the completion of purging, VOCs will not be collected for that well. Other samples may be collected using a maximum of five attempts to recover sufficient sample water for analysis. This procedure is discussed in the following paragraph.

The containers used for sample collection from poor producing wells may differ from those used for high yield wells in some instances due to constraints on obtaining enough sample to fill sample containers. In some instances smaller containers may be utilized, or analyte samples normally collected in separate containers may be combined into a single container. Well histories can be used to identify which wells may require a modified sample suite and an extended sampling period. These wells will initially be sampled for a period of 48 hours after the completion of purging, with the exception of VOC sample collection, which is discussed in the previous paragraphs. The completion of purging will be considered 0 hour. At the end of 48 hours, any partial sample will be measured. The accumulated sample will be compared to the minimum volume requirement identified in Table 1 and the allowed sample holding time. If the minimum volume requirement for the target analyte has not been achieved, then sampling may continue as determined from the well recharge

history. All analyte samples that have only minimum sample volumes collected, and all uncollected samples will be documented on the sample collection log.

Table 1

Sample Containers and Preservatives for Groundwater Samples

Parameter	Minimum Container ¹	Preservative	Holding Time
Radiation Screen	120 ml poly	None	NA
VOC - CLP	3 – 40 ml amber glass	Cool to 4° C	4 Days
BNA	1 L amber glass	Cool to 4° C	7 Days
Pesticides/PCB	1 L amber glass	Cool to 4° C	7 Days
TSS	125 ml poly	Cool to 4° C	7 Days
TDS, CI, F, SO4, CO3, HCO3	1 L poly	Cool to 4° C	7 Days
Dissolved Metals - CLP, with Cs, Li, Sr, Sn, Mo, Si	1 L poly	*Filtered, HNO ₃ to pH <2, Cool to 4° C	6 Months
TOC	125 ml poly	H ₂ SO ₄ < pH2, Cool to 4° C	28 Days
COD	125 ml poly	H ₂ SO ₄ < pH2, Cool to 4° C	28 Days
Total Metals - CLP with Cs, Li, Sr, Sn, Mo, Si	1 L poly	Unfiltered, HNO ₃ to pH <2, Cool to 4° C	6 Months
Orthophosphate	250 ml poly	Filtered, Cool to 4° C	2 Days
Nitrate / Nitrite as N	250 ml poly	H ₂ SO ₄ to pH <2, Cool to 4° C	28 Days
Cyanide	1 L poly	NaOH to pH >12, Cool to 4° C	14 Days
Gross Alpha / Beta	550 ml poly	HNO ₃ to pH <2	6 Months
233/2340, 2350, 2380	100 ml poly	Filtered, HNO₃ to pH <2	6 Months
^{239/240} Pu	1 L poly	HNO₃ to pH <2	6 Months
²⁴¹ Am	1 L poly	HNO₃ to pH <2	6 Months
^{89/90} Sr	700 ml poly	Filtered, HNO ₃ to pH <2	6 Months
^{226/228} Ra	750 ml poly	Filtered, HNO ₃ to pH <2	6 Months
¹³⁷ Cs	2.5 L poly	Filtered, HNO ₃ to pH <2	6 Months

¹ The volume listed is the minimum amount required for analysis. Actual sample volumes may be slightly higher and some parameters may be combined in a single container.

* Some samples may not require filtering if taken from a well with a dedicated pump and turbidity of 5 NTU or less.

The order of sample collection may be changed at the discretion of the sampling team. Changes in the order shall be based on the predicted volume of water that will be recovered and the priority stated in the controlling document. The sampling team shall document their sample selections on the sample collection log.

Sample containers shall be stored away from sunlight and cooled to 4°C prior to filling. Immediately after collection, samples requiring cooling shall be cooled to 4°C. A chilled cooler shall be used as the storage container. Whenever a sample bottle that requires chilling is not being physically handled, it will be placed in the cooler to prevent heating or freezing, exposure to sunlight, and possible breakage.

VOC samples shall be collected using a bailer equipped with a bottom-decanting control valve or directly from the pump discharge line on wells equipped with bladder pumps. The procedures for collecting VOC samples are discussed in Subsections 4.8.1.1 and 4.8.1.2 of this procedure.

VOC vials shall never be filled and stored below capacity because of insufficient quantities of water in the well. Except for the VOC vials, adequate air space should be left in the sample bottles to allow for expansion.

Samples shall be placed in the appropriate containers and packed with ice in coolers as soon as practical. VOC samples will be stored in the cooler in an inverted position immediately after collection. When sampling is complete, the well cap shall be replaced and locked.

Sampling tools, instruments, and equipment shall be protected from sources of contamination before use and decontaminated after use as specified in Subsection 4.3. *Liquids from decontamination operations will be handled in accordance with the procedures in Subsection 4.6.3 of this procedure.* Sample containers shall also be protected from sources of contamination. Sampling personnel shall wear chemical-resistant gloves (e.g., nitrile) when handling samples, and the gloves will be disposed of between well sites.

4.8.1.1 Groundwater Sampling Using a Bailer

This subsection describes the use of a bailer for collecting groundwater samples that may be used to obtain physical, chemical, or radiological data.

A bailer attached to a Teflon[®] coated stainless steel cable is carefully lowered into the well. After filling within the well, the bailer is withdrawn by rewinding the bailer line, and the bailer contents are drained into the appropriate containers. Certain recommendations and/or constraints should be observed when using bailers for sampling groundwater monitoring wells, as follows.

- Use only bottom-filling Teflon³⁰ bailers or bailers made of other inert materials.
- Ensure that bailers are attached to a Teflon[®] coated stainless steel line that is pre-wound on a reel.
- Do not use bailers constructed with adhesive joints.
- Lower the bailer slowly to the interval from which the sample is to be collected.

VOC samples shall be collected using a bailer equipped with a bottom-decanting control valve. The first water through the valve assembly will be discarded into the purge water container. Vials will be filled by dispensing water through the control valve along the inside edge of the slightly tilted sample vial. Care shall be taken to eliminate acration of the sample water. The vials will be filled beyond capacity so the resulting meniscus will produce an airtight seal when capped. The capped vial will be checked for trapped air by lightly tapping the vial in an inverted position. If air becomes trapped in the vial, the sample water shall be discarded, and the vial refilled. If two consecutive attempts to fill a VOC vial result in trapped air bubbles, the vial shall be discarded.

The remainder of the sampling water shall be collected in a stainless steel container from which the remaining sample bottles will be filled. Samples requiring filtration shall be filtered and then containerized.

4.8.1.2 Groundwater Sampling Using a Peristaltic Pump

Use of peristaltic pumps shall generally be limited to collecting sample aliquots for radionuclides, metals, and other species that are not subject to volatilization and degassing. Peristaltic pumps shall never be used to collect VOCs or other

volatile species in routine wells, although such samples may be collected for special screening applications. All downhole tubing shall be Teflon[®] except in areas of special concern (e.g., where immiscible layers exist) where special tubing, such as stainless steel or Viton[®], may be required. If so, the project manager will make this determination. Only the portion of tubing that is inserted into the mechanical drive shall be made of silicon. This drive portion of the tubing shall be discarded after each use.

4.8.1.3 Groundwater Sampling Using a Downhole Bladder Pump

Some wells are equipped with dedicated downhole bladder pumps for purging and sampling. These are wells that will normally produce an adequate amount of water during a single visit to complete the required sampling suite. The equipment required to purge and sample a well consists of a pump control unit, a portable air compressor, a continuous sampler for measuring the field parameters, and the necessary sample containers, graduated cylinders, and container(s) to collect the purge and excess water. The following precautions should be observed during the sampling operation.

- Locate the compressor used to power the pump downwind from the well to eliminate the contamination of equipment and samples with exhaust.
- If the flow-through cell will not maintain a full sample chamber (tends to drain back), then clean the check valve on the pump if it is fouled, or replace the pump.
- Calculate the minimum purge volume using the procedure in Section 4.6. Note that a purge is considered completed only when the groundwater parameters have stabilized.
- Upon completion of purging, initiate sampling with the collection of the VOC sample(s). The pump should operate with minimum interruptions while the full sample suite is collected. Allowing the pump to stop for an extended period of time will cause the water trapped in the discharge lines to equilibrate to ambient temperatures, which is not acceptable. During sampling, the pump can be slowed to any rate that allows efficient sampling while also maintaining stable field parameters.
- Measure groundwater parameters periodically during sample collection and record them on the sample collection log to document conditions during sampling.
- Because micropurging is the method used for sampling, adjust the flow rate to limit the drawdown in the well. Also adjust the rate such that the turbidity is below 5 NTU for sampling. If this criterion is met, the samples need not be filtered.
- Operate the pump, pump control unit, and the flow-through cell according to the manufacturer's recommendations.
- 4.8.1.4 Groundwater Sampling Using a Push Type Sampler

This portion of this procedure describes the use of a Geoprobe[®] Screen Point 15 Groundwater Sampler, or similar type equipment, for collecting groundwater samples at predetermined depths. These samples may be used to obtain physical, chemical, or radiological analyses.

A Geoprobe⁴⁰ Screen Point 15 Groundwater Sampler, or equivalent tool, is driven to a predetermined depth by a push type-sampling rig. The Screen Point 15 Groundwater Sampler is equipped with a 41-inch retractable screen and expendable drive point. It can then be partially or fully withdrawn (up to 41 inches) to expose a portion or the entire deployed well screen. After groundwater enters the exposed screen, a sample is collected using either the procedures in Subsection 4.8.1.1, Groundwater Sampling Using a Bailer, or in Section 4.8.1.2, Groundwater Sampling Using a Peristaltic Pump. Note that these samples are collected only for screening purposes because the sampling tool hole has not been completed as a well.

The method for obtaining QC samples using the push type-sampling tool is provided in Subsection 4.8.4.1 for groundwater sampling. Duplicate groundwater samples shall be collected only if there is enough water to collect two full suites of analytes without dewatering the annulus. If insufficient water is available for the collection of a planned QC sample, it shall be explained and documented in the field log book, and the project manager informed. If insufficient water is available for two full suites of analytes, it may be come necessary to prioritize the analyte list. The prioritization sequence should be described in the project-specific work plan.

4.8.2 Sample Filtering and Preservation

Samples for dissolved metals, Gross Alpha/Beta, ^{233/234}Uranium, ²³⁵Uranium, ²³⁸Uranium, ^{89/90}Strontium, ¹³⁷Cesium, ²²⁶Radium, ²²⁸Radium, and orthophosphate shall be filtered in the field at the well location during the sampling event through a disposable 0.45-micrometer membrane filter. If a peristaltic or bladder pump is used, a disposable filter may be attached directly to the sample delivery line so that the sample is filtered directly into the sample container as it exits the delivery line. Discharge pressure shall be gauged so it does not exceed 50 psi. Alternatively, sample water may be collected in a stainless steel container and filtered with a peristaltic pump. Before sample collection, 100 to 200 milliliters of sample water shall be passed through the filter in order to rinse the filter and filtration apparatus of possible contaminating substances.

Preservatives shall be added to the sample bottles prior to the introduction of the filtered sample water. The preservative shall be added in aliquots appropriate to the size of the bottle.

After sample collection has been completed, the pH of preserved samples shall be checked as follows.

- Pour a small amount of sample from the sample bottle directly onto approved pH paper. Use care so that the threaded neck of the bottle does not contact the pH paper. Do not, under any circumstances, insert the pH paper into the sample bottle.
- Check the pH paper against the supplied color chart. If the appropriate pH has not been achieved, add additional preservative to the sample in 5 ml aliquots and repeat the pH test after each addition.

4.8.3 QA/QC Samples

The frequency and types of field QA/QC samples collected during groundwater sampling are described in project-specific work plans or quality assurance plan documents. These documents detail the applicable criteria for collecting QA/QC samples.

4.8.3.1 Duplicates

Duplicate samples shall be collected only from wells that produce enough water to collect two full suites of analytes without dewatering. Wells that produce sufficient water shall be incorporated into the sampling program such that the required duplicate frequency can be maintained.

Wells scheduled for duplicate sample collection shall be sampled as described in Subsection 4.8 of this procedure, and in relevant sections of project-specific work plans and/or quality assurance documents. Field duplicates are collected following the same sampling procedures used to obtain the real samples. With the exception of VOCs, the typical procedure for a location is to collect the real and duplicate of each sample at the same time, in two equal portions, with each portion going to the laboratory in separate containers. This is accomplished by alternately filling two sample bottles one half at a time to minimize heterogeneity. Note that real and duplicate VOC samples shall be collected independently to reduce the possibility of volatilization of the sample.

When a well with a dedicated pump is being used for sample collection, all samples shall be collected in the normal order, with duplicate VOC samples being collected first. The remaining samples will be sampled as described above.

If a well is being used for matrix spike (MS) and matrix spike duplicate (MSD) samples, the duplicate shall be collected after collection of the MS and MSD.

All duplicate samples shall be given a sample number different from the original sample and the information recorded on the sample collection log and/or the field QC sample collection log.

4.8.3.2 Matrix Spike and Matrix Spike Duplicate

MS and MSD samples shall be collected only from wells that produce enough water to collect the required suites of analytes without dewatering. MS and MSD samples are not collected on a routine basis, but will be collected if so designated in a site-specific sampling plans, or if requested by the project manager.

MS and MSD samples shall be collected as follows.

- Purge the well as described in Subsection 4.6 of this procedure..
- After completion of purging, collect VOC samples. Collect the real sample followed by the MS and MSD. Collect these samples in immediate succession.
- Collect the remaining samples not requiring filtering. For each sample parameter, collect the original sample, MS, and MSD concurrently. Fill the original sample bottle one-third full followed by the MS and MSD sample bottles, which are also filled one-third full. Rotate each bottle in the sequence, filling in one-third full until all three bottles are full. For analytes not requiring an MSD, collect only the original sample and the MS.
- After the real sample, MS, and MSD (where appropriate) are collected for one parameter, repeat the process for the next parameter.
- Similarly, collect samples requiring filtering. When a bailer is used, fill a stainless steel bucket with sample water. As samples are collected and the reservoir of water in the bucket is depleted, add more water with discretion. When a pump is used, attach the filter directly to the discharge line. Fill

sample bottles as described above, partially filling the original sample, MS, and MSD in rotating sequence until each parameter bottle is full.

- Radiochemistry samples may have more than one bottle for each parameter group. In this case, include all required bottles in the rotating sequence.
- Field parameter measurements are not be required for MS and MSD samples.
- Retain the original sample number for MS and MSD samples. However, add a suffix of MS or MSD to the sample number to correspond with each QA/QC sample. Record all information on the field QC groundwater sample collection log.
- 4.8.3.3 Replicates and Splits

Replicate and split samples shall be collected in the same manner as described for the MS and MSD. Seek instruction from the project manager for replicates and splits exceeding three samples. Record all information will be recorded on the groundwater sample collection logs.

4.8.3.4 Field Equipment Rinses

Wells scheduled for equipment rinsate samples shall be sampled as described in Subsection 4.8 of this procedure, and field equipment rinses shall be collected as described in this Subsection and in relevant portions of project-specific QC documents and work plans. Field equipment rinses shall be collected in a manner designed to reflect sampling techniques. All equipment used during sampling will be fully decontaminated as described in Subsection 4.3, then rinsed with distilled or deionized water. The rinse water will then be collected in bottles identical to those used for the original sample, and assigned a separate sample number. Analytes requiring filtration will be filtered using a new filter and tubing as required for the real sample. All information will be recorded on groundwater sample collection logs.

4.8.3.4.1 Bailed Wells

After completion of sampling, all equipment shall be decontaminated. Prior to leaving the well location, the equipment rinse will then be collected as follows.

- Fill the bailer with distilled or deionized water by pouring the water into the top opening.
- Decant the rinse water to the VOC vials through the bottom valve just as was done during sample collection.
- For the remaining unfiltered samples, fill the bailer with distilled or deionized water each time additional rinsate is needed. Transfer the rinsate to sample bottles or to a stainless steel bucket and then to sample containers in the same manner used during collection.
- Collect filtered samples in an identical manner as the real samples. Fill the bailer with distilled or deionized water. Then transfer the rinse water to a stainless steel bucket. Filter the rinse water in the bucket through a new disposable filter.

- Preserve rinse samples in the same manner as the real samples.
- 4.8.3.4.2 Pumped Wells

Rinsate samples are not routinely collected from wells that are equipped with dedicated bladder pumps because the samples from these wells are collected directly from the pump discharge line. However, wells sampled using peristaltic pumps for sampling may be selected for rinsate sampling, with equipment used in sample collection (down hole tubing, filter tubing and the stainless steel bucket used for sample water collection, etc.) being decontaminated prior to rinsate sampling. The tubing at the pump head will be replaced, and a new filter used for filtered analytes. To collect the samples, distilled or deionized water will be poured into the decontaminated stainless steel bucket and pumped, using the decontaminated tubing, into the sample containers. The equipment used to collect the real VOC samples will also be decontaminated, rinsed, and used to collect the VOC rinse samples. All samples will be preserved at the same pH levels as the real samples.

4.8.3.5 Distilled Water Blanks

Distilled water sample blanks are not submitted on a routine basis, but will be made up if so designated in a site-specific sampling plan. Samples of the distilled or deionized water used for the final decontamination of equipment will be transferred directly to sample bottles to determine any baseline contamination the water may have introduced into the samples. Five-gallon bottles of the distilled or deionized water will be opened in a controlled area, such as the bottle storage room, and then poured directly into the appropriate sample bottle. A Teflon³⁶, glass, or stainless steel funnel may be used to help control flows into small mouth bottles. Blank samples will be preserved to the appropriate pH required for each analyte. All information will be recorded on groundwater sample collection logs.

4.9 Sample Handling and Control

Pre-cleaned sample containers will be obtained from a contract analytical sample container source. Preserving solution will be added to the bottles by a laboratory, the sample manager or qualified sampling personnel. The bottles will be labeled to indicate the preservative added.

The sampling containers, preservation requirements, and holding times for the various types of analyses are shown in Table 1. Groundwater samples will be properly labeled so that they can be easily identified. The sample numbering system will be assigned by project-specific sampling plan documents. A sample identification (ID) number will be assigned to each sample suite. The sample ID number will contain the following information as part of a nine to twelve character, alpha-numeric code:

Character(s)	Description	Code
1 and 2	Project ID	GW
3 through 7	Sample Number	00001 to 99999
8 and 9	Subcontractor ID	Alpha (e.g. TE = Tierra Environmental Consultants)
10, 11, and 12	QA/QC	MS for matrix spike, MSD for matrix spike duplicate

In addition to a sample number, each well sampled will be assigned a current Record Identification Number (RIN), an event number (specific to the RIN), and bottle numbers that are specific to the RIN and event number.

5.0 Records

All field activities shall be recorded on a Field Activity Daily Log or Groundwater Sample Collection Log. Additional logs may be required to record QC samples and for recording well status. Refer to specific project, site, or facility work plans for further information. Summary information of the day's activities or other pertinent information should always be recorded on the field forms. Under some circumstances, the project manager may assign a bound field logbook to the field personnel that will remain in their custody during all sampling activities. The cover of each logbook shall contain the following information at a minimum:

- Name of the organization to which the book is assigned
- Book number
- Project name
- Start and end dates

Logbook pages shall be sequentially numbered and marked with the book number before any data are recorded. All data and information pertinent to field sampling shall be recorded in the logbook or on the field forms that identify all required data entries. Enough detail must be included in the documentation to reconstruct the sampling event. Field form entries shall include the following minimum information:

- Date and time
- Names of field personnel
- Names of all visitors
- Location of field activities
- Description of sampling sites including weather conditions
- All field observations and comments
- Field parameters
- Sample identification information
- References to all prepared field activity forms and chain-of-custody records

Field logbooks, when required on specific projects, shall normally be kept only by the field sampling team leaders and the site supervisor and shall typically be used only to summarize field activities and to document project information not required by the procedure field forms.

Permanent ink shall be used for all entries in the logbooks and on the field forms. Mistakes shall be crossed out with a single line, initialed, and dated. Unused pages or partial pages shall be voided by drawing a line through the blank sections and initialing and dating the mark. Any deviation from this procedure shall require documentation in the site supervisor's logbook.

The field activity daily log narrative should create a chronological record of the sampling team's activities, including the time and location of each activity. Descriptions of problems encountered, personnel contacted, deviations from the procedure, and visitors on site shall also be included. The weather conditions, date, signature of the person responsible for entries, and the number of field activity daily log sheets used to record media team activities for a given day shall also be included.

The Groundwater Levels Measurement/Calculations Form and the Chain of Custody Record (see *Containing, Preserving, Handling, and Shipping Soil and Water Samples*) shall also be completed for each site. All blank fields on the forms must be completed or voided.

6.0 References

- Environmental Protection Agency, 1982, Test Methods for Evaluating Solid Waste, SW-846, Volume II. Field Methods, 2nd edition.
- Environmental Protection Agency, 1986a, Engineering Support Branch Standard Operating Procedures and Quality Assurance Manual, EPA Region IV Environmental Service Division.
- Environmental Protection Agency, September 1986b, RCRA Ground Water Monitoring Technical Enforcement Guidance Document, OSWER-9950.1.
- Environmental Protection Agency, 1987a, A Compendium of Superfund Field Operations Methods, EPA/540/P-87/001. 1987.
- Environmental Protection Agency, 1987b, Data Quality Objectives for Remedial Activities, Development Process, EPA/540/G-87/003.
- Environmental Protection Agency, December 1988, User's Guide to the Contract Laboratory Program.

APPENDIX A

STANDARD GROUNDWATER FORMS

Appendix B Sample Collection Forms

105 Technology Dr., Suite 190 Broomfield, CO 80021 (303) 546-4300

									
Project Nam	1e:	, ,			Sample Loc	ation:			
	Cobr	do Sch	∞/of.	Mines		CSMRI	-1		í
Project Num	iber:		•		Date:				1
		107-5-10				3/17 / Malezyk	09		
Sample Typ	e:	Ì	SW	EB	Sampler:				1
		Duplicate	Other:		N	Malazak			
							•		-
Purge Vo	lume Calcu	Ilations		Sample C	ollection	······································			7
Measured TI	D =	2	4.93 (tt) Analysis	Container	Preservative	Date	Time	1
			(+.28)	R-226 R-228	Igal				1
Total Depth	=		5-21 (ft	Diss. U	inte	HNO3	3/17/09	1445	
Depth to Wa	ter =		(ft	Nor/	16				
		8.	28	NOZ	Plastiz	-	3/17/09	1445	T
Initial Water	Column =		(ft)	Cetterns	SOOML				1
		16	.93	Carry K, No	Plaste	HNO3	3/17/09	1445	
Initial Water	Volume =	2	(gal)	Anions	SOOML	1			1
		-	•• -	rin ions	Plastic	-	3/17/09	1445	
3 X Water Vo	olume	5	?./ð (gal)	Lab: Por	m Fort (al	Uns Test	America -	And	1
				•		<u></u>	//		1
Purge Vol	umes and	Field Water	Quality M	easuremen	ts	··· · ·			1
Time	Volume	Temperature	pН	Conductivity	DO	ORP	Turbidity	Appearance	1
	(gal)	CD	(SU)	(uS/cm)	(mg/L)	(m∨)	(NTU)		
1419	1.35	8.55	8179	408	12.28	149	222	brown	
1422	2.70	7.25	8,28	429	10,29	16Z	315	1	
1424	4.05	6.95	7.84	445	9,10	175	317		
1426	5.40	7,32	7.66	504	8,03	177	375		
1428	4.75	6.81	7.68	427	8,98	174	425		
1431	10	7.09	7.55	473	7.96	177	449	4	
			10						
								sam	
/olume purge	ed:								-

8.1 001 Analysis Container Preservative Dete Time Comments: Diss. Phosphorus 250ml plastic H- SOY 3/17/09 1445 125ml Amber TOC Ho SOU 3/ 17/09 1445 500ml Plastre TA Ferric Fe HNO, 3/17/09 1445 TA Ferrows Fe 16 Plastiz 3/17/09 1445

105 Technology Dr., Suite 190 Broomfield, CO 80021 (303) 546-4300

Project Nan					Sample Loc	ation:		
	Cobr	do Sch	oo/ of	Mines	Cs	MRI-11	3	
roject Nun					Date:	,	1	, ,
		107-510				3/16 / Malezyk	109, 3/1-	7/07, 3/18/
ample Typ	be:	GW	SW	EB	Sampler:		,	. , ,
		Duplicate	Other:		N	Malezyk		
Purge Vo	olume Calcu	ilations		Sample (Collection	······································		·
leasured T	······		3,40	(ft) Analysis	Container	Preservative	Date	Time
			(+.28)	Re-226	1 gal		1 1	
otal Depth	=	2		(ft) Dise. U	inte	HNO3	2/18/09	1230
epth to Wa	ater =			(ft) Nor /	14		_/ /	
		20		107	Plashe		3/ 109	
itial Water	Column =		~~~	(ft) Cetterns	500mL			
		X.	37	Ca. My. K. A	1 Plastic	HNO3	3/ /09	
itial Water	Volume =	0,	38 (g	al) An iung	Sooml			
				rin 10413	Plactic		\$ 109	
X Water V	olume	1.1	14 (g	al) Lab: Rom	in Fort (of	Ilms Test	America -	Arrida
urge Vo	lumes and	Field Water	Quality	Measuremei	nts			
urge Vo Time	Volume (gal)	Field Water Temperature	рH	Conductivity (uS/cm)	(DO (ma/L)	ORP (mV)	Turbidity (NTU)	Appearance
Time	Volume	Temperature	рН	Conductivity (uS/cm)	(DO (ma/L)		3	Appearance
Time	Volume (gal)	Temperature	pH en (SU)	Conductivity	(DO (ma/L)	(mV)	(NTU)	
Time	Volume (gal) 0,3%	Temperature	pH en (SU)	Conductivity (uS/cm)	(DO (ma/L)	(mV)	(NTU)	
	Volume (gal) 0,38 0,76	Temperature	pH en (SU)	Conductivity (uS/cm)	(DO (ma/L)	(mV)	(NTU)	
Time	Volume (gal) 0,38 0,76	Temperature	pH en (SU)	Conductivity (uS/cm)	(DO (ma/L)	(mV)	(NTU)	
Time	Volume (gal) 0,38 0,76	Temperature	pH en (SU)	Conductivity (uS/cm)	(DO (ma/L)	(mV)	(NTU)	
Time	Volume (gal) 0,38 0,76	Temperature	pH en (SU)	Conductivity (uS/cm)	(DO (ma/L)	(mV)	(NTU)	
Time	Volume (gal) 0,38 0,76	Temperature	pH en (SU)	Conductivity (uS/cm)	(DO (ma/L)	(mV)	(NTU)	
Time	Volume (gal) 0,38 0,76	Temperature	pH en (SU)	Conductivity (uS/cm)	(DO (ma/L)	(mV)	(NTU)	brown
Time	Volume (gal) 0,38 0,76 7,74	Temperature	pH en (SU)	Conductivity (uS/cm)	(DO (ma/L)	(mV)	(NTU)	
Time	Volume (gal) 0,38 0,76 7,74 7,74 ed: 0,53	Temperature ©©7 52+8	pH en (SU)	Conductivity (uS/cm)	(DO (ma/L)	(mV)	(NTU)	brown
Time	Volume (gal) 0.38 0176 174 174 ed: 0.55 An_lyst3	Temperature ©© 54:6	pH en (SU)	Conductivity (uS/cm)	(DO (ma/L)	(mV) -2-7	(NTU) 681	brown
Time	Volume (gal) 0,38 0,76 7,74 7,74 ed: 0,53	Temperature ©© 54:6	pH (SU) 7.5-1	Conductivity (uS/cm)	(DO (mg/L) c 6.36	(mV) -2-7	(NTU) 681	boon
Time	Volume (gal) 0,38 0,76 7,74 7,74 6 6 6 6 7,74 7,74 6 7,74 7,74	Temperature ©© 54:6	Conta	Conductivity (uS/cm)	Preserva	(mV) -2-7	(NTU) 681	boon
Time	Volume (gal) 0,38 0,76 7,74 7,74 1,74 1,74 1,74 1,74 1,75 1,75 2,55 An-lyst 3: Diss. Pho	Temperature ©© 54:6	Conta 250m	Conductivity (uS/cm)	Preserve Hz Sey	(mV) -2-7	(NTU) 681 	boon

There was insufficient water to collect all of the samples

105 Technology Dr., Suite 190 Broomfield, CO 80021 (303) 546-4300

Project Nar		ndo sch		Miner	Sample Loca			
Project Nur	nber:	reio -ch	00/07	- (IAES	Date:	SMRJ-	<u> </u>	
•		107-510			Date.	alar	109,3/1	ala
Sample Typ	pe:	107-510 GVD	SW	EB	Sampler:	3/16/	104, 311	8/07
		Duplicate	Other:		11	Malczyk	-	
						2 aleryn	·	
Purge Vo	olume Calci	ulations		Sample C	ollection			
Measured T	fD =		<i>5.10</i> (ft		Container	Preservative	Date	Time
			(+.28)	L-226 L-228	1 gal		· · · · · · · · · · · · · · · · · · ·	
Fotal Depth	otal Depth = 95,38 (ft				inte	HNO3	2/18/09	1300
Depth to Wa	$\begin{array}{cccccccccccccccccccccccccccccccccccc$				16		1 .	1
	pur to vvater = 68,46 (ft				Plastic		3/18/09	1300
nitial Water	Column =	~	(ft)	NO3 Cetterns	SOOML			
			. 98	GM KN.		HNO3	3/18/09	1300
nitial Water	Volume =	4.	32 (gal)	Antons	Sooml		alment	
				rinions	Plastic	-	3/18/09	1300
X Water V	/olume	12	. 96 (gal)	Lab: Proge		In: Test		
-urae Vo	lumes and	Field Water	· Quality M	asuromon	to			
Time	Volume (gal)	Field Water	рH	Conductivity (uS/cm)	ts DO (mg/L)	ORP (mV)	Turbidity (NTU)	Appearance
Time /342	Volume (gal) 2.//6	Temperature	pH (SU) 7:82	Conductivity	DO			Appearance
Time /342 /351	Volume (gal) 2./6 4/.32_	Temperature 74,87 14,60	pH (SU) 7.82 7.91	Conductivity (uS/cm)	DO (mg/L) Z.16 2.21	(mV) 122 120	(NTU)	
Time /342 /351 /357	Volume (gal) 2.16 4.32 6.48	Temperature CCR 14.87 14.00 13,54	pH (SU) 7.82 7.91 7.77	Conductivity (uS/cm) 4/2	DO (mg/L) Z.16	(mV) /ZZ	(NTU) 238	
Time /342 /351	Volume (gal) 2.16 4.32 6.48 8.64	Temperature 74,87 14,60	pH (SU) 7.82 7.91	Conductivity (uS/cm) 4/2 374	DO (mg/L) Z.16 2.21	(mV) 122 120	(NTU) 238 1000+	
Time /342 /351 /357	Volume (gal) 2.16 4.32 6.48 8.64 -16.80	Temperature CCR 14.87 14.00 13,54	pH (SU) 7.82 7.91 7.77	Conductivity (uS/cm) 4/12 374 399	DO (mg/L) 2,16 2,21 7.53	(mV) 122 120 135 ⁻¹³⁴	(NTU) 238 1000+ 1000+	6000
Time /342 /351 /357	Volume (gal) 2.16 4.32 6.48 8.64	Temperature CCR 14.87 14.00 13,54	pH (SU) 7.82 7.91 7.77	Conductivity (uS/cm) 4/12 374 399	DO (mg/L) Z.16 2.21 7.53	(mV) 122 120 135 ⁻¹³⁴	(NTU) 238 1000+ 1000+	6000
Time /342 /351 /357	Volume (gal) 2.16 4.32 6.48 8.64 -16.80	Temperature CCR 14.87 14.00 13,54	pH (SU) 7.82 7.91 7.77	Conductivity (uS/cm) 4/12 374 399	DO (mg/L) Z.16 2.21 7.53	(mV) 122 120 135 ⁻¹³⁴	(NTU) 238 1000+ 1000+	6000
Time /342 /351 /357	Volume (gal) 2.16 4.32 6.48 8.64 -16.80	Temperature CCR 14.87 14.00 13,54	pH (SU) 7.82 7.91 7.77	Conductivity (uS/cm) 4/12 374 399	DO (mg/L) Z.16 2.21 7.53	(mV) 122 120 135 ⁻¹³⁴	(NTU) 238 1000+ 1000+	6000
Time /342 /351 /357	Volume (gal) 2.16 4.32 6.48 8.64 -16.80	Temperature CCR 14.87 14.00 13,54	pH (SU) 7.82 7.91 7.77	Conductivity (uS/cm) 4/12 374 399	DO (mg/L) Z.16 2.21 7.53	(mV) 122 120 135 ⁻¹³⁴	(NTU) 238 1000+ 1000+	6100
Time /342 /351 /357 /406	Volume (gal) 2.16 4.32 6.48 8.64 10.80 12.96	Temperature CCR 14.87 14.00 13,54	pH (SU) 7.82 7.91 7.77	Conductivity (uS/cm) 4/12 374 399	DO (mg/L) Z.16 2.21 7.53	(mV) 122 120 135 ⁻¹³⁴	(NTU) 238 1000+ 1000+	6000
Time /342 /35 / /35 7 /406	Volume (gal) 2.16 4.32 6.45 8.64 12.96 12.96	Temperature (14,87 14,60 13,34 13,84 13,84	pH (SU) 7.82 7.91 7.77	Conductivity (uS/cm) 4/12 374 399	DO (mg/L) Z.16 2.21 7.53	(mV) 122 120 135 ⁻¹³⁴	(NTU) 238 1000+ 1000+	6100
Time /342 /35 / /35 7 /406 olume purg	Volume (gal) 2.16 4.32 6.48 8.64 12.96 12.96 ed: 6.6 7.6 8.6	Temperature (28) 14.87 14.00 17:39 13.84 13.84 4 gcl	pH (SU) 7.82 7.91 7.77	Conductivity (uS/cm) 4/12- 374 399 403	DO (mg/L) Z.16 2.21 7.53	(mV) 122. 120 135 ⁻¹ 34 131	(NTU) Z 38 1000+ 1000+ 1000+ 1000+	6100
Time /342 /351 /357 /406 olume purg	Volume (gal) 2.16 4.32 6.48 8.64 12.96 12.96 ed: 6.6 7.6 8.6	Temperature (28) 14.87 14.00 17:39 13.84 13.84 4 gcl	pH (SU) 7.82 7.91 7.78 7.78	Conductivity (uS/cm) 4/12 374 399 4/03	DO (mg/L) 2.116 2.21 7.53 2.51 Preserve	(mV) 122. 120 135-134 131	(NTU) Z38 1000+ 1000+ 1000+ 1000+	Time
Time /342 /351 /357 /406 folume purg	Volume (gal) 2.16 4.32 6.48 8.64 12.96 12.96 ed: 8.6	Temperature (28) 14.87 14.00 17:39 13.84 13.84 4 gcl	pH (SU) 7.82 7.91 7.77 7.78 7.78 Contain 250mL	Conductivity (uS/cm) 4/12 374 399 403	DO (mg/L) 2.116 2.21 7.53 2.51 Preserve Hz SOy	(mV) 122 120 135-134 131 131 tre Details	(NTU) 238 1000+ 100+	Time 1300
Time /342 /351 /357 /406 folume purg	Volume (gal) 2.16 4.32 6.48 8.64 12.96 12.96 12.96 ed: 8.6 An-lyst 5. Diss. Pho TOC	Temperature (28) 14.87 14.00 17:39 13.84 13.84 4 gcl	pH (SU) 7.82 7.91 7.78 7.78	Conductivity (uS/cm) 4/12 374 399 403	DO (mg/L) 2.116 2.21 7.53 2.51 Preserve	(mV) 122 120 135-134 131 131 tre Details	(NTU) Z38 1000+ 1000+ 1000+ 1000+	Time

Well most day at 8.64 gallons

2

Project Name:	brado sch	lool of	Mines	Sample Location: CSMRJ - 4	
Project Number:	4107-510	·		Date: 2/17/09	
Sample Type:	GW Duplicate	SW Other:	EB	Sampler: NMalazyk	

Purge Volume Calcula	tions		Sample C	ollection				
Measured TD =	17.29	(ft)	Analysis	Container	Preservative	Date	Time]
Total Depth =	(+.28) 17.57		Ju-226 Re-228 Diss. U	I gal cube	HNO;	3/17/09	1115	
Depth to Water =	7.36		NO2/ NO2	1 L Plastic		3/17/09	1115	τ
Initial Water Column =	10.21		Cetters Ca. My. K. No	500mL Plastic	HNO3	3/17 /09	1115	
Initial Water Volume =	1.64	(aab)		500ml Plastic	-	3/17/09	1115]
3 X Water Volume	4.92	(gal)	Lab: Para	n Fort (o)	Uns Test	America -	Arrida]

Purge Vo	lumes and l	Field Water	Quality M	easurement	's			
Time	Volume	Temperature		Conductivity	DO	ORP	Turbidity	Appearance
	(gal)	CO	rm(SU)	(uS/cm)	(mg/L)	(mV)	(NTU)	
1103	1.64	7,54	7,66	1380	6.00	156	222	born
1106	3.28	7.52	7.57	892	3.65	158	101	1
1110	4.92	7.53	7.08	881	3,29	160	105	6
					_			
								Name
Volume purg	ed:	,	,					
	5 gal Analysis	llons						
	Analysis	-	Contai	ner	Preserva	five Del	re.	Time
Comments	Diss. Pho:	shorus	250ml	Plastic	H2 SQy	3/17	109	1115
	TOC	1	125ml	Amber	H2 SOU	דו /נ	109	1115
TA	Ferric F	ř.	500ml i		H2 504 HNO,	217	109	1115
TA	Ferrows F	ż	16 Plas			5/17	109	1115

105 Technology Dr., Suite 190 Broomfield, CO 80021 (303) 546-4300

Project Nam		do Sch.	10		Sample Loca			~]
Project Nurr		do -ch	oo/ ot /	Vines	Date:		IRJ-S		1
	41	107-510				3/17	09		
Sample Typ		GWD	SW	EB	Sampler:				1
		Duplicate	Other:		N	Malezyk			
Purae Va	lume Calcu	ilations		Sample C	ollection				1
Measured T			1 and (ft)		Container	Preservative	Date	Time	1
	0 -	10.98-	(+.28) (ft)	4-226 Re-228	1 gal				1
Total Depth	=	1426 4	4 7.25 (ft)	Re-228 Dise. U	ente	HNO3	2/17/09	1215	
Depth to Wa	nter =			No2/ NO2	1 L Plastic	-	3/17/09	1215	TA
Initial Water	Column =	4		Cations	500mL Plastre	H.NO3	3/17/09	1215	
Initial Water	Volume =	0,0	68 (gal)	Ca, Mg, K, No An runs	500ml Plastic	1	3/17/09	1215	
3 X Water V	olume	2.0	' (gal)	Lab: Parace	n Fert (o)	llong Test	America -	Arnala	
				-	.=				-
Purge Vo	lumes and	Field Water	Quality Me	easuremen	ts			.	
Time	Volume	Temperature	pH	Conductivity	DO	ORP	Turbidity	Appearance	
	(gal)	OD1		(uS/cm)	(mg/L)	(mV)	<u>(NTU)</u>	 }	
1200	0.68	4.16	7.85	B72	9.58	168		brown	1
1202	1,36	7,76	7,74	835	7.73	169	959	- <u></u>	
1205	2.04	72.68	7,41	1170	6.59	150	650	\$	
							· · ·		
								NEM	
Volume purg	led: Ze	04 gellons		<u> </u>		l			
	Analysi	3	Contair		Preserv		L	Time	
Comments	S: Diss. Pho	sphorus	250ml	plastic	H- 500	, 3/17		1215	
	TOC	•	125ml 1	Amber	H2 504	3/17		1215	
TA	Ferric H	-1	500mL F		HNOZ	3/17		1215	
TA	Ferrous 1	Fe	16 Plasi	hz		<u></u>	109	1215	

Droiget Mary	·····							
Project Nam		do sch	10	Min	Sample Loca		<i>c c</i>	
Project Num		old sch	00/07.	relines	Date:	CSMRI	-66	
i i oj o ci nutili		107-510			Date.	alir	100	
Sample Typ	e:	GW)	SW	EB	Sampler:	2/16 / Malazyk	07	
		Duplicate	Other:		1	Malarik	-	
Purge Vo	lume Calcu	lations		Sample C	ollection			
Measured TI	D =		9.94 (ft	t) Analysis	Container	Preservative	Date	Time
		\backslash	(+.28)	R-226	Igal	11.000	1_1	-
				Dise. U	infe	HNO;	2/-109	
Depth to Wa	iter =		(ft)vor/	16		2/-1	
·······			DRY "	NO3 Cetterns	Plastic	_	3/-/09	
Initial Water	Column =		(ft		SOOML	HNO3	3/ - 109	-
		·	<u> </u>	Car My K, No	Plastic		-1-109	
Initial Water	Volume =		(gai	Anions	SDOML		3/-109	
		No.	m `		Plastic			
0 V/ M/ / V/	,							H I
3 X Water Vo	olume		(gal) Lab: Para	n Fort lol	Ins lest	America -	minda
						Ins lest	America -	Arrida
Purge Vol	lumes and	Field Water	Quality M	leasuremen	ts			
	<i>lumes and</i> Volume	<i>Field Water</i> Temperature	Quality M pH	easuremen Conductivity	ts DO	ORP	Turbidíty	Appearance
Purge Vol	lumes and	Field Water	Quality M	leasuremen	ts			
Purge Vol	<i>lumes and</i> Volume	<i>Field Water</i> Temperature	Quality M pH	easuremen Conductivity	ts DO	ORP	Turbidíty	
Purge Vol	<i>lumes and</i> Volume	<i>Field Water</i> Temperature	Quality M pH	easuremen Conductivity	ts DO	ORP	Turbidíty	
Purge Vol	<i>lumes and</i> Volume	<i>Field Water</i> Temperature	Quality M pH	easuremen Conductivity	ts DO	ORP	Turbidíty	
Purge Vol	<i>lumes and</i> Volume	<i>Field Water</i> Temperature	Quality M pH	easuremen Conductivity	ts DO	ORP	Turbidíty	
Purge Vol	<i>lumes and</i> Volume	<i>Field Water</i> Temperature	Quality M pH	easuremen Conductivity	ts DO	ORP	Turbidíty	
Purge Vol	<i>lumes and</i> Volume	<i>Field Water</i> Temperature	Quality M pH	easuremen Conductivity	ts DO	ORP	Turbidíty	
Purge Vol	<i>lumes and</i> Volume	<i>Field Water</i> Temperature	Quality M pH	easuremen Conductivity	ts DO	ORP	Turbidíty	
	<i>lumes and</i> Volume	<i>Field Water</i> Temperature	Quality M pH	easuremen Conductivity	ts DO	ORP	Turbidíty	
Purge Vol	<i>lumes and</i> Volume	<i>Field Water</i> Temperature	Quality M pH	easuremen Conductivity	ts DO	ORP	Turbidíty	
Purge Vol	Iumes and Volume (gal)	Field Water	Quality M pH	easuremen Conductivity	ts DO	ORP	Turbidíty	
Purge Vol	Iumes and Volume (gal)	Field Water	Quality M pH	easuremen Conductivity	ts DO	ORP	Turbidíty	
Purge Vol	lumes and Volume (gal)	Field Water	Quality M pH	easuremen Conductivity (uS/cm)	ts DO	ORP (mV)	Turbidity (NTU)	
Purge Vol Time	ed:	Field Water	Quality M pH (SU)	Conductivity (uS/cm)	ts DO (mg/L)	ORP (mV)	Turbidity (NTU)	Appearance
Volume purge	ed:	Field Water Temperature (°C, ©)	Quality M pH (SU)	Conductivity (uS/cm)	ts DO (mg/L)	ORP (mV)	Turbidity (NTU)	Appearance
Volume purge	ed:	Field Water Temperature (°C, C)	Quality M pH (SU)	Conductivity (uS/cm)	ts DO (mg/L)	ORP (mV)	Turbidity (NTU)	Appearance

105 Technology Dr., Suite 190 Broomfield, CO 80021 (303) 546-4300

Project Name:				Sample Location:	
Ce	brado Sch	ool of	Mines	CEMPI-7B	
Project Number:				Date:	
-	4107-510			3/16/09	
Sample Type:	(GW)	SW	EB	Sampler:	
	Duplicate	Other:		N Malout	

Purge Volume Calculations	:		Sample Co	ollection			
Measured TD =	16.82	(ft)		Container	Preservative	Date	Time
Total Depth =	(+.28) 17.10		LZZ6 Re-ZZ8 Diss. U	I gal Cube	HNO3	31-109	<u> </u>
Depth to Water =	DRY		Nor/ Nor/	1 L Plastic	-	3/-109	-
Initial Water Column =			Cetterns Carly K, No	500mL Plastri	HN03	3/-109	<u> </u>
Initial Water Volume =		(cal)	Antons	500ml Plastic	-	3/709	
3 X Water Volume		(gal)	Lab: Proc	n-Fort Co	Uns Test.	America -	Arrida

Purge Vol	umes and	Field Water	Quality N	leasurement	s			
Time	Volume	Temperature	pН	Conductivity	DO	ORP	Turbidity	Appearance
	(gal)	(°C, 🕑	(SU)	(uS/cm)	(mg/L)	(mV)	(NTU)	
		\sim						
								ļ
				\downarrow				
								
								. .
				++				
				1				va
olume purge	ed: ~/.	4		•	<u></u>			
	Analysis	r	Contai	ner	Preserve	five De	Fe .	Time
Comments	Diss. Pho	sphorus	250mL	Dlastic	Ha SOU	3/-	-109	
	TOC Ferric F	-	125mL	Amber	H2 SOY H2 SOY HNO,		-109	_
A	Ferric F	z	500mL	Plactic	HNO	3/-	109	

109

16 Plastiz

TA

Ferrows Fe

105 Technology Dr., Suite 190 Broomfield, CO 80021 (303) 546-4300

Ptoject Name:	brado sci	lool of	Mines	Sample Location: CSMRI-8
Project Number:	4107-570	•		Date: 3/17 /09, 3/18/07
Sample Type:	GD Duplicate	SW Other:	EB	Sampler: NMalezyk

Purge Volume Calculations			Sample C	ollection				٦
Measured TD =	17,06	(ft)		Container	Preservative	Date	Time	1
Total Depth =	(+.28) 17.34	(ft)	р226 Re-228 Diss. И	I gal cube	HNO3	2/18/09	1200	
Depth to Water =	8.80		Noz/ Noz/	1 L Plastiz	-	3/18/09	1200	Τ
Initial Water Column =	8.54		Cattons Ca, Mg, K, No	500mL	HNO3	3/18/09	1200	
Initial Water Volume =		(gal)	Anions	500ml Plastic		3/18/09	1200	1
3 X Water Volume	4.08	(gal)	Lab: Parace	n Fort (of	Ins Test	America -	Anda	1

Time	Volume	Temperature	рH	Conductivity	DO	ORP	Turbidity	Appearance
	(gal)	CO	(SU)	(uS/cm)	(mg/L)	(mV)	(NTU)	Appearance
1028	1.36	7.69	6,99	2036	6,55	204	1000+	brown
1030	2.72	7.76	7.42	2320	6,71	194	1000+	L
	4.08							
<u> </u>			_					1
						/		1
<u></u>								wit
/olume purge	ed: 3.0	gel		X				
	Analysis		Contai	ner	Preserva	chive De	fe.	Time
Comments	Diss Pho	sphorus	250mL	plastic	1+, SOU	3/12	3 109	1200
	TOC	<u> </u>	125ml	Amber	H2 SOU		101	17.00
A	Ferric F Ferrous F	r.	500mL i	Planster	HNO	3/ 18	2/09	1200
-A								

105 Technology Dr., Suite 190 Broomfield, CO 80021 (303) 546-4300

Project Name:			-	Sample Location:
<u> </u>	brado Sch	ool of	Mines	ESMRIT-10-9
Project Number:				Date:
	4107-510			3/16/09
Sample Type:	GW	SW	EB	Sampler:
	Duplicate	Other:		N Maleryk

Purge Volume Calculat	ions	Sample C	ollection				
Measured TD =	33.01 (1	t) Analysis	Container	Preservative	Date	Time	
Total Depth =	(+.28) 33,29 (1	l-226 Re-228 1) Diss. И	I gal cube	HNO3	2/16/09	1540	
Depth to Water =		t) vor / vor	1 L Plastic	-	3/16/09	1540	7
Initial Water Column =	5.57 ^{(f}	t) Cettons Ca, Mg, K, No	SOOML	HNO3	3/16/09	1540	
Initial Water Volume =	0,90 (ga		SOOML Plastic		3/16/09	1540	
3 X Water Volume	2.70 (ga	I) Lab: Prog	· · · · · · · · · · · · · · · · · · ·	lone Test	America -	Aniala	

Time	Volume	Temperature	Ha	Conductivity	DO	ORP	Turbidity	Appearance
	(gal)	ROCEDA		(uS/cm)	(mg/L)	(mV)	(NTU)	rippedianee
1104	0,90	12.72	7,79	750	4.23	73	582	brown
1109	1.80	13.15	7.54	732	4,13	84	10000 +	1
1114	2.70	13.27	7.50	725	433	97	~~~~+	+
			_ .			·		
·								
			···· ···					
					· · ·			
/olume purg	ed: 2.7	70 gel		1 1				J
	An-lysi)		Contai	ner	Preservi Hz SQy	ctive De	te	Time
Commente	Diss. Pho.	sphorus	250mL	plastic	1+- 500	3/1	6/09	1540
	TOC.		125ml	Amber	H2 504	3/10	-109	1540
FA	Ferric F	2	500ml i	Jucke	-Horso		109 1	r.M.

Ferrow Fe

16

Plastic

T-A

109

Nen

105 Technology Dr., Suite 190 Broomfield, CO 80021 (303) 546-4300

Project Name:	1 1	, ,		Sample Location:	
<u>C</u> e	brado Sch	00/07	2 Mines	CSMRI-	10
Project Number:				Date:	
	4107-510			3/16	109
Sample Type:	(The second seco	SW	EB	Sampler:	
	Duplicate	Other:		N Malezyk	

Purge Volume Calcula	tions		Sample C	ollection				٦
Measured TD =	27.26	(ft)	· · · ·	Container	Preservative	Date	Time	
Total Depth =	(+.28) 27.54		La-226 Re-228 Diss. U	I gal cube	HNO3	2/26/09	1600	
Depth to Water =	2477		Nor/ Nor/	1 L Plastic		3/16/09	1600	
Initial Water Column ≃	2.77		Cettoms Ca, My, K, No	SOOML	HNO3	3/16/09	1600	
Initial Water Volume ≃	,44	(dal)		500mL Plastic		3/16/09	1600	1
3 X Water Volume	1.32	(gal)	Lab: Prog		Ins Test,	America -	Arreda	1

Time	Volume	Temperature	pН	Conductivity	DO	ORP	Turbidity	Appearance
	(gal)	OD	rm(SU)	(uS/cm)	(mg/L)	(mV)	(NTU)	
1136	0.44	12.22	7.77	680	6,22	106	1000+	brown
1138	0.88	11.89	7.70	697	6.36	112	1000 ×	1
1141	4.32	14.89	7.64	692	5779	104	1000+	*
								L
				· · · · ·				
	ļ					ļ		
<u></u>							_	
								ļ
	+							
<u> </u>	L					<u>_</u>	<u> </u>	win
/olume purg	An-lysiz	2 gal						
	An-lysi3		Contai	ner	Preserv	ctive De	ite	Time
comments	Diss. Pho.	sphorus	250mL	plastic	H- 50,		6/09	1600
	TOC		125ml	Amber	H3 500		4	1600
7	FERRIC F	÷	SOOME	Harte	11-10-		109-V2	

tog ven

3/

16 Plastiz

TA Forman Fe

Project Nar					Sample Loca			
		do Sch	<u>~/ of /</u>	Mines		CSME	<u>I-11B</u>	
Project Nur					Date:	,	1	i
		107-510				2/16 / Malazyk	109	
Sample Typ	be:	T	SW	EB	Sampler:		,	
		Duplicate	Other:		N	Malezyk	<u> </u>	
Dure 1/	luma Cala	-1-4:						
	olume Calcu	1		Sample C				
Measured T	D =	2	0	Analysis	Container	Preservative	Date	Time
Total Depth	_	-	(+.28)	4-226 A-228	1 gal	HNO3	3/-109	
Depth to Wa				Dise. U	inter 16			
·		De	<u>v</u> ""	Noz / NOz Cations	Plastic		3/-/09	<u> </u>
Initial Water	Column =		(ft)		SOOML	HNO3	3/ -109	
				Ca, Mg, K, N.	Plastic	#**** <u>3</u>	1 109	
Initial Water	· Volume =		(gal)	Antons	500ml Plastic	-	3/-109	-
3 X Water V	/olume		(gal)	Lab: Para	n Fort (of	Ims Test.	America -	Horada
				V				
Purge Vo	olumes and	Field Water	Quality Me	easuremen	ts			
Time	Volume	Temperature	pН	Conductivity	DO	ORP	Turbidity	Appearance
	(gal)	(°C,Œ	(SU)	(uS/cm)	(mg/L)	(m∨)	(NTU)	
		4 1						
· ·=_ ·		<u> </u>						
								· · · ·
·								
/olume purg	jed: N/H	11 J-	<u>.</u> 1					vin
	Analysis	2	Contair		Preservi		L	TIME
Comment	s: Diss. Pho	sphorus	250ml i	Dlastic	H2 SOY		109	\frown
	100		1Bml F	tmber	H2 504		101	
And the second s		-		v /		· · · _	,	
<u>τ</u> Α	Ferric F Ferrous F		500mL F IL Plast		HNOZ	¥	109	

									_
Project Na			1 0		Sample Loca]
		do Sch	ool of .	Mines		561-1			
Project Nul	mber:				Date:	ý			
	4	07-510				3/16	09		
Sample Ty	pe:	GW	(RW)	EB	Sampler:				
		Duplicate	Other:	,	N	3/16 / Malezyk	····		1
			<u> </u>						-
Purge V	olume Calcu	lations		Sample C	ollection				
Measured 7	TD =	k	(ft		Container	Preservative	Date	Time	
			(+.28)	4-226 Re-228	1gal	4000	-lel		
Total Depth	1 =		(ft)	Dise. U	inte	HNO3	3/16/09	1515	
Depth to W	ater =		(ft)	No2/	16		alut		TI
				NO3 Cetterns	Plastic		3/16/09		<u> ''</u>
Initial Wate	r Column =		(ft)	Cetterns	SOOML	11.4.00	alic la		
			Nam	Ca, My, K, No	Plastic	HNO3	3/16 /09	1515	
Initial Wate	r Volume =		(gal)	Anions	SOOML		alich		
			•	I	Plactic		3/16 /09 3/16 /09	1515	
3 X Water \	/olume		(gal)	Lab: Para	n Fert lol	los Test	America -	- Arrida	
				v		,			•
Purge Vo	olumes and	Field Water	Quality M	easuremen	ts		······································		ł
Time	Volume	Temperature	pН	Conductivity	DO	ORP	Turbidity	Appearance	
	(gal)	OB1	en (SU)	(uS/cm)	(mg/L)	(mV)	(NTU)		
1446	1/4	7.94	9.41	252	9.68	-+++-115	86.2	cloudy	
							· · · · ·		
			······································					Sea	
Volume pur	ged:	·		<u>د </u>		,			
	NI	9							
	Analysia	3	Contair	115	Preserve	ctive Det	e	Time	. •
Comment	S. Diss. Pho	shows					109	1515	
	TOC	epicary and	125ml 1	Amber	H2 SOU	3/16		1575	
17	Ferric +		500ml i	7. 1. 1.	-H-12 304		109 ma		
т.А	-Fernand		16 Plas	La			tog ma	. <u> </u>	
			·	16-		4	1 mm		

Project N:		1 0	110	14.	Sample Loca			
Project Ni		do sch	00/01.	Mines	Date:	54-2		
		107-510			Date:	alu	1	
Sample T		GW	(SW)	EB	Sampler:	3/16 / Malazyk	09	
1	21	Duplicate	Other:	20		M/_ 6	-	
		<u> </u>				2 GIELYN		
Purge V	/olume Calci	ulations		Sample C	ollection			
Measured	TD =		(ft) Analysis	Container	Preservative	Date	Time
			(+.28)	A-226 Re-228	1gal			
otal Dept	th =		(ft	Diss. U	inte	HNO3	3/16/09	1215
Depth to V	Vater =			Nor 1 Nor	1 L Plastic	-	3/16/09	1215
nitial Wate	er Column =		(ft	Cettens	SOOML			
		1 m	cm \	G. M. K.V.		HNO3	3/16/09	1215
nitial Wate	er Volume =		(gal)	Anions	SOOML			
			\	rinions	Plastic		3/16/09	1215
X Water	Volume		(gal)	Lab: Para	n Fort (of	Ins Test	America -	Arrela
				*		,		
	olumes and				ts			
Purge V Time	Volume	Temperature	рН	Conductivity	ts DO	ORP	Turbidity	Appearance
Time	Volume (gal)	Temperature	рН •••• (SU)	Conductivity (uS/cm)		(mV)	(NTU)	
Time	Volume	Temperature	рН	Conductivity	DO		(NTU)	Appearance
Time	Volume (gal)	Temperature	рН •••• (SU)	Conductivity (uS/cm)	DO (mg/L)	(mV)	(NTU)	closty
Time	Volume (gal)	Temperature	рН •••• (SU)	Conductivity (uS/cm)	DO (mg/L)	(mV)	(NTU)	closty
Time	Volume (gal)	Temperature	рН •••• (SU)	Conductivity (uS/cm)	DO (mg/L)	(mV)	(NTU)	closty
Time	Volume (gal)	Temperature	рН •••• (SU)	Conductivity (uS/cm)	DO (mg/L)	(mV)	(NTU)	closty
Time	Volume (gal)	Temperature	рН •••• (SU)	Conductivity (uS/cm)	DO (mg/L)	(mV)	(NTU)	closty
	Volume (gal)	Temperature	рН •••• (SU)	Conductivity (uS/cm)	DO (mg/L)	(mV)	(NTU)	closty
Time	Volume (gal)	Temperature	рН •••• (SU)	Conductivity (uS/cm)	DO (mg/L)	(mV)	(NTU)	closty
Time	Volume (gal)	Temperature	рН •••• (SU)	Conductivity (uS/cm)	DO (mg/L)	(mV)	(NTU)	clorty barn
Time	volume (gal)		рН •••• (SU)	Conductivity (uS/cm)	DO (mg/L)	(mV)	(NTU)	closty
Time	Volume (gal) ////////////////////////////////////		pH (SU) 8.66	Conductivity (uS/cm) 289	DO (mg/L) (0.37	(mV) 95	(NTU) 53.4	clorty barn
Time	Volume (gal) ////////////////////////////////////		pH (SU) 8.66	Conductivity (uS/cm) 289	DO (mg/L) (0.37	(mV) 95	(NTU) 53.4	cloudy barn
Time	Volume (gal) ////////////////////////////////////		pH (SU) 8.66	Conductivity (uS/cm) 288	DO (mg/L) (0.37	(mV) 95 fre Defe 3/16	(NTU) 53.4	cloudy barn Man Time
Time	Volume (gal) ////////////////////////////////////		pH (SU) 8.66 Contair 250mL	Conductivity (uS/cm) 288	DO (mg/L) (0.37 Preserve H ₂ SQy	(mV) 95 fire Defe 3/16	(NTU) 55.4	Cloudy barn Man Time 1215 1245

105 Technology Dr., Suite 190 Broomfield, CO 80021 (303) 546-4300

Project Name	3:				Sample Loca	ition:		
Colorado School of Mines			Equipment Blank Date:					
Project Numb			01 01 -		Date:	,	,	
		07-570				3/16/	09	
Sample Type			sw (B	Sampler:			
Duplicate Other:				B Sampler: NMlezyk				
<u> </u>						<u> </u>		
Purge Vol	ume Calcu	lations		Sample Co	ollection			
Measured TE			(ft)		Container	Preservative	Date	Time
Measured TL)	$ \rangle$	(+.28)	4-226 Re-228	Igal		11	
Tatal Danih :	_	$ \rangle$		Re-228 Diss. U	infe	HNO3	3/16/09	1030
Total Depth =		┼──╲───			16			
Depth to Wat	ter =		(10)	vor/	Plastic		3/16/09	1030
		$+ - \overline{-}$		NO3 Cettoms	500mL			
Initial Water	Column =					HNO3	3/16 109	1030
	<u>.</u> .		Vin .	Ca, Mg, K, No	SOOML			
Initial Water	Volume =		(gal)	Antons	Plastic	-	3/6/09	1030
					Mastric			
3 X Water Volume			(එහි)	lian 72 .	-Farta	Unt Kst	Hondrica -	Arrida
		Field Water		Lab: Programen				
		Field Water			ts DO	ORP	Turbidity	Appearance
Purge Vol	umes and		Quality M	easuremen	ts		·····	·
Purge Vol	umes and Volume	Temperature	Quality Mo	easuremen Conductivity	ts DO	ORP	Turbidity	·
Purge Vol	umes and Volume	Temperature	Quality Mo	easuremen Conductivity	ts DO	ORP	Turbidity	·
Purge Vol	umes and Volume	Temperature	Quality Mo	easuremen Conductivity	ts DO	ORP	Turbidity	·
Purge Vol	umes and Volume	Temperature	Quality Mo	easuremen Conductivity	ts DO	ORP	Turbidity	·
Purge Vol	umes and Volume	Temperature	Quality Mo	easuremen Conductivity	ts DO	ORP	Turbidity	·
Purge Vol	umes and Volume	Temperature	Quality Mo	easuremen Conductivity	ts DO	ORP	Turbidity	·
Purge Vol	umes and Volume	Temperature	Quality Mo	easuremen Conductivity	ts DO	ORP	Turbidity	·
Purge Vol	umes and Volume	Temperature	Quality Mo	easuremen Conductivity	ts DO	ORP	Turbidity	·
Purge Vol	umes and Volume	Temperature	Quality Mo	easuremen Conductivity	ts DO	ORP	Turbidity	Appearance
Purge Vol	umes and Volume	Temperature	Quality Mo	easuremen Conductivity	ts DO	ORP	Turbidity	·
Purge Vol	Volume (gal)	Temperature (°C. (E)	Quality Mo	easuremen Conductivity	ts DO	ORP	Turbidity	Appearance
Purge Vol	Volume (gal)	Temperature (°C. (C)	Quality Mo	Conductivity (uS/cm)	ts DO	ORP (mV)	Turbidity (NTU)	Appearance
Volume purg	ed:	Temperature (°C. (É)	Quality Mo pH (SU)	Conductivity (uS/cm)	ts DO (mg/L)	ORP (mV)	Turbidity (NTU)	Appearance
Volume purg	ed: An-lyst	Temperature (°C. (C)	Quality Mo pH (SU) Contain 250mL	Conductivity (uS/cm)	preserv H ₂ SQ	ORP (mV)	Turbidity (NTU)	Appearance
Purge Vol Time	ed: S: Diss. Pho To C	Temperature (°C. (D)	Quality Mo pH (SU) Contain 250mL 125mL	Conductivity (US/cm)	ts DO (mg/L)	ORP (mV)	Turbidity (NTU)	Appearance
Volume purg	ed: An-lyst	Temperature (°C. D	Quality Mo pH (SU) Contain 250mL 125mL	Conductivity (US/cm)	ts DO (mg/L) Preserv H ₂ SO, H ₂ SO,	ORP (mV)	Turbidity (NTU)	Appearance

A

Appendix C Surface Water Sampling Procedures

٠.

Surface Water Sampling

1.0 Scope and Objective

1.1 Scope

This procedure provides instructions and establishes requirements for the collection and documentation of surface water samples by Stoller personnel. This procedure applies to the collection of surface water samples from streams, rivers, ponds, lakes, seeps, impoundments, and other surface sources.

1.2 Objective

The objective of this procedure is to establish a uniform method for the collection of surface water samples that provides representative samples in a safe and responsible manner.

2.0 Definitions

Composite Sample – A sample that is comprised of roughly equal amounts of water collected from a set of sample locations known as a sample group.

Grab Sample – A single sample collected at one sampling point over a short period of time. Grab sample results are representative of the sample location at the time of sample collection. Also called a catch sample.

Peristaltic Pump – A self-priming, low volume pump consisting of a rotor and ball bearing rollers. Tubing placed around the rotors is squeezed by the rotors as they revolve. The squeezing produces a wavelike contractual movement which causes water to be drawn through the tubing. The peristaltic pump is limited to sampling at depths of less than 25 feet.

3.0 Responsibilities and Qualifications

3.1 Project Manager

The Project Manager is responsible for ensuring that surface water samples are properly and safely collected. This will be accomplished through staff training and by maintaining quality control (QC). At a minimum, project management shall:

- 3.1.1 Verify that personnel have reviewed, and are familiar with, site-specific work plans which address surface water sampling, this procedure, and any associated procedures.
- 3.1.2 Ensure that hazards are identified and analyzed with respect to collecting surface water samples, and develop and implement controls to minimize hazards.
- 3.1.3 Provide personnel with training in the operation of surface water sampling equipment and the requirements of this procedure.
- 3.1.4 Periodically review field generated documentation associated with surface water sampling to ensure compliance with project requirements and implement corrective action if necessary.
- 3.1.5 Receive feedback from field sampling personnel in order to continually improve surface water sampling process.

3.2 Site Supervisor

The Site Supervisor is responsible for directing and overseeing all field activities, including sampling, to ensure that site-specific plan requirements are met in a safe and efficient manner within the established safety envelope.

3.3 Field Sampling Personnel

Field sampling personnel are responsible for the proper sample collection and documentation of the sampling event in accordance with this procedure. At a minimum, field sampling personnel have the responsibility to:

- 3.3.1 Familiarize themselves with site-specific work plans, surface water sampling procedures, potential hazards, and health and safety plan.
- 3.3.2 Implement the controls to minimize hazards.
- 3.3.3 Be familiar with sampling equipment and its proper use.
- 3.3.4 Properly complete field documentation.
- 3.3.5 Provide feedback to project manager in order to improve sampling process.

4.0 Equipment/Materials and Calibration

4.1 Equipment/Materials

A number of devices are available for the collection of surface water samples. These devices are constructed of a number of materials including, but not limited to: stainless steel, glass, Teflon^{*}, Tygon^{*}. The sampling and analytical requirements, as well as site characteristics, must be taken into account when determining the proper surface water sampling equipment to use. The site-specific work plans should identify the specific equipment to be used, and methods for safely using equipment.

4.2 Calibration

Equipment shall be calibrated in accordance with manufacturer's recommendations and calibration documentation shall be maintained in project files.

5.0 Method

5.1 Field Preparation

Field preparation requires the organization of sample containers, sample labels, and documentation in an orderly, systematic manner to promote consistency and traceability of all data.

- 5.1.1 General sampling areas will be predetermined to ensure coverage of the various impact scenarios and should be described in project-specific work plans. The location of each sampling point shall be surveyed or mapped and staked as described in Section 5.1.6 prior to sampling.
- 5.1.2 In flowing water, surface water sampling shall be conducted from downstream locations first, then proceed to upstream locations to avoid potential cross contamination from disturbing the substrate.
- 5.1.3 Prior to sampling and between sampling locations, sampling equipment shall be decontaminated.
- 5.1.4 Appropriate personal protective equipment shall be used, as specified in the project-specific health and safety plan.
- 5.1.5 All pertinent information (date, site name, identification number, and location) shall be recorded on a Field Activity Daily Log (FADL) and a Sample Collection Log, as appropriate. Field conditions, unusual circumstances, and weather conditions shall be noted.

- 5.1.6 Due to the nature of sampling an aqueous environment, additional steps are required to verify and mark sample locations. Depending on the project needs, it may be useful to use a Global Positioning System (GPS) to verify and mark the sample locations. Refer to *Field Mapping with a Global Positioning System* for details. The following steps shall be followed by the sampler in addition to the field preparation requirements described in Section 5.1.1.
 - 5.1.6.1 Place a marker (stake) on the shore approximately perpendicular to the sampling location and mark the sample number on the stake.
 - 5.1.6.2 If the sample location is accessible by foot, use a measuring tape to measure the distance between the marked point and the sample location station. Record the compass bearing from the sample location to the shore marker.
 - 5.1.6.3 If the sample location is accessible only by boat, use a rangefinder to estimate the distance to the shore marker to obtain the most accurate measurement. Record the compass bearing from the sample location to the shore marker. It is recommended that the boat's position on the water be stabilized to prevent drifting.
 - 5.1.6.4 Determine and record the distance and direction of each shore marker from a reference point shown on the topographic map and mark all points on a map or use a GPS, if available.
- 5.1.7 Quality Control samples, including field and source blanks, shall be collected in accordance with the project-specific work plan.

5.2 Surface Water Sample Collection Using a Transfer Container

The device most commonly used to collect grab surface water samples is a transfer container (beaker, flask, etc.) made of inert material such as glass, stainless steel or Teflon^{*}. When sampling with a transfer container, the procedure is as follows:

- 5.2.1 Survey and clearly map sampling points as described in Section 5.1.6 prior to sampling. The sample should be collected as close to the mapped location as possible. If the collection point must be moved, the new location must be approved and documented.
- 5.2.2 Dip the transfer container into the surface water. Always use a clean, properly decontaminated transfer container at each sample location.
- 5.2.3 Filter the sample if required.
- 5.2.4 Fill the sample bottle, allowing the sample stream to flow gently down the inside of the bottle with minimal turbulence.
- 5.2.5 Cap the bottle and handle the sample according to the procedures outlined in Project *Sample Shipping.*
- 5.2.6 Label the sample and document the sampling event.

5.3 Surface Water Sample Collection Using a Peristaltic Pump

A device used to collect composite surface water samples is a peristaltic pump. Samples to be analyzed for volatile organic analysis cannot be composited. When sampling with a peristaltic pump, the procedure is as follows:

5.3.1 Survey and clearly map sampling points as described in Section 5.1.6 prior to sampling. The sample should be collected as close to the mapped location as possible. If a collection point must be moved, the new location must be approved and documented.

- 5.3.2 Attach the appropriate tubing to the peristaltic pump. Always use new tubing at each sample location. Do not try to decontaminate and reuse tubing.
- 5.3.3 If filtering is required, attach the filtering device to the discharge end of the tubing.
- 5.3.4 Lower the intake end of the tubing into the water and begin pumping. If the pump is computerized, program the pump to collect the sample at the desired intervals and flow rate. If the pump is not programmable, record the discharge rate (compute discharge rate by dividing an amount of water collected by the time it took to collect it). Collect the sample at the desired interval.
- 5.3.5 Fill the sample bottle, allowing the sample stream to flow gently down the inside of the bottle with minimal turbulence. The programmable pump will perform this automatically.
- 5.3.6 Cap the bottle and handle the sample according to the procedures outlined in Project *Sample and Shipping*.
- 5.3.7 Label the sample and document the sampling event.

6.0 Required Inspection/Acceptance Criteria

None.

7.0 Records

The following records generated as a result of implementation of this procedure shall be maintained in a safe manner and submitted to project central files for storage and disposition.

Field Activity Daily Log

Sample Collection Log

Chain of Custody

8.0 References

8.1 Others

- U.S. Environmental Protection Agency. 1987. EPA Compendium of Superfund Field Operations Methods, EPA 540/P-87/001a, OSWER 9355.0-14. Washington, DC.
- U.S. Environmental Protection Agency. 1988. EPA Guidance for Conducting Remedial Investigation and Feasibility Studies under CERCLA, Interim Final OSWER Directive 9355.3-01. Washington, DC.
- American Public Health Association, American Water Works Association, Water Pollution Control Federation. 1985. *Standard Methods for the Examination of Water and Wastewater*, 16th Edition, American Public Health Association, Washington, DC.

Appendix D Data Validation Reports

¢

DATA VALIDATION REPORT

To:	Steve Brinkman/Robert Hill
From:	John Garrett
Date:	May 28, 2009
Project/Site:	Colorado School of Mines
Project No.:	4060
SDG No.:	0903149 Radium-226

This report presents the radiological data validation for the data obtained during the field activities for the above referenced work assignment. The purpose of this review is to provide a technical evaluation of the radiological results that were obtained by Paragon Procedure PA SOP 783R8 for Radium-226 by Radon Emanation Counting for SDG 0903149 from Paragon Analytics, Inc. (Fort Collins, CO). This report consists of eleven water samples for the Colorado School of Mines/4060 project collected on March 16, 2009, March 17, 2009, and March 18, 2009 and submitted to Paragon Analytics, Inc on March 19, 2009. The samples were analyzed for Radium-226 by Radon Emanation Counting on May 8, 2009. All analyses were conducted by Paragon Analytics, Inc. The field sample numbers and corresponding laboratory numbers are presented below:

Client Sample Number	Laboratory Sample Number	Matrix	Collection Date
EQUIPMENT BLANK	0903149-1	Water	March 16, 2009
SW-2	0903149-2	Water	March 16, 2009
SW1	0903149-3	Water	March 16, 2009
CSMRI-9	0903149-4	Water	March 16, 2009
CSMRI-10	0903149-5	Water	March 16, 2009
CSMRI-4	0903149-6	Water	March 17, 2009
CSMRI-5	0903149-7	Water	March 17, 2009
CSMRI-1	0903149-8	Water	March 17, 2009
CSMRI-8	0903149-9	Water	March 18, 2009
CSMRI-2	0903149-10	Water	March 18, 2009
CSMRI-1B	0903149-11	Water	March 18, 2009

Data validation was conducted in accordance with the Analytical Services Statement of Work for the following modules: Gas Proportional Counting Module RC04-v2, October 1, 2002, and U.S. DOE Quality Systems for Analytical Services Revision 2.3 (QSAS).

The radiological data were evaluated based on the following parameters:

- * Data Completeness
- * Holding Times and Preservation
- * Instrument Initial Calibrations
- * Instrument Performance Checks
- * Preparation Blanks
- * Duplicate Sample Results
- * Laboratory Control Samples (LCS) Results
- * Laboratory Control Samples Duplicate (LCSD) Results
- * Compound Quantitation and Reporting Limits (full validation only)

Data Completeness

The data package was complete as per Paragon Procedure PA SOP 783R8 for Radium-226 by Radon Emanation counting.

Holding Times and Preservation

Analytical holding times were evaluated and all criteria were met. However, holding time requirements are not applicable to radiochemistry analyses unless the isotopes of interest have short half-lives.

Calibrations

The instruments were calibrated at the required frequency.

Initial Calibration

All instruments were calibrated properly using NIST traceable SRM.

Instrument Performance Checks

All isotopes were within criteria.

Preparation Blanks

All isotopes that were analyzed had activities that were below their respective MDCs in their QC batch preparation blanks.

Duplicate Sample Analysis

All isotopic activities for Radium-226 duplicate and original analysis were within the limits of the statistical test for equivalency. No action was required.

Matrix Spike/Matrix Spike Duplicates

Matrix spike/matrix spike duplicates were not performed for the samples in this SDG, nor were any required.

Laboratory Control Samples

All recoveries were within 75-125% limits. No calculation errors or transcription errors were found.

Analyte Quantitation and Reporting Limits

Analyte quantitation was evaluated for all samples. No calculation or transcription errors were found. The results and reporting limits were correctly reported.

Overall Comments

Radium-226 was detected above the RDL in sample CSMRI-2 at 2.37 pCi/L and is considered detected.

DATA QUALIFIER DEFINITIONS

For the purpose of Data Validation, the following code letters and associated definitions are provided for use by the data validator to summarize the data quality.

- R Reported value is "rejected." Resampling or reanalysis may be necessary to verify the presence or absence of the compound.
- J The associated numerical value is an estimated quantity because the Quality Control criteria were not met.
- U J The reported quantitation limit is estimated because Quality Control criteria were not met. Element or compound was not detected.
- U The material was analyzed for, but was not detected above the level of the associated value. The associated value is either the sample quantitation limit or the sample detection limit.
- Result was not used from a particular sample analysis. This typically occurs when more than one result for an element is reported due to dilutions and reanalyses.

DATA VALIDATION REPORT

To:	Steve Brinkman/Robert Hill
From:	John Garrett
Date:	May 28, 2009
Project/Site:	Colorado School of Mines
Project No.:	4060
SDG No.:	0903149 Radium-228

This report presents the radiological data validation for the data obtained during the field activities for the above referenced work assignment. The purpose of this review is to provide a technical evaluation of the radiological results that were obtained by Paragon PA SOP 724R10 for Radium-228 by gas proportional counting for SDG 0903149 from Paragon Analytics, Inc. (Fort Collins, CO). This report consists of eleven water samples for the Colorado School of Mines/4060 project collected on March 16, 2009, March 17, 2009, and March 18, 2009 and submitted to Paragon Analytics, Inc on March 19, 2009. The samples were analyzed for Radium-228 by Radon gas proportional counting on April 24 8, 2009. All analyses were conducted by Paragon Analytics, Inc. The field sample numbers and corresponding laboratory numbers are presented below:

Client Sample Number	Laboratory Sample Number	Matrix	Collection Date
EQUIPMENT BLANK	0903149-1	Water	March 16, 2009
SW-2	0903149-2	Water	March 16, 2009
SW-1	0903149-3	Water	March 16, 2009
CSMRI-9	0903149-4	Water	March 16, 2009
CSMRI-10	0903149-5	Water	March 16, 2009
CSMRI-4	0903149-6	Water	March 17, 2009
CSMRI-5	0903149-7	Water	March 17, 2009
CSMRI-1	0903149-8	Water	March 17, 2009
CSMRI-8	0903149-9	Water	March 18, 2009
CSMRI-2	0903149-10	Water	March 18, 2009
CSMRI-1B	0903149-11	Water	March 18, 2009

Data validation was conducted in accordance with the Analytical Services Statement of Work for the following modules: Gas Proportional Counting Module RC04-v2, October 1, 2002, and U.S. DOE Quality Systems for Analytical Services Revision 2.3 (QSAS).

The radiological data were evaluated based on the following parameters:

- * Data Completeness
- * Holding Times and Preservation
- * Instrument Initial Calibrations
- * Instrument Performance Checks
- * Preparation Blanks
- * Duplicate Sample Results
- * Laboratory Control Samples (LCS) Results
- * Laboratory Control Samples Duplicate (LCSD) Results
- * Compound Quantitation and Reporting Limits (full validation only)

Data Completeness

The data package was complete as per Paragon Procedure PA SOP 724R10 for Radium-228 by gas proportional counting for SDG 0903149.

Holding Times and Preservation

Analytical holding times were evaluated and all criteria were met. However, holding time requirements are not applicable to radiochemistry analyses unless the isotopes of interest have short half-lives.

Calibrations

The instruments were calibrated at the required frequency.

Initial Calibration

All instruments were calibrated properly using NIST traceable SRM.

Instrument Performance Checks

Detector A3 on detector A failed low on the day that sample SW1 laboratory ID 0903149-3 was counted 04/24/2009. The reported sample activity was $0.73 \text{ pCi/l} \pm 0.54$ with the MDC 1 pCi/l. The laboratory additionally reports that a daily check on this detector was not performed the following day on 04/25/2009. There is a potential low bias of the reported result of 7.2% which exceeds the 3σ control limit. The reported result for sample SW-1 is qualified as **[R]** Rejected.

All other performance checks were within criteria.

Preparation Blanks

All isotopes that were analyzed had activities that were below their respective MDCs in their QC batch preparation blanks.

Duplicate Sample Analysis

All isotopic activities for Radium-228 duplicate and original analysis were within the limits of the statistical test for equivalency. No action was required.

Matrix Spike/Matrix Spike Duplicates

Matrix spike/matrix spike duplicates were not performed for the samples in this SDG, nor were any required.

Laboratory Control Samples

All recoveries were within 75-125% limits. No calculation errors or transcription errors were found.

Analyte Quantitation and Reporting Limits

Analyte quantitation was evaluated for all samples. No calculation or transcription errors were found. The results and reporting limits were correctly reported.

Overall Comments

Due to failed daily performance check for the detector A3 used to analyze sample SW-1 there is a potential low bias of 7.2% for the reported result of 0.73 ± 0.54 , The reported result for sample SW-1 is qualified as **[R]** Rejected.

Radium-228 was detected above the RDL in samples CSMRI-10 at 1.01 pCi/L, CSMRI-5 at 1.24, CSMRI-2 at 2.68 pCi/L, CSMRI-1B at 1.15 pCi/L and are considered detected.

DATA QUALIFIER DEFINITIONS

For the purpose of Data Validation, the following code letters and associated definitions are provided for use by the data validator to summarize the data quality.

- R Reported value is "rejected." Resampling or reanalysis may be necessary to verify the presence or absence of the compound.
- J The associated numerical value is an estimated quantity because the Quality Control criteria were not met.
- U J The reported quantitation limit is estimated because Quality Control criteria were not met. Element or compound was not detected.
- U The material was analyzed for, but was not detected above the level of the associated value. The associated value is either the sample quantitation limit or the sample detection limit.
- NR Result was not used from a particular sample analysis. This typically occurs when more than one result for an element is reported due to dilutions and reanalyses.

DATA VALIDATION REPORT

To:Steve Brinkman/Robert HillFrom:John GarrettDate:June 13, 2009Project/Site:Colorado School of MinesProject No.:4060SDG No.:0903149

This report presents the inorganic anions data validation for the data obtained for ten CSMRI water sample collected on March 16, 2009, March 17, 2009, and March 18, 2009 and submitted to Paragon Analytics, Inc on March 19, 2009 for the above referenced work assignment. The purpose of this review is to provide a technical evaluation of the inorganic anions results that were obtained by preparation method MCAWW, May 1994, and EMSL Rev 2.1 Alkalinity, Bicarbonate, and Carbonate by Method 310.1, Total Phosphorus by Method 365.2, Bromide, Chloride, and Sulfate by Method 300.0 from Paragon Analytics, Inc. (Fort Collins, CO). The water samples were analyzed for Bicarbonate, Total Alkalinity on March 27, 2009, Sulfate on March 24, 2009, and Chloride on March 26, 2009, Total Phosphorus on March 25, 2009. All analyses were conducted by Paragon Analytics, Inc. The field sample numbers and corresponding laboratory numbers are presented below:

Client Sample Number	Laboratory Sample Number	Matrix	Collection Date
EQUIPMENT BLANK	0903149-1	Water	March 16, 2009
SW-2	0903149-2	Water	March 16, 2009
SW-1	0903149-3	Water	March 16, 2009
CSMRI-9	0903149-4	Water	March 16, 2009
CSMRI-10	0903149-5	Water	March 16, 2009
CSMRI-4	0903149-6	Water	March 17, 2009
CSMRI-5	0903149-7	Water	March 17, 2009
CSMRI-1	0903149-8	Water	March 17, 2009
CSMRI-8	0903149-9	Water	March 18, 2009
CSMRI-2	0903149-10	Water	March 18, 2009
CSMRI-1	0903149-11	Water	March 18, 2009

Data validation was conducted in accordance with the USEPA Contract Laboratory Program National Functional Guidelines for Inorganic Data Review.

The Inorganics data were evaluated based on the following parameters:

- * Data Completeness
- * Holding Times and Preservation
- * Initial and Continuing Calibration Verification
- * Contract Required Detection Limit (CRDL)
- * Preparation/ Initial (ICB)/ and Continuing (CCB) Calibration Blanks
- * Interference Check Sample (ICSA) Results
- * Matrix Spike Results
- * Duplicate Sample Results
- * Laboratory Control Samples (LCS) Results
- * Serial Dilution Sample Results
- * Compound Quantitation and Reporting Limits (full validation only)

* All criteria were met for this parameter

Data Completeness

The data package was complete. No results were qualified as a result of the missing data.

Holding Times and Preservation

Analytical holding times were evaluated and all criteria were met.

The water samples were all found to be field filtered and had a pH less than 2.

Initial and Continuing Calibration Verification

Initial and Continuing Calibration Verification standards were analyzed at the required frequency and all were within the required 90-110%. No action was necessary.

Contract Required Detection Limit (CRDL)

All CRDL %Rs CRI %Rs were within 80-120% limits. No action was necessary.

Preparation and Initial/ Continuing Calibration Blanks

Preparation and Initial/ Continuing Calibration Blanks are evaluated to assess the level of contamination in the preparation and analytical processes.

Preparation and Initial/ Continuing Calibration Blanks were prepared and analyzed at the required frequencies.

All of the blanks that were analyzed had concentrations that were below their respective Reporting Limits (RLs).

However, if blank results were above the Instrument Detection Limits (IDLs) and below the RLs, it caused the associated sample results to be qualified for contamination as estimated and non-detected [UJ 107]. If blank results were below the negate IDL and above the negate RL, it caused the associated sample results to be qualified for negative contamination as estimated [J 107]. No sample results were qualified due to blank contamination.

Matrix Spike/Matrix Spike Duplicate Results

All MS/MSD percent recoveries were within 75-125% limits. No action was necessary.

Duplicate Sample Analysis

All original sample/duplicate sample and MS/MSD differences were less than 20% RPD or less than the RDL for results less than (5)(RDL). No actions were necessary.

Laboratory Control Samples

The laboratory analyzed laboratory control samples for all analytes. All recoveries were within 80-120% limits. No action was necessary.

Serial Dilution Results

All %Ds were less than 10% for all analytes.

Analyte Quantitation and Reporting Limits

Analyte quantitation was evaluated for all samples. No calculation or transcription errors were found. The results and reporting limits were correctly reported.

Overall Comments

Matrix Spike recoveries were not evaluated for Chloride. The Chloride concentration was above the analytical range and therefore quantitation of MS/MSD recoveries were not possible as the spike added was small relative to the unspiked sample concentration. The LCS, ICV, and CCV QC results indicate that the procedure was in control and no action was necessary.

All data were acceptable without qualification as received by the laboratory.

DATA QUALIFIER DEFINITIONS

For the purpose of Data Validation, the following code letters and associated definitions are provided for use by the data validator to summarize the data quality.

- R Reported value is "rejected." Resampling or reanalysis may be necessary to verify the presence or absence of the compound.
- J The associated numerical value is an estimated quantity because the Quality Control criteria were not met.
- U J The reported quantitation limit is estimated because Quality Control criteria were not met. Element or compound was not detected.
- U The material was analyzed for, but was not detected above the level of the associated value. The associated value is either the sample quantitation limit or the sample detection limit.
- NR Result was not used from a particular sample analysis. This typically occurs when more than one result for an element is reported due to dilutions and reanalyses.

4.7

DATA VALIDATION REPORT

To:	Steve Brinkman/Robert Hill
From:	John Garrett
Date:	June 15, 2009
Project/Site:	Colorado School of Mines
Project No.:	4060
SDG No.:	00903149

This report presents the Dissolved Organic Carbon data validation for the data obtained for ten CSMRI water sample collected on March 16, 2009, March 17, 2009, and March 18, 2009 and submitted to Paragon Analytics, Inc on March 19, 2009 for the above referenced work assignment. The purpose of this review is to provide a technical evaluation of Dissolved Organic Carbon results that were obtained by MCAWW, May 1994, Dissolved Organic Carbon by Method 415.1 from Paragon Analytics, Inc. (Fort Collins, CO). The water samples were analyzed March 24, 2009. All analyses were conducted by Paragon Analytics, Inc. The field sample numbers and corresponding laboratory numbers are presented below:

Client Sample Number	Laboratory Sample Number	Matrix	Collection Date
EQUIPMENT BLANK	0903149-1	Water	March 16, 2009
SW-2	0903149-2	Water	March 16, 2009
SW-1	0903149-3	Water	March 16, 2009
CSMRI-9	0903149-4	Water	March 16, 2009
CSMRI-10	0903149-5	Water	March 16, 2009
CSMRI-4	0903149-6	Water	March 17, 2009
CSMRI-5	0903149-7	Water	March 17, 2009
CSMRI-1	0903149-8	Water	March 17, 2009
CSMRI-8	0903149-9	Water	March 18, 2009
CSMRI-2	0903149-10	Water	March 18, 2009

Data validation was conducted in accordance with the USEPA Contract Laboratory Program National Functional Guidelines for Organic Data Review.

The organics data were evaluated based on the following parameters:

- * Data Completeness
- * Holding Times and Preservation
- * Initial and Continuing Calibration Verification
- * Contract Required Detection Limit (CRDL)
- * Preparation/ Initial (ICB)/ and Continuing (CCB) Calibration Blanks
- * Interference Check Sample (ICSA) Results
- * Matrix Spike Results
- * Duplicate Sample Results
- * Laboratory Control Samples (LCS) Results
- * Serial Dilution Sample Results
- * Compound Quantitation and Reporting Limits (full validation only)

* All criteria were met for this parameter

Data Completeness

The data package was complete. No results were qualified as a result of the missing data.

Holding Times and Preservation

Analytical holding times were evaluated and all criteria were met.

The water samples were all found to be field filtered and had a pH less than 2.

Initial and Continuing Calibration Verification

Initial and Continuing Calibration Verification standards were analyzed at the required frequency and all were within the required 90-110%. No action was necessary.

Contract Required Detection Limit (CRDL)

All CRDL %Rs CRI %Rs were within 80-120% limits. No action was necessary.

Preparation and Initial/ Continuing Calibration Blanks

Preparation and Initial/ Continuing Calibration Blanks are evaluated to assess the level of contamination in the preparation and analytical processes.

Preparation and Initial/ Continuing Calibration Blanks were prepared and analyzed at the required frequencies.

All of the blanks that were analyzed had concentrations that were below their respective Reporting Limits (RLs).

However, if blank results were above the Instrument Detection Limits (IDLs) and below the RLs, it caused the associated sample results to be qualified for contamination as estimated and non-detected [UJ 107]. If blank results were below the negate IDL and above the negate RL, it caused the associated sample results to be qualified for negative contamination as estimated [J 107]. No sample results were qualified due to blank contamination.

Matrix Spike/Matrix Spike Duplicate Results

All MS/MSD percent recoveries were within 75-125% limits. No action was necessary.

Duplicate Sample Analysis

All original sample/duplicate sample and MS/MSD differences were less than 20% RPD or less than the RDL for results less than (5)(RDL). No actions were necessary.

Laboratory Control Samples

The laboratory analyzed laboratory control samples for all analytes. All recoveries were within 80-120% limits. No action was necessary.

Serial Dilution Results

All %Ds were less than 10% for all analytes.

Analyte Quantitation and Reporting Limits

Analyte quantitation was evaluated for all samples. No calculation or transcription errors were found. The results and reporting limits were correctly reported.

Overall Comments

All data were acceptable without qualification as received by the laboratory.

DATA QUALIFIER DEFINITIONS

For the purpose of Data Validation, the following code letters and associated definitions are provided for use by the data validator to summarize the data quality.

- R Reported value is "rejected." Resampling or reanalysis may be necessary to verify the presence or absence of the compound.
- J The associated numerical value is an estimated quantity because the Quality Control criteria were not met.
- U J The reported quantitation limit is estimated because Quality Control criteria were not met. Element or compound was not detected.
- U The material was analyzed for, but was not detected above the level of the associated value. The associated value is either the sample quantitation limit or the sample detection limit.
- NR Result was not used from a particular sample analysis. This typically occurs when more than one result for an element is reported due to dilutions and reanalyses.

DATA VALIDATION REPORT

To:	Steve Brinkman/Robert Hill
From:	John Garrett
Date:	May 28, 2009
Project/Site:	Colorado School of Mines
Project No.:	4060
SDG No.:	0903149

This report presents the inorganic metals data validation for the data obtained for eleven CSMRI water sample collected on March 16, 2009, March 17, 2009, and March 18, 2009 and submitted to Paragon Analytics, Inc on March 19, 2009 for the above referenced work assignment. The purpose of this review is to provide a technical evaluation of the inorganic metals results that were obtained by SW-846, 3rd edition, Method 6010B and Paragon Procedure PA SOP 834R7 for trace metals by Inductively Coupled Plasma (ICP) atomic emission spectrometry analysis, Method 6020B and Paragon Procedure PA SOP 827R6 for dissolved metals by Inductively Coupled Plasma mass spectrometry (ICP-MS) (Uranium only) analysis for SDG 0903149 from Paragon Analytics, Inc. (Fort Collins, CO). The water samples were analyzed for dissolved ICP trace metals on March 31, 2009 and dissolved ICP-MS uranium on April 9, 2009. All analyses were conducted by Paragon Analytics, Inc. The field sample numbers and corresponding laboratory numbers are presented below:

Client Sample Number	Laboratory Sample Number	Matrix	Collection Date
EQUIPMENT BLANK	0812064-1	Water	March 16, 2009
SW-2	0812064-2	Water	March 16, 2009
SW-1	0812064-3	Water	March 16, 2009
CSMRI-9	0812064-4	Water	March 16, 2009
CSMRI-10	0812064-5	Water	March 16, 2009
CSMRI-4	0812064-6	Water	March 17, 2009
CSMRI-5	0812064-7	Water	March 17, 2009
CSMRI-1	0812064-8	Water	March 17, 2009
CSMRI-8	0812064-9	Water	March 18, 2009
CSMRI-2	0812064-10	Water	March 18, 2009
CSMRI-1B	0812064-11	Water	March 18, 2009

Data validation was conducted in accordance with the USEPA Contract Laboratory Program National Functional Guidelines for Inorganic Data Review.

The metals data were evaluated based on the following parameters:

- * Data Completeness
- * Holding Times and Preservation
- * Initial and Continuing Calibration Verification
- * Contract Required Detection Limit (CRDL) Preparation/ Initial (ICB)/ and Continuing (CCB) Calibration Blanks
- * Interference Check Sample (ICSA) Results
- * Matrix Spike Results
- * Duplicate Sample Results
- * Laboratory Control Samples (LCS) Results Serial Dilution Sample Results
- * Compound Quantitation and Reporting Limits (full validation only)

* All criteria were met for this parameter

Data Completeness

ł >

The data package was complete except for the missing CRDL (2B) and IDL (10) QC Summary Forms. No results were qualified as a result of the missing data.

Holding Times and Preservation

Analytical holding times were evaluated and all criteria were met.

The water samples were field filtered and had a pH less than 2.

Initial and Continuing Calibration Verification

Initial and Continuing Calibration Verification standards were analyzed at the required frequency and all were within the required 90-110% limits for ICP trace. No action was necessary.

Contract Required Detection Limit (CRDL)

No CRDL or CRI standard recovery summary forms (EPA Form 2b) were included in the data package. The reviewer obtained the %Rs from the instrument raw data. All CRDL %Rs for ICP and CRI %Rs for mercury were within 80-120% limits. No action was necessary.

Preparation and Initial/ Continuing Calibration Blanks

Preparation and Initial/ Continuing Calibration Blanks are evaluated to assess the level of contamination in the preparation and analytical processes.

Preparation and Initial/ Continuing Calibration Blanks were prepared and analyzed at the required frequencies.

All of the blanks that were analyzed had concentrations that were below their respective Reporting Limits (RLs).

However, if blank results were above the Instrument Detection Limits (IDLs) and below the RLs, it caused the associated sample results to be qualified for contamination as estimated and non-detected [UJ 107]. If blank results were below the negate IDL and above the negate RL, it caused the associated sample results to be qualified for negative contamination as estimated [J 107]. No sample results were qualified due to blank contamination.

Interference Check Sample (ICSA) Results

Interference Check Samples were prepared and analyzed at the required frequencies.

No aqueous concentrations of aluminum, calcium, iron, or magnesium exceeded the ICSA values in any of the samples. No action was necessary.

Matrix Spike/Matrix Spike Duplicate Results

All ICP and Mercury MS/MSD percent recoveries were within 75-125% limits. No action was necessary.

Duplicate Sample Analysis

All ICP and Mercury original sample/duplicate sample and MS/MSD differences were less than 20% RPD or less than the RDL for results less than (5)(RDL). No actions were necessary.

Laboratory Control Samples

The laboratory analyzed laboratory control samples for all metals and mercury. All recoveries were within 80-120% limits. No action was necessary.

Serial Dilution Results

All %Ds were less than 10% for all ICP and ICP-MS metals.

Analyte Quantitation and Reporting Limits

Analyte quantitation was evaluated for all samples. No calculation or transcription errors were found. The results and reporting limits were correctly reported.

Overall Comments

No CRDL or CRI standard recovery summary forms (EPA Form 2b) were included in the data package. The reviewer obtained the results from the raw data. No action was necessary.

All data were acceptable without qualification as received by the laboratory.

DATA QUALIFIER DEFINITIONS

For the purpose of Data Validation, the following code letters and associated definitions are provided for use by the data validator to summarize the data quality.

- R Reported value is "rejected." Resampling or reanalysis may be necessary to verify the presence or absence of the compound.
- J The associated numerical value is an estimated quantity because the Quality Control criteria were not met.
- U J The reported quantitation limit is estimated because Quality Control criteria were not met. Element or compound was not detected.
- U The material was analyzed for, but was not detected above the level of the associated value. The associated value is either the sample quantitation limit or the sample detection limit.
- NR Result was not used from a particular sample analysis. This typically occurs when more than one result for an element is reported due to dilutions and reanalyses.

Appendix E Results of Analyses CD

Appendix F Chains of Custody

Chain c. Custody Bacord		Temperatu	ture on Receipt	eipt _		•	<u></u>	TestAmericc	$\overline{\mathcal{A}}$	Ч	ЭТ.	\bigcirc		6	
4124 (0907)		Drinking Water?		Yes 🗆 🛛	No 🗆		THE LI	EADER I	N ENVI	RONM	ENTAL	THE LEADER IN ENVIRONMENTAL TESTING			
Client Stoller		Project Mañager	ager K							Date	21/2		Chain of Custody Number	dy Number	I
	,	Telephone	Telephone Number (Area Code)/Fax Number	Code)/Fé	X Numbe	2				Lab N		-	3	000	I
105 Trehneley De		(353)	3) 546	1	1440								Page /	of	1
State	, ,	Sile Contact	а н (Lat	Contact	4	7		Ar Mo	alysis (re space	Analysis (Attach list if more space is needed)	st if led)			I
		Carrier/Wa	Carrier/Waybill Number	6	6150	JAV VA	k v								
Contract/Purchase Order/Quote No.			Matrix		Pre	Containers & Preservatives	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	an'	<u>, F</u>				Conc	Special Instructions/ Conditions of Receipt	a /
Sample I.D. No. and Description (Containers for each sample may be combined on one line)	Date	Time 🛓	lioS ∵p∂S snoanby	'səıdu∏	HNO3 HSSO4	HO®N HCi	HO®N /9¥UZ	ton	113						
En quant Black	1165 1	1630	×	×		÷		$\langle \rangle$	1			+			I
20-2		1215	×	×				X							ł
764.1		1515	>	×											I
55 MIR 7 - 9	**	15110.	×	×				×							þ
52410 I - 10	4	1100	X	×				X				- 			1 :
															k ·
															- ¹ -1
															÷
										<u>.</u>			-		
															1
-															I
n mmable 🔲 Skin trritant	🗌 Poison B	Unknown	Sample Disposal	al Vient	N Disp	M Disposal By Lab		Archive For	2	Months		eerthan 1 n	(A fee may be assessed if samples are retained longer than 1 month)	are retained	I
	l ĉ	1 አ	610 Ju		OC Req	OC Requirements (Specify)	Sp								1
id By		Date	Time		1. Received By	ived By	i and						, Date	, Time	1
		3/16/6	5 11	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~		V		~	ور ز المراجع المراجع						
c. Heinquisned By and		Date	Time		2: Rece	2: Received By	4	and the second se	i N	-			Date	Time	I
3. Relinquished By		Date	Time		3. Received By	ived By							Date	Time	I
Comments															1

DISTRIBUTION: WHITE - Returned to Client with Report: CANARY - Stays with the Sample; PINK - Field Copy

Chain u		Tempe	Temperature on Receipt	eceipt .	.	•	<u></u>	St,	A	Ľ	TestAmeric	D		(,
<pre>Lusioay Hecord 4124 (0907)</pre>		Drinking	Water?	Yes 🗆 /	No 🗆		THE LI	EADER	NEN	VIRONN	ENTAL -	THE LEADER IN ENVIRONMENTAL TESTING	·	
Client < to Iter		Project Manager	Aanager							Date	2 long		Chain of Custody Numbe	ly Number
105 Tr. Larland		Telepho	Telephone Number (Area Code)/Fax Number	ea Code)/Fi	ie)/Fax Number L/L/L/N					Lab	Lab Number		Dace	
State	Code	Site Contact			Lab Contact					Analysis Iore spac	Analysis (Attach list if more space is needed)	t if ed)		5
State) COL	× 00×1	Carrier/V	Carrier/Waybill Number		ice by		× S	.						
Order/Quote			Matrix		Con Pres	Containers & Preservatives	N 9		<u></u>				Condit	special instructions/ Conditions of Receipt
Sample I.D. No. and Description (Containers for each sample may be combined on one line)	Date	Time	∵pəs snoanby JIV	lio2 Unpres.	FONH POSTH	и¤он юн	HO®N /Jyuz	ton	ر در در د د د ز					
(5-21/2 - 1/	shater	115	×			+		×						
	~ -		X					\times						
			×	×	-			-	\times					
0. 3.1. E. S 5		1.2 2.2						X						
	f - s annad		×		Х			× ·						
3	Million - Lander -		X	×					\geq					
we shart at	/	المناعات	×	·>				\times						
			۲ (×			\times		n				
	\rightarrow	÷	>	>					\times					
Possible Hazard Identification X Non-Hazard	Deison B	Unknown	Sample Disposal	osal o Client	N. Disposal By Lab	e j ng jes		Archiva Enr	, L	OW.	(A fe Moothe Inno	e may be a	(A fee may be assessed if samples are retained	are retained
Required 7 Days 14 D	21 Da	s K Other	- 4 10 A	de se	ac Reg	OC Requirements (Specify)	So.		5				6 m m	
d By					1. Received By	ved By							Date	Time
· · · · · · · · · · · · · · · · · · ·		31.7	65	1	12			2 - 2	··· ,	1 8 1	N.			
. All benavious and the second s		Date	Time	•	2. Received By	ved By		ت					Dáte	time - 3
3. Relinquished By		Date	Time		3. Received By	ved By							Date	Time
Comments					_									

DISTRIBUTION: WHITE - Returned to Client with Report; CANARY - Stays with the Sample; PINK - Field Copy

Chain C	Tempera	Temperature on Receipt		Test,		Ď	
Custody Hecord	Drinking I	Water? Yes 🗆	No 🗆	THE LEADER	THE LEADER IN ENVIRONMENTAL TESTING	STING	
Client Stoller	Project Manager	nager Hull			Date Date	Chain of Custody Number	odv Number
Address 105 Technichen Dr. # 190	Telephone	nber (Area C)/Fax Number		Imper		
	Sile Contact		Lab Contact		Analysis (Attach list if	Page	of
Project Name and Location (State)		Carrier/Waybill Number	Lise Antin	zek	more space is needed		
ContractPurchase Order/Quote No.		Matrix	Containers & Preservatives	-SN	27 24	Spe	Special Instructions/ Conditions of Receipt
Sample I.D. No. and Description (Containers for each sample may be combined on one line) Da	Date Time	iloS PəS sncənby	HOI HOI HOI HOI HOI HOI HOI HOI HOI HOI	HOEN 19402 19402	3111		
CSAIRT-12 Show	1/2 1200	/ ×	1	X			
		X	×	×			
		×					
(SAIRT. 2.	4 1300	X	×				
	,						
Datable							17. () () () () () () () () () (
Possible Hazard Odentification X Non-Hazard C Flammable Skin Irritant C Poison B	Unknown	Sample Disposal	X Disposal By L	ab 🗌 Archive For	Months	(A fee may be assessed if samples are retained ionder than 1 month)	are retained
Required 1 48 Hours 1 7 Days 14 Days		210 Nove	OC Requirements (Specify)	its (Specify)		6	
			1. Received By	MAN V		9.	Time
2. Refinquished By		75 1/55 5	2: Received By	A Contraction of the second se	Entrance and	CAR PA	. Time
3. Relinquished By	Date					- -	
	Card	aunt	3. Heceived By			Date	Time
comments							-

DISTRIBUTION: WHITE - Returned to Client with Report, CANARY - Stays with the Sample; PINK - Field Copy

.

	.D .	A D
7	ব	1
÷	_	<u> </u>

on Analytics

ivision of DataChem Laboratories, Inc.

800-443-1511 or (970) 490-1511 (970) 490-1522 Fax 225 Commerce Drive Fort Collins, CO 805

Date 3/15/1-01 Chain-of-Custody

Originator: Retain pink copy!

うちちちょうない いっちょう ちょうちょう しいし たちまだい たん してきやく しんしょう

Return to Client \mathbf{V} _of_ Date Dispose:

Ъ

(circle one or bolh)

Page .

Accession Number (LAB ID)

Standard) or Rush (Due Turnaround (circle one)

1

- William

9

Project Name/No.: <u>CC C/ C/ C/ Ai - C</u>/ Sampler(s): E-mail: 1. 11 @ "hollor com Phone: (303) 546-4440 Report To: Robert A Mill Fax: (303) 4113-11108

シン 00 Address: 16 5 Tertrofist Company: 540Hr Breen Call

9610 5 202 1

Circle method (right); provide additional information as needed (comments)

2808WS OC Pesticides A1808W2 SW8270C 81208WS 80928MS No. of Containers (indicate type... HCI, etc.)

Ľ Arata Ar

Нq	OSPOGWS 80406WS
sbilos:	Total E160.3 TDS E160.1 TSS E160.2
inorganic Anions	SW9056 E300.0 (specify in comments)
Hexavalent Chromium	N \ Y Steepid enits#IA A8et7W2
Dissolved Metals by ICP/MS	SW6020A E200.8
Total Metals by ICP/MS	8.0020A E200.8
Dissolved Metals by ICP Hg	SW6010B 7470 E200.7
gH 901 vd sisteM istoT	20023 1470 7471 5200.7
TCLP Metals SW1311 Hg	0247 80109WS
TCLP Organics SW1311	SW6260B 8270C 8081A 8151A
sevisolqx∃	0668WS
Herbicides	A1218WS

muitinT	E906.0
902 nogene9 vd sebinitoA	4t\mA\U\nd
6705 Alpha / Beta	0.0063 0166W2
Нат	SW80158 GRO DR
Hq	09406MS 80406MS
:sbiloS	Total E160.3 TDS
Inorganic Anions	s) 0.0065 8300.0 (s
Hexavalent Chromium	MIIISHIA ABELTW2
Dissolved Metals by ICP/MS	8.0023 A0200 E200.8
ZMIADI VO sisismi kato T	8.0023 A0203WS
Dissolved Metals by ICP Hg	23 0747 80108WS
Total Metals by ICP Hg	72 0272 80109MS

sagotosi emmeĐ	L.F003
Strontium 90 (Total RadioSr)	D5811-00
822 muibeЯ	SW9320 E904.0
82 <u>5</u> muibsЯ	E903.1
muibsЯ ըույյim∃-sriqlA lstoT	0'E063 SLEEMS
ասնո	0.9063
ACE nogened vd sebinitoA	_\m\\ft\mA\U\u9
Gross Alpha / Beta	0.0063 0166WS
Нат	SW8015B CRO DRO (circle o
Hq	29406MS 80406MS
100000	

5.112.90

C 378

3101472	
Dissolved (('service	44.9 ·
S22 nobe9	n90f37M2
saqotosi emmeĐ	F901.1
Strontium 90 (Total RadioSr)	D5811-00
822 muibeA	0.408320 E904.0
825 muibeA	E903.1
muibsЯ gaittim∃-srlqlA lstoT	0.6003 SIEGWR

<u>ې، چ</u> 10

 \times

25%

 $\langle c \rangle$

>

>

bCBs

SOOUS

soov

xitteM

al de l

H.V.C.7

. }

1. V. C.

15 21

£

24

7

 $\xi_{\mathcal{K}_{u'}}$

≽

ŧ.

42.2.41 No

いた

 \mathbf{N}

1.50

BTEX (only)

Preservative

Time *

Date

Sample ID

port

 \geq

 \geq

 $\mathbf{\dot{z}}$

 \succ

~

Relinquished By: (1)	(1) Relinquished By: (2)
Signature	
at la lo 2 la	Printed Name
	Date Time
	Company
Received By: (1) (1)	(1) Received By: (2)
Signature X ALCO 1 CV	
Printed Name Love The State	Printed Name

Time

Company

Date

031

Time

Date 3 [1최

Form 202r6.xis (6/16/06) Company

 \ge

Anners - 4003, 603, Alkalinity, cl, 504 Callens - Co, My, K, Na

All samples were altered

Matrix Key: O = oil, S = soil, NS = non-soil solid, W = water, L = liquid, E = extract, F = filter

1. 2.

¥

Time Zone: EST CST MST7PST

Comments:

H7564

	٦	A Divis
1	ব	1

i Ç

5 V		2:398 5-2.291	Deceleral Phoe	1			\geq	Ê				2		5			6		
000		· · · · · · · · · · · · · · · · · · ·	Surj?)		$\overline{}$			┢		$\overline{\overline{}}$		~~							
pi Li		X41 (3) (4	Deserver me	\times					$\mathbf{\times}$	<u>~</u>									
<u>Originator</u> . Retain pink copyl	lent	 naoistme	222 nobsЯ	·					<u> </u>										
ية ب		1:1063	eamna lsotopes					<u> </u>								Time			allie
nato	Return to Client	D2811-00	Strontium 90 (Total RadioSr)													_		F	- 1
rigi	Ret																		
O1	þ		222 mulani 828 mulan					<u> </u>	\times	- 4.5				BY:	0			a	
امیں		E903'4	Radium 226	\times										ishec	Pag	2	ed By	Nam	2
s V		2M6312 E603'0	muibsЯ grittim3-shqlA IstoT									-		Relinquished	Signature Printed Name	Date Company	Received By: Signature	Printed Name	Company
~	ŧ	E306.0	muitin Tritium											<u> </u>	፳៥	<u>s ö</u>	i	<u>د</u> د	<u>š</u> č
Page _	: Date		Actinides by Paragon SOP		_									Ξ	1		Ē	ł	
	Dispose:	2M0310 E0000	6ross Alpha / Beta												2	1. A 2.			
0	Dis		НдТ								. <u> </u>					1	J.	5	
B (D)	Îî	SM9040B SM9046C	Hq												17	~1 j	\leq		₽ ₹
Accession Number (LAB,ID)		Total E160.3 TDS E160.1 TSS E160.2	:sbiloS		· · · ·						2 (N	Lime			치
umber Date		SW9056 E300.0 (specify in comments)	Inorganic Anions			\times					\times				1S	110	X	140	
N 5		N \ Y Steepige DisklA A3617W2	muimontO transkere											BY:		2 1 1	Ş	4	۔ اب د
Accession Accession Chain-of-Custody	Rush (Due	SW6020A E200.8	Dissolved Metals by ICP/MS											Relinquished By	Printed Name		β B	Printed Name	
O AO	- HSH	SW6020A E200.8	Total Metals by ICP/MS											induis	Printed Na	Date <u>3∕/</u> Company	Received By Signature	ted N	0
Ģ	or R	SW6010B 7470 E200.7	Dissolved Metals by ICP Hg											Reli		Date Comp	Rec Sign	Printe	
hair		SW6010B 7470 7471 E200.7	0H 901 ya sisise h y ICP Hg											E					6/06)
Ö	Standard	0272 80109MS	TCLP Metals SW1311 Hg											= filter					Form 202r6.xls (6/16/06)
		SW8260B 8270C 8081A 8151A	TCLP Organics SW1311											E = extract, F					2r6.x
5. Fax	e one	088330	səvisolqx∃											= extr					orm 2(
) 805. -1522 Fa	circle	Aratews	Herbicides																ů.
llins, CO 805. (970) 490-1522 Fax	around (circle	Z808WS	PCBs							٩				= liquid,					
ollin: (970	naroi	A1808W2	oC Pesticides											1					
Fort Collins, CO 2-1511 (970) 490-1	Turn	2M8570C	SOOR											wate					
/е F (490-	Y	SW8021B	BTEX (only)											= M .					
e Driv (970)	N	SW8260B	VOCs											solid					
225 Commerce Drive Fort (800-443-1511 or (970) 490-1511	100	(j	No. of Containers	/	· ·	ţ	1	7	1	1	1	į	1	= soil, NS = non-soil solid, W = water					·
Comr 13-15'	14	uen u	(indicate type HCI, etc.)	ņ	5	~	60	Er,	ć,	¢ 1	۱ ۱	Č.	6	= nor					
225 C	2	сон Сон	Preservative	31.94	Sivi	1.	H1, 364	H., Er,	NINGS	M, φ	,	N,	1.84	NSN					
		eded.	Matrix	14			···•						÷	= soil					
ģ	:(s)ampler(s):	9 8 9	רשף ום									i e	der.	= oil S					
es, lr	âmp	tion the second s	*				A .		0			8.9% 		0					
atori	N Y	j	Time *	5151		**		\rightarrow	2115				->	ey:		-	•		
,on Analytics			<u>ر</u> م	्म जन्म										Matrix Key: 0		* 11			
	ję.	addition	Date	3hch									<u>ج</u>	Ma		م من			
An a	1.01	e ad		1										ST					
on /	12	ې کې د د د د د د د د د د د د د د د د د د			ļ				i					CST MET PSI		لې مې			
	0		0						44				i	S) E		<u>ئ</u> م			
P. Jon Analytics A Division of DataChem Laboratories, Inc.	0	d (rig	Sample ID						ì				~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	ч СS					
- <	ne/N	etho	amt	1 × 1			[7	1.12				ĺ	Ë.	÷				
	Project Name/No.:	Report To: Phone: Fax: E-mail:	Ś	N N	ĺ				5-2110					Time Zone: EST Comments:	5				
\mathbb{N}	ojecí	Report Phone: Fax: E-mail: Compai Addres		• ,					V					ime	5				
	Ā	<u>ке</u> щпо <u>к</u>												ţ)				

3

1. 1. 1. 1. 1.

		ž		Z'591	5 5-11-7	D. sselwert Pheroh	T	1	T		$\overline{}$	<u>`</u>	I			Ê						
		5				5 10 17 27)						<u> </u>			-	3	11		3		
		pink		· · · · · · · · · · · · · · · · · · ·	1-1-	marin granjassi		$ $ \ge					\times				4					
1. 19 M		ain	Ţ					ļ	<u> </u>			\times	 	<u> </u>		ļ	4					
×.	-	Ret	ō	· · · · · · · · · · · · · · · · · · ·	SM7510Rn	222 nobe7																
	r ·		2		1.100E	seqojosi smmsč													Time		Time	
144.6.		<u>Originator</u> : Retain pink copy!	Return to Client		00-11850	(120ibsA lstoT) 06 muitronts	;]					
مىدەرل (<u>ii</u>	ъ В	0.406	SW9320 E6	822 muibe5	$ \times$					X					1.					
and the state of the second					E903.1	822 muibes	\mathbf{X}					\times					Relinquished By:	ue -		:2	e	
な来て		3		0.5083	a steews	muibsЯ gnittim∃-sriqlA listo											uishe	ure Nai	an y	/ed E	Nar Nar	ла Г
		ď			0.8063	ասյյւլ											eling	Printed Name	Date Company	Received By: Signature	Printed Name Date	Company
		M	Date	/ wo / ut / w		ACtinides by Paragon SOP											(1)	<u>0 a.</u>		(1) S		<u> </u>
		Page,			1 0126MS	Gross Alpha / Beta	-										F			5		ſ
		ł	Dispose:	GRO DRO (circle one or both)		Hd1	┝										-	[]				
			ö			Hq	╂						- <u>.</u>						and the second s	j K	5	
	dí at	1	Î		80706MS													17	Time	Å.		
	91 (L)	٩٩ ٩		3 1D2 E160.1 122 E160.2		solids:												N	≓		Time	
	Accession Number (LAB Ip)	Date		(stnermoo ni Yibeqs) 0.005		Inorganic Anions			X					\geq	、		ĥ		1	, S		
17	on N	췽		Alkaline Digest? 丫 / N	A9617WS	Hexavalent Chromium											2		5	E.C.		4
	cessí	Chain-of-Custody	Rush (Due	E200.8	A0203W2	Dissolved Metals by ICP/MS											Relinquished By	ane /	1		¥.	4
С. 1	Act	S S	ų.	E200.8	A0S03W2	Total Metals by ICP/MS											Relinquish Signature	Printed Name	bany 😽	Received By Signature	N Pa	pany
		è	م R	7470 E200.7	80109MS	Dissolved Metals by ICP Hg											Relir	Print	Date 😽	Received E Signature	Printed Nai	Company
0		nain		7470 7471 E200.7	80109WS	Total Metals by ICP Hg											L					
		้ว	Standard	0242	80109WS	TCLP Metals SW1311 Hg											extract, F = filter					Form 202r6.xls (6/16/06)
				A1318 A1808 D0728	80928WS	TCLP Organics SW1311											н ж					6.xls
		ä	around (circle one)		OEEBW2	səvisolqx∃					-+						extrac					1 202r
	805	522 F.	- 원		Ararawa	Herbicides					\neg			\rightarrow			Л					Гоги
	8	(970) 490-1522 Fax	<u>(</u> 0)		2808WS	PCBs											= liquìd, E					
	lins,	6/0/6	JI DE		A1808W2	OC Pesticides				-+	-+		<u> </u>				⊑ ∟					
e.	റ്	- 1	Turne		20128W8	svocs									-+							
2		90-15			81208WS	BTEX (only)		-		\rightarrow			_		_		= M					
	Drive	(9/0) 490-1511	4										-				м, М					
	29 29	8. 10			80928WS	VOCs							_				ll sol					
	nmei	110			ints).	No. of Containers	1	1	1	1		-	~	-	×	\sim	os-uc					
	225 Commerce Drive		1110		emme	(indicate type HCI, etc.)	HALF	4 W27		84	4,54	er s	102		5.64	50	= soil, NS = non-soil solid, W = water,					
	225	909	2		d (co	Preservative	14.	. N			7 Y	here	1		ž,	20	No.					
					eede	Matrix	1.0				~					$\dot{\gamma}$	S II					
		2 L	bler		as n	Ci de l											oil S					
	P , on Analytics	Tes,	Sampler(s):		ation	*								NCP 2		新闻的来 下。	o					
	10	rator	14	~~~~	form	Time	160		_		プ	U	+			>	ey:		~			
	on Analytics	Labo	Al. in	×.	nal ir	0	- 6					-			-		Matrix Key:		Z			
	aly	lem	<	1 Sart	ditio	Date	14				P	1 d				$\dot{\gamma}$	Ма		rood			
	A n		3		le ad		<u> </u>		-+			~					201					
	- n		27		rovic														Set			
:	<u> </u>	uoi		•••	ht); p	0						1										
	ם ל				d (rig	<u>e</u>	10			. ,		ł					3					
	ш,	۲	N ^e		etho	Sample ID		T	Ī		*	1-				7	л Ц					
- 0,00			un na la	any :: :: :: :: ::	Circle method (right); provide additional information as needed (comments)	Ň	11					11.2					one: onts:					
1	ব্		Project Name/No.: <u>/ /</u>	Keport Io: Phone: Fax: E-mail: Company: Address:	ij		Ŷ					Y					Comments:					1
_		╝└	ž	Report Phor E-ma Com			<u> </u>										ŝ					

	P on A	A Division of Data(
C	<u> </u>	1

Control Line Control Line<	-	. Г	2:598 5-0	NATION MANGASS			-	<u> </u>	\sim					\times						
Party Contraction Biology Data Contraction Biology <	1000		6.072	Such 2	<u> </u>			$ $ \geq	-	1			$\left \right\rangle$	_	<u> </u> @	I		ର	j ∣	
Party Contraction Biology Data Contraction Biology <	nink			1 2 2 10 VIN 235 10			<u> </u>	-	-		$ \times$									
Party Contraction Biology Data Contraction Biology <	tain				\times		-	-		$ \times $			ļ		-					
Party Contraction Biology Data Contraction Biology <	a a							<u> </u>		 	· ·		<u> </u>		-		 e			e e
Party Contraction Biology Data Contraction Biology <	lator		L'1063				<u> </u>			<u> </u>		<u> </u>			-		Ē			щ. Ц
Party Contraction Biology Data Contraction Biology <	riain		D5811-00				<u> </u>		ļ	<u> </u>	<u> </u>	<u> </u>		[ļ					
P Online Open of the Analytics Second of the	C	⁰ 2	?	····	· · ·		-				· ·				BY:					
P Online Open of the Analytics Second of the	к¢	4		·····						×					shed	e Vame	2	d By:	e Vame	
P Online Open of the Analytics Second of the	t t								-						linqui	natur nted h	te La la La la	ceive	natur ted ∜	te mpan
Constraint Constra	3	+ •	, ,												h	ο Σ Δ	ас		Sig Pri	<u>n</u> 0
P Commentation	Pade	ĥ					ļ								Ξ			E	i	.
P Solution PH Solution Contraction				···-							<u> </u>			<u> </u>		Ň] (5 8
P Solids: Twee tool Solids:		1														1	00		$\frac{1}{2}$	51
P On Analytics 255 Commerce Dive Fort Collins, Co. 805 Constrained from advances, Inc. 255 Commerce Dive Fort Collins, Co. 805 Constrained from advances, Inc. 255 Commerce Dive Fort Collins, Co. 805 Constrained from advances, Inc. Constraine, Inc. <thconstr< td=""><td>AB ID</td><td></td><td>1</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>1</td><td>er E</td><td></td><td>र्ये</td><td></td></thconstr<>	AB ID		1													1	er E		र्ये	
P On Analytics 255 Commerce Dive Fort Collins, Co. 805 Constrained from advances, Inc. 255 Commerce Dive Fort Collins, Co. 805 Constrained from advances, Inc. 255 Commerce Dive Fort Collins, Co. 805 Constrained from advances, Inc. Constraine, Inc. <thconstr< td=""><td>lte (L</td><td>1</td><td></td><td></td><td></td><td></td><td>$\overline{}$</td><td></td><td></td><td> </td><td></td><td></td><td></td><td></td><td></td><td>K</td><td>Ē</td><td></td><td></td><td>1</td></thconstr<>	lte (L	1					$\overline{}$									K	Ē			1
P On Analytics 255 Commerce Dive Fort Collins, Co. 805 Constrained from advances, Inc. 255 Commerce Dive Fort Collins, Co. 805 Constrained from advances, Inc. 255 Commerce Dive Fort Collins, Co. 805 Constrained from advances, Inc. Constraine, Inc. <thconstr< td=""><td>Vumb Da</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td><u>~</u></td><td></td><td></td><td></td><td>12</td><td>1/0</td><td></td><td>1 1</td><td>5 301</td></thconstr<>	Vumb Da											<u>~</u>				12	1/0		1 1	5 301
P On Analytics 255 Commerce Dive Fort Collins, Co. 805 Constrained from advances, Inc. 255 Commerce Dive Fort Collins, Co. 805 Constrained from advances, Inc. 255 Commerce Dive Fort Collins, Co. 805 Constrained from advances, Inc. Constraine, Inc. <thconstr< td=""><td>sion l</td><td>` a</td><td>I</td><td>·</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>B.</td><td>11</td><td>UN.</td><td>S</td><td>2-] </td><td><u>P</u></td></thconstr<>	sion l	` a	I	·											B.	11	UN.	S	2 -] 	<u>P</u>
P On Analytics 255 Commerce Dive Fort Collins, Co. 805 Constrained from advances, Inc. 255 Commerce Dive Fort Collins, Co. 805 Constrained from advances, Inc. 255 Commerce Dive Fort Collins, Co. 805 Constrained from advances, Inc. Constraine, Inc. <thconstr< td=""><td>lcces uste</td><td>le</td><td>9.0023 M0209WIS</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>•</td><td>isheo</td><td>i Ē</td><td><u>د کر</u> ۲</td><td>g By</td><td>Nam_√ Nam_√</td><td>R P</td></thconstr<>	lcces uste	le	9.0023 M0209WIS											•	isheo	i Ē	<u>د کر</u> ۲	g By	Nam_√ Nam_√	R P
P On Analytics 228 Commerce Dire For on Analytics 228 Commerce Dire Appresent of DataChen Leboratories, Inc. 228 Commerce Dire	v v	Rus	20008 4500 8												elinqu	inted	ate	ceive	gnatu inted	ate ompai
P On Analytics 228 Commerce Dire For on Analytics 228 Commerce Dire Appresent of DataChen Leboratories, Inc. 228 Commerce Dire	i.	Å	24400102 1410 1410 E2001												άΰ	ን ቪ	ŏŏ	ď	ቨት	
Poinson of DataChemi Laborations. Inc. 226 Commerce Fort Collins. CO 805 ADvision of DataChemi Laborations. Inc. 226 Commerce Fort Collins. CO 805 Annohor: CC 57/cvr / 4/1, v1 54 microscope 238 commerce Fort Collins. CO 805 Annohor: CC 57/cvr / 4/1, v1 54 microscope 500 405 Annohor: CC 57/cvr / 4/1, v1 54 microscope 500 405 Annohor: CC 57/cvr / 4/1, v1 54 microscope 500 406 Annohor: CC 57/cvr / 4/1, v1 4 500 406 Annohor: CC 57/cvr / 4/1, v1 4 500 406 Annohor: CC 57/cvr / 4/1, v1 4 500 406 Annohor: CC 57/cvr / 4/1, v1 4 500 406 Annohor: CC 57/cvr / 4/1, v1 4 500 406 Annohor: CC 57/cvr / 4/1, v1 4 500 406 Annohor: CC 57/cvr / 4/1, v1 4 500 406 Annohor: CC 57/cvr / 4/1, v1 4 500 406 Annohor: CC 57/cvr / 4/1, v1 4 500 406 Annohor: CC 57/cvr / 4/1, v1 4 500 406 Annohor: CC 57/cvr / 4/1, v1 4 500 406 Annohor: CC 57/cvr / 4/1, v1 4 500 406 Annohor: CC 57/cvr / 4/1, v1 4 500 406 Annohor: CC 57/cvr / 4/1, v1 4 500 406 Annohor 500 406 A	Che	darc	0/t/ B0109MS												filter					9/16/06
P On Analytics 225 Commerce Dive Fort Collins, CO ameiNol.: CO State: / 24 M x 3 Sampler(s); (100 apoint) (970 apoint) ameiNol.: CO State: / 24 M x 3 Sampler(s); (100 apoint) (970 apoint) ameiNol:: CO State: / 24 M x 3 Sampler(s); (100 apoint) (970 apoint) amelNol:: CO State: / 24 M x 3 Sampler(s); (100 apoint) (970 apoint) amelNol:: CO State: / 24 M x 3 Sampler(s); (100 apoint) (970 apoint) ampleoit (100 apoint) (100 apoint) aminthout <		Star Star	41918 81808 200C 80818 81918												II LL					i.xls (6
P On Analytics 225 Commerce Dive Fort Collins, CO ameiNol.: CO State: / 24 M x 3 Sampler(s); (100 apoint) (970 apoint) ameiNol.: CO State: / 24 M x 3 Sampler(s); (100 apoint) (970 apoint) ameiNol:: CO State: / 24 M x 3 Sampler(s); (100 apoint) (970 apoint) amelNol:: CO State: / 24 M x 3 Sampler(s); (100 apoint) (970 apoint) amelNol:: CO State: / 24 M x 3 Sampler(s); (100 apoint) (970 apoint) ampleoit (100 apoint) (100 apoint) aminthout <	ž	one)		· · · · · · · · · · · · · · · · · · ·					-						xtract					202r6
Pon Analytics 225 Commerce Drive Ir A Division of DataChem Laboratories, Inc. 225 Commerce Drive Ir ameNo.: CD Strike / drive / dri	805. 522 Fe	rcle	Ararawa									-			ю н Ш					Form
Pon Analytics 225 Commerce Drive Ir A Division of DataChem Laboratories, Inc. 225 Commerce Drive Ir ameNo.: CD Strike / drive / dri	49-1 1	ld (ci	2808/MS																	
Pon Analytics 225 Commerce Drive Ir A Division of DataChem Laboratories, Inc. 225 Commerce Drive Ir ameNo.: CD Strike / drive / dri	llins, (970)	arour	A1808W2								*									~
Pon Analytics 225 Commerce Drive Ir A Division of DataChem Laboratories, Inc. 225 Commerce Drive Ir ameNo.: CD Strike / drive / dri	X	Turn	20178WS												rater,					
P On Analytics A Division of DataChem Laboratories, Inc. ame/No.: CD Scieve / S	∋ Fc 490-1£		1	BTEX (only)											× ₩					
P On Analytics A Division of DataChem Laboratories, Inc. ame/No.: CD Scieve / S	Driv (970)	V	80928MS							-					olíd, /					
P On Analytics A Division of DataChem Laboratories, Inc. ame/No.: CD Scieve / S	lerce 1 or	2		No. of Containers		~	-	-	~~.	-	-	~	~	,	soil s					
P On Analytics A Division of DataChem Laboratories, Inc. ame/No.: CD Scieve / S	20mn 3-151	1. 6	ment		্গ	M	-	4	2	*	Μ			<u>.</u>	-uou					
P On Analytics A Division of DataChem Laboratories, Inc. ame/No.: CD Scieve / S	225 C 300-44		(com		here	Here	1.	4	1.5	1 v.	24.90	!	$\mu_{i} \mathfrak{L}$	H. 36	"SN					
Pon Analytics A Division of DataChem Laboratories amerNo.: <u>CO Schew Leb Al Ary</u> Sa To:: amerNo.: <u>CO Schew Leb Al Ary</u> Sa To:: NY: Sample ID Date Time * A Division of DataChem Laboratories			ede d	Matrix	$[\sim]$									▶	soil,					
Pon Analytics A Division of DataChem Laboratories amerNo.: <u>CO Schew Leb Al Ary</u> Sa To:: amerNo.: <u>CO Schew Leb Al Ary</u> Sa To:: NY: Sample ID Date Time * A Division of DataChem Laboratories	ö	pler(as ne	Lab ID										a de s	ູ່ ເ					
Polynomial Pon Analytics Project Name/No.: CD School Laborator Project Name/No.: CD School Laborator Report To: Phone: Fax: E-mail: Company:	ies, I	Sam	ation) a															
Point Point Project Name/No.: CD Schem Labo Project Name/No.: CD Schem Labo Report To: Phone: Fax: Company: Sample ID Sample ID Date Company: Company: <td>S rator</td> <td>2</td> <td>l / log</td> <td>Time</td> <td>12.14</td> <td></td> <td></td> <td></td> <td>\rightarrow</td> <td>N/H</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>1</td> <td></td> <td></td> <td></td>	S rator	2	l / log	Time	12.14				\rightarrow	N/H							1			
P. On Analy A Division of DataChem Project Name/No.: CD Strice / A Phone: Fax: E-mail: Company: KC / A Sample ID Dat Sample ID Dat Comments: Comments:	tic: Labo	7			13			-							trix r		Ň			
Project Name/No.: CO Schore Report To: Phone: Fax: E-mail: Company: KK	hem hem	13	dditio	Dat	1. 4									≯ :	Ma		2	r.		
Project Name/No.: CO Sta Project Name/No.: CO Sta Report To: Phone: Fax: E-mail: Company:	An ataC	30	ide a				·		+	-1			-		n N		Ĭ,	,		
Project Name/No.: 52 Report To: Phone: Fax: E-mail: Company: A Division Fax: Company: Company: Company: Address: Address: Company	o D D		prov X														V.	1		
Project Name/No.: Project Name/No.: Report To: Phone: Fax: Company: Co	VISIO	$ $ \vee	ight)	ē	6					~					U N					
Project Name Project Name Report To: Phone: Fax: Company: Address: Circle met Circle met Company:	D A	/No.:) poq	ple	*1				⇒		-+-			$\geq $	כ ה					
Project h Report Fax: Fax: Compa Compa Compa Compa		ame	s: ny:	San						Neger				l	i ts:					
	ব্ব1	act N	Circle		\sim					A. *					men					
	<u> </u>	Proj	Rei Fax Adc												Com					

 $\sum_{i=1}^{n} (i \in [i] \setminus \{i\})$

the second strategy of the second strategy of the

and the second differences of the second

í V	j,		7 578 512	Disseleral Pless	T	Τ	1	$\overline{\mathbb{N}}$		<u> </u>		[<u>_</u>		5		<u> </u>	2		
11. J. W. A.	Retain pink copy!	1	······································	500493		॑		\vdash	·		\mathbf{x}				12			18		[
an at the sec	lniq r			Dicede lat Wearing	\sim				1	$\overline{\mathbf{x}}$	\vdash		$\left \right $	\vdash	1					
× 14.	tetair	Return to Client	uziotezme	Radon 222			<u> </u>	<u> </u>	+						1					
a da a		5	L.108∃	camma lsotopes	1 1			1						<u> </u>	1		Time			Lime
「「「「」」、「」、「」、「」、「」、「」、「」、「」、「」、「」、「」、「」、	<u>Originatoı</u> .	eturn	D5811-00	Strontium 90 (Total RadioSr)																ľ
and the	<u>Oric</u>	ъ Г	2M3350 E304.0	822 muibeA	\geq				1	\mathbf{X}					1					
1 in 1			E903.1	922 muibeA	\geq			1		X					Relinquished By:	1			em	1
5	\$		0.6063 8166WS	mulbeЯ griffimЭ-eriqlA isto		1		1							duish	Signature		Company	Signature	
	ة الأ		0.9063	Tritium											Relin	Signé	Date	Received	Signature Printed Na	Date
	Page	Date	Pu / U / Am / Th / Cm /	AOS nogeney by Paragon SOP											E	5	1 1	Ē	1	гİ
	- <u>6</u>)Se:	0.0003 0156WS	Stos Alpha / Seta												/				
	5	Dispose:	2M8012B CKO DKO (citcle one or polly)	Нат					<u> </u>]	1				ت ا ۲
	(LAB ID)		OS406MS 80406MS	Hq		ļ										N.			रें] उ	
	Accession Number (LAB ID) Sustody Date 3/131		Total E160.3 TDS E160.1 TSS E160.2	sbilo2:												N	Time			
	<i>Imber</i> Date		SW9056 E300.0 (specify in comments)	Inorganic Anions			\times			<u> </u>		$ \times $						Y.		Ι,
	N N		N \ Y Sizegi O enils XIA A3017WS	Hexavalent Chromium											2	1			J.	-
	Accession I Chain-of-Custody	Rush (Due	8W6020A E200.8	SM/901 yd sistsM beviosei0											Relinquished By		10	١Å) N P	ر) شمہ ا
?	^A CU	tush	SW6020A E200.8	Total Metals by ICP/MS											indui	Signature	Date 3/	Received B	Signature	ć
	io-u		SW6010B 7470 E200.7	Dissolved Metals by ICP Hg				<u> </u>							Rel	Sig Prir	D at	n R	Sig Prir	40C
	chai	ard)	SW6010B 7470 7471 E200.7	Total Metals by ICP Hg	ĺ	 									= filter					
	0	standard) or	0247 80109MS	TCLP Metals SW1311 Hg											ի և լ					
			SW8260B 8270C 8081A 8151A	TCLP Organics SW1311											extract,					
	ollins, CO 805. (970) 490-1522 Fax	cle ol	2M8330	Herbicides Explosives											ш Ш					
	50 l	d (cir	2808082 A1518W2	PCBs											= liquid, E					
	lins, CO 970) 490-1	loun	A1808W2	OC Pesticides							4				l .					s.
		Turmaround (circle one)	2M8570C	200 D-4,-1,-1											ater, I					
	For 90-15		SW8021B	BTEX (only)											∧ = \					
	Drive 970) 4	Ŕ	SW8260B	AOCs										•	olid, V					
	225 Commerce Drive Fort C 800-443-1511 or (970) 490-1511		· · · · · · · · · · · · · · · · · · ·		1	<u> </u>	1				-	~		~	= soil, NS = non-soil solid, W = water, I					
	Comn 13-151	1-1		Preservative (indicate type HCI, etc.)		مر بر	Ň.	¥,,	2	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	5	\	El,	¥ 1,	non					
	225 (800-4	2 role		Preservative	1.203	フィード	. 1	11 1. 26%	17. CA	5 N.N.	1640	1	5.4	11.4	SNS					
		s):		e B XitteM	01		····-							+	= soil					
	lnc.	npier(E OI QE											= oil, S					
	P. on Analytics A Division of DataChem Laboratories, Inc.	.(s): کار Sampler(s):		Sample ID Date Time *	<u>ی</u> ب	2100794	·			Ú Ú					0					
	CS aborat	M.M.		Lingo	5				4	201				1	Matrix Key:		-			
	alyti em La	3		Date	1.16									7	Matri			~		
	Ana	100	2		~										ST			Darg 4		
	of Da	501.	× × × ×																	
	sion	26	Ŵ.		Ì.				-	С					. –			y V		
	A A	No.:		s metrod (rign Sample ID	٤.				\mathbf{i}	1 1~	-			- X I	st csi					
	4	Ime/i	ö Ä	Sam	1.11				ĺ.	1.15				1	Time Zone: EST Commants:	į				
		ct Na	ort ne: ipar ress		12 12					t ,					Zon	5				
<u>_</u>		Project Name/No.:	Report To: Phone: Fax: E-mail: Company: Address:												' Time Zone: Commants:					
		- Line		1	. 1	1				1	1	- I	1		• ~	-				

opy!		2' 572 5 mary	Discoluted Phere											(2)		Ę	<u>۱</u>		
Retain pink copy!			Sunt D								ļ								
ain p	ŧ		Why provide	Х		<u> </u>					<u> </u>		ļ						
Reta	Clie	n Aotat Ma	Radon 222	-					· ; *						 e			6	
4	Return to Client	E901.1	sagotosi emmeð	-i							<u>.</u>	-			Time			Time	
Origina	Retu	D2811-00	Strontium 90 (Total RadioSr)					• • • •			ŀ		ļ						
<u>S</u>	ō	2M3350 E304 0	Radium 228	<u>`</u>										By:					
1		E903 1	825 muibeA	\times		ļ	<u> </u>					. <u>.</u>	<u> </u>	Relinquished By Signature	Printed Name Date	2		Printed Name Date	
ŭ ŭ		0.509315 E903.0	muibsЯ goithim⊒-sriqlA IstoT			ļ					ļ			Relinquist Signature	te	Company	Received By Signature	nted te	Company
er l		E306.0	Tritium								<u> </u>				Printe Date	_		Printe Date	<u> </u>
Page	Date	/ mጋ / dT / mA / U / u9	Actinides by Paragon SOP							·			. 	E	A I		E I	$\langle \rangle$	
	Dispose:	0.009310 E900.0	Gross Alpha / Beta			ļ									10			ş 🦳	
5	Disg	SW8015B CKO DKO (circle one or bolh)	ТРН			<u> </u>			·						20	8) 31		25	Ť.
B (D)	$\cdot \mid \mid$	SW9040B SW904SC	Hq			<u> </u>										**	1	Time	ن لا
er (LA			Inorganic Anions Solids:		-			• .							Щ.	VI.	\leq		
vumber Date		SW9066 E30.0 (specify in comments)	Hexavalent Chromium								 	. 			\sum	2/6	5	5 y 5	
Accession Number (LAB ID)	e	SW6020A E200.8 SW6020A E200.8	Dissolved Metals by ICP/MS			<u> </u>		1.			 		-	d BY	100 P		7g	ne <u>(</u>)	2
icces: UStC	<u>n</u> g	SW6020A E200.8	Total Metals by ICP/MS											uishe	Nan Nan	any .	ਸ਼ ਸ਼ੁਰੂ ਅਸ	n and a second	any
Ç, A	Rush (Due	SW6010B 7470 E200.7	Dissolved Metals by ICP Hg								•			Relinquished By	Printed Name Date 3/14/	Company	Received By Signature	Printed Name	Company
Accession I Chain-of-Custody		2002 2420 2420 2421 E2002	total Metals by ICP Hg	. ,	<u> </u>					-				•	<u>a</u> 13	010	L ()		
Che	Standard or	0247 80109MS	TCLP Metals SW1311 Hg											= filter					(6/16/
	N.	AIBI8 AI808 D0728 80828WS	TCLP Organics SW1311																Form 202r6.xls (6/16/06)
ř	one)	0668WS	səvisolqx∃			:								extract, F					m 202
llins, CO 80: (970) 490-1522 Fax	around (circle one)	A1218WS	Herbicides							· .				Ш Ш					я Го
CO 499-1	o) pu	2808WS	PCBs					. ,						= liquid,			,	4	
ollins, (970)	arou	Ar808W2	OC Pesticides				· .										ι.		
Fort Collins, CO 0-1511 (970) 490-	Turn	20128W8	SVOCs								-			= wate	· .			2	
е F(490-1		SW8021B	BTEX (only)											≞ N	• •				
e Driv (970)	X	80928MS	VOCs							-				solid	÷ .				
225 Commerce Drive Fort (800-443-1511 or (970) 490-1511	alake + K	1	No. of Containers	-								-		= oil, S = soil, NS = non-soil solid, W					
Comr 43-15	×1,*			Ester										ou ≞					
225 (800-4	2		Preservative											i, NS					
	(s)		¹ xinteM	14										100					
ti.	pler		01 9P 1	i Len ny l		 								= oil, 5					
atories,	. المعلمة المعل		* e U U U U	08.01										(ey: 0	•	~			
F Jon Analytics A Division of DataChem Laboratories, Inc.	1 may 1	ort To: ne: all: 1pany: ress:	Date	169 1.		· .	• .							Matrix Key: 🛛		ير حدد ل			
Jon Analytics n of DataChem Labor	\sim			1. Stor		 		•			<u> </u>	<u></u>				~ ¥~			
J n ∕ Jf.Dat	57.00			~ -								. •		CST MST PST		Ň			
JC Division	00	lan can e gi		3										ST€			`		
Divis	10:1	e e la companya de la Recentra de la companya de la company Recentra de la companya de la company	Sample ID	- È			•								•				
- ∢	me/h	ö Ä.	Sam	11.12						•			2 2 1	e: E					
	Project Name/No.:	Report To: Phone: Fax: E-mail: Company: Address:		Ь С								. 		Time Zone: EST Comments:	5				
ノ	ojec	Report Phone: Fax: E-mail: Compar Addres:		Ĩ										Time	× .				
	Ā	ועפתחטא	<u> </u>	L				<u> </u>	L		<u>.</u>	1	L	* •					

	F	CSMRI-4		F		I	3		1	CSMRI-2	T				1				1			CSMRI-1B	1					F	1	T			CSMRI-1				4				Sample Station
9/7/05	6/14/05	2/25/05	12/5/08	9/24/08	4/17/08	2/28/08	11/27/07	9/11/07	6/28/07	3/8/07	9/13/06	6/14/06	3/15/06	12/20/05	9/7/05	6/14/05	2/25/05	12/5/08	9/24/08	4/18/08	2/28/08	11/27/07	9/11/07	6/26/07	3/8/07	12/3/08	9/25/08	4/18/08	2/27/08	11/27/07	9/11/07	6/27/07	3/1/07	9/13/06	6/14/06	3/15/06	12/20/05	9/7/05	6/14/05	2/25/05	Sample Date
0.17	0.26	-0.03	1.1	0.97	1.08	1.37	0.45	0.78	1.4	0.76	1.01	0.99	1.25	1.35	1.78	1.47	0.8	0.02	0.05	0.03	0.32	0.11	-0.13	0.09	0.13	0.32	0.26	-0.02	0.2	-0.2	-0.3	0.51	0.32	0.25	0.42	-0.15	-0.19	0.1	0.16	-0.11	Ra-226 (pCi/l)
0.78	0.34	0.16	1.88	1.41	1.89	2.26	2.05	3.2	3.2	2.15	2.35	1.79	2.53	1.62	2.71	3.0	1.85	0.88	0.3	0.72	0.61	1.16	0.65	0.3	1.19	1.39	0.88	0.66	0.85	0.72	0.53	0,91	0.78	0.34	0.05	0.58	0.59	0.63	0.44	0.81	Ra-228 (pCi/l)
-0.013	0.013	0.019	NT	TN	0.041	0.043	0.037	0.016	-0.075	0.022	0.088	0.25	0.03	0.108	0.162	0.14	0.07	NT	NT	-0.004	0.01	0.004	0.019	0.001	-0.03	NT	NT	-0.03	0.035	0.71	-0.031	0.17	0.052	0.11	0.15	0.025	-0.045	0.068	0.018	0.007	(pCI/I)
0.164	0.014	-0.009	NT	NT	-0.021	0.085	0.035	0.101	-0.01	-0.01	-0.039	0.22	0.204	0.285	0.108	0.003	-0.02	NT	NT	-0.046	0.058	0.06	0.012	0.002	-0.09	* NT	NT	-0.004	0.032	0.101	0.019	0.064	-0.031	-0.079	-0.06	0.032	0.32	0.167	-0.021	0.07	Th-228 (pCi/l) (pCi/l)
0.086	0.005	0.013	NT	NT	0.008	0.044	0.006	0.014	-0.007	0.011	-0.008	0.049	0.012	0.024	0.049	0.026	0.01	NT	NT	0	0.033	0.016	0.001	0.012	0.02	TN	NT	0.01	0.011	0.02	0.001	-0.005	0.012	0.027	0.062	-0.004	0.014	0.114	0.012	0.01	Th-232 (pCi/l)
6.4	11.4	9.7	NT	TN	NT	NT	NŢ	NT	NT	NT	0.46	0.69	0.83	0.83	0.65	0.68	0.6	T	NT	NT	NT	NT	NT	TN	NT	NT	NT	NT	NT	NT	NT	NT	N	0.45	0.18	1.76	0.94	0.85	0.43	0.77	(pCi/l)
0.33	0.49	0.53	NT	NT	NT	NT	TN	T	NT	NT	0.014	0.04	0.066	0.002	0.050	0.025	0.05	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	0.051	0.18	0.11	0.073	0.053	0.011	0.043	U-235 (pC <i>V</i> I)
6.4	10.6	8.2	NT	TN	NT	NT	NT	NT	NT	NT	0.28	0.25	0.45	0.35	0.31	0.299	0.16	NT	NT	NT	NT	NT	NT	TN	NT	NT	TN	NT	TN	NT	NT	NT	NT	0.25	0.08	0.92	0.46	0.43	0.217	0.53	(pCII)
19.3	31.4	24.7	0.83	0.69	0.89	0.68	_	0.98	2	0.72	0.85	0.76	1.36	1.06	0.94	0.89	0.53	4.6	4	0	6.5	6.9	6.3	5	2.7	1,5	0.96	1.9	1.5	1.2	0.72	0.88	1.2	0.77	0.31	2.8	1.41	1.3	0.64	1.61	Total U (µg/l)

			CSMRI-7B				CSMRI-6C				RA-IAWSU			-							CSMRI-5																				Sample Station	
DRY	9/24/08			9/10/07	6/26/07	2/27/07	7/11/08 (DRY)	4/18/08	2/28/08	11/27/07	9/10/07	6/26/07	2/27/07	12/4/08	9/25/08	4/17/08	2/27/08	11/26/07	9/11/07	6/27/07	3/8/07	9/13/06	6/15/06	3/15/06	12/20/05	9/7/05	6/14/05	2/25/05	12/5/08	9/25/08	4/17/08	2/27/08	11/26/07	9/11/07	6/27/07	3/8/07	9/13/06	6/15/06	3/15/06	12/20/05	Sample Date	· · · · · · · · · · · · · · · · · · ·
NT	DRY	N	NT	NT	0.65	NT	NT	0.36	0.26	-0.02	0.15	0.46	NT	0.78	2.87	1.37	1.05	1.52	1.91	2.22	1.78	2.29	2.13	0.57	1.97	2.50	2.51	1.06	0.09	0.32	0.11	0.24	0.33	0.99	0.07	0.09	-0.05	0.41	0	0.13	Ra-226 (pCi/l)	
NT	DRY	TN	NT	NT	0.22	NT	NT	0.88		0.77	0.91	0.63	NT	0.68	0.47	0.64	0.17	0.49	1.2	0.86	0.39	0.56	0.87	0.45	0.52	0.76	0.44	0.53	0.97	0.8	0.71	0.78	0.73	1.12	0.87	0.37	0.79	0.39	0.38	0.1	Ra-228 (pCi/l)	
NT	TN	TN	TN	TN	0.036	TN	NT	-0.005	-0.009	-0.002	0.046	-0.009	NT	NT	NT	0.068	-0.011	0.004	0.091	0.008	-0.012	0.053	0.145	0.038	0.032	0.06	-0.018	0.009	NT	TN	0.017	0.011	0.029	0.024	0.011	-0.034	0.056	0.11	0.004	0.033	Th-228 (pCill)	
TN	NT	TN	NT	NT	0.054	NT	NT	-0.022	0.022	0.069	0.025	-0.006	NT	NT	NT	0.029	0.02	-0.008	0.003	-0.023	-0.061	-0.053	0.08	0.144	0.126	1.25	0.039	0.007	NT	NT	-0,019	0.038	0.149	0.112	0.035	-0.037	-0.015	0.17	0.174	0.311	Th-228 Th-230 (pCill) (pCill)	
TN	NT	NT	NT	NT	0.027	NT	NT	0.021	0.022	0.004	0.023	0.024	NT	NT	NT	0.017	0.051	0.01	0.006	0.013	0	0.005	0.043	0.019	0.01	0.051	0.011	0.034	NT	NT	0.002	0.014	0.016	0.021	0.004	0.013	0.007	0.061	0.007	0.012	Th-232 (pCi/l)	
TN	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	TN	NT	IN	NT	TN	3.18	1.03	1.81	1.45	1.85	1.51	1.22	NT	NT	NT	NT	NT	NT	NT	NT	6.5	9.2	9	11.5	U-234 (pCi/l)	
TN	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	TN	0.17	0.13	0.058	0.066	0.051	0.086	0.056	NT	TN	NT	NT	NT	NT	NT	TN	0.35	0,4	0.43	0.61	U-235 (pCi/l)	
TN	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	NT	TN	TN	NT	NT	NT	NT	NT	NT	2.32	0.92	1.38	1.21	1.47	1.2	0.93	TN	NT	NT	TN	NT	TN	NT	NT	6	8.9	9	11.4	U-238 (pCi/l)	
TN	NT	NT	NT	NT	89	TN	NT	5	4.7	8.2	11	17	TN	10	10	6.7	6.6	6.6	11	10	5.8	7	2.8	4.1	3.63	4.4	3.57	2.8	61	43	62	58	48	49	66	48	17.9	26.8	27.1	34.3	(µg/l)	

*Maximum Contaminant Level – National Primary Drinking Water Regulations **5 CCR 1002-41 Reg 41 – Colorado Groundwater Standards pCi/1 - picocuries per liter NE – Not Established NT – not tested µg/1 – micrograms per liter

CSMRI-11B

Not sampled

TN T

Total Ra = 5

Th 230 + Th 232 = 60**

0.016 NT

DRY

4/15/08 2/26/08

MCL*

CSMRI-11

11/26/07

9/10/07

0.11 0.16 0.37 0.26 0.28

0.44 0.56 0.92 0.92 0.43 0.43 0.43 0.43 0.43 0.43 0.52 0.75 0.75

0.011 -0.05 0.085 0.085 0.006 0.006 0.006 0.006 0.004 0.006 0.004

0.019 0.005 NT NT 0.007 0.008 0.016 0.012

3/1/07 6/26/07

12/4/08

CSMRI-10

11/26/07 2/26/08

-0.017 0.018 0.023 0.023 0.047 0.004 0.004 0.004 0.007 0.008 0.008 0.051 0.051 0.084 0.084 0.084

4/15/08 9/24/08

3/1/07 6/26/07 9/10/07

4/15/08 9/24/08 12/5/08

Ä	ΤN	NT	NL	Π	NT	Π	TN	NT	TN	N	Π	NT	TN	TN	τN	NT	NT	N	TN	NT	N T	TN	T	TN	T	TN	Ę	Π	Z	Z	T	TN	U-235 (pCi/l)
NE	NT	NT	NT	NT	NT	NT	NT	NT	TN	IN	TN	NT	NT	NT	NT	NL	NT	NT	NT	NT	TN	NT	ΤN	NT	NT	NT	NT	NT	NT	NT	NT	NT	U-238 (pCi/l)
30	NT	NT	7.6	8.7	11	10	8.4	4.8	19	11	8.7	9.2	10	9.9	8.8	7.8	26	28	22	24	28	35	32	9.7	1,900	068	770	1,200	1,300	630	810	1,100	Total U (µg/l)

Sample Station

Sample Date

3/8/07

Ra-226 (pCi/l) 0.7 0.8

 Table G-1

 Historical Summary of Radioisotopes in Groundwater (Stoller)

 Th-230

 (pCill)

 (pCill)
 (pCill)
 (pCill)

 0.072
 -0.031
 0.016

 0.039
 0.046
 0.008

•

0.031 -0.02

0.05 0.074 0.1

0.009

0.043

0.089

-0.015 NT

0.009 NT

Ę

CSMRI-8

CSMRI-9

9/10/07 11/26/07

6/26/07

 Ra-228

 Incention

 In

2/27/07

9/25/08 4/17/08 2/27/08 11/27/07 9/10/07 6/27/07

12/5/08

2/27/08

 1.31

 1.27

 1.19

 0.39

 0.39

 1.55

 1.55

 0.12

 0.22

 0.21

 0.11

 0.12

 0.12

 0.12

 0.12

 0.12

 0.12

 0.13

 0.13

 0.13

 0.13

 0.126

 0.26

 0.12

 0.12

 0.12

 0.13

 0.14

 0.15

 0.16

 0.17

 0.18

 0.19

 0.12

 0.12

 0.12

 0.12

 0.12

-0.053 NT 0.04 0.004 0.003 0.037 0.015 0.037 0.015 0.037 0.037

0.027 -0.015 0.012 0.003 0.041 0.022 0.022 NT NT 0.018 0.005

		CSMRI-4								CSMRI-2												CSMRI-1B											CSMRI-1								Station	Sample	
9/7/05	6/14/05	2/25/05	12/5/08	9/24/08	4/17/08	2/28/08	11/27/07	9/11/07	6/28/07	3/8/07	9/13/06	6/14/06	3/15/06	12/20/05	9/7/05	6/14/05	2/25/05	12/5/08	9/24/08	4/18/08	2/28/08	11/27/07	9/11/07	6/26/07	3/1/07	12/3/08	9/25/08	4/18/08	2/27/08	11/27/07	9/11/07	6/27/07	3/1/07	9/13/06	6/14/06	3/15/06	12/20/05	9/7/05	6/14/05	2/25/05	Date	Sample	
ND	ND	ND	NT	NT	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NŢ	TN	ND	N	ND	ND	ND	ND	NT	TN	ND	D	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	Ag		
0.0035 (B)	ND	ND	NT	T	ND	ND	ND	ND	ND	0.0058 (B)	ND	ND	ND	ND	ND	dN	ND	NT	NT	ND	ND	ND	ND	ND	ND	NT	NT	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	As		
0.055 (B)	ND	ND	NT	NT	0.092 (B)	0.094 (B)	0.093 (B)	0.1	0.11	0.12	0.11	0.093 (B)	0.09 (B)	0.098 (B)	0.11	0.1	0.11	NT	NT	0.11	0.11	0.11	0.1	0.071 (B)	0.098 (B)	NT	NT	-0.081 (B)	0.08 (B)	0.075 (B)	0.065 (B)	0.063 (B)	0.081 (B)	0.061 (B)	0.031 (B)	0.064 (B)	0.067 (B)	0.055 (B)	ND	N	Ba		
82	86	72	75	74	78	81	83	91	97	88	81	70	74	76	81	76	72	95	92	93	97	100	93	83	130	39	30	36	36	31	23	23	39	20	10	33	32	21	17	28	Ca		
ND	ND	ND	NT	NT	ND	ND	ND	ND	ND	ND	ND	ND	N	ND	ND	ND	ND	NT	NT	D	ND	ND	ND	ND	ND	NT	NT	ND	ND	DN	ND	ND	0.00045 (B)	ND	ND	ND	ND	ND	ND	ND	G		
ND	ND	ND	NT	NT	ND	0.0018 (B)	ND	ND	ND	ND	ND	ND	ND	DN	ND	ND	ND	NT		ND	0.0015 (B)	dN	ND	ND	0.00014 (B)	NT	NT	ND	dN	ND	0.00061 (B)	ND	0.00063 (B)	0.041 (B)	ND	DN	ND	ND	ND	ND	Cr		(All t
ND	ND	ND	NT	NT	ND	ND	0.000023 (B)	0.000016 (B)	0.0000056 (B)	ND	ND	ND	0.000023 (B)	0.000031 (B)	ND	ND	ND	NT	TN	ND	ND	0.000029 (B)	0.0000094 (B)	0.0000072 (B)	0.000017 (B)	NT	NT	ND	ND	0.000029 (B)	0.000011 (B)	0.0000073 (B)	0.000017 (B)	ND	ND	0.00002 (B)	0.000034 (B)	ND	ND	ND	Ηg		All results in milligrams
7.6	6.6	5.1	6.6	6,4	6.6	6.6	7	7.2	7.9	8.3	6.7	6.3	6.1	6.7	7.1	6.3	7.1	7.6	7.3	9.1	9.3	9.4	8.4	10	52	3.5	ω	2.7	2.5	2.5	2.5	2.4	ω	2.7	1.9	2.6	2.9	2.9	2.3	2.8	~	· · · · .	ums per liter
33	34	31	33	34	36	38	38	43	49	39	35	31	31	33	35	32	32	39	39	43	45	46	43	38	47	12	9	11	12	9.7	7.2	9	12	6	З	10	10	6.3	5.1	9.4	ВW		ter)
0.035	0.038	0.017	NT	N	ND	ND	ND	ND	ND	ND	0.0014 (B)	0.0048 (B)	ND	ND	dN	ND	ND	NT	τN	0.027	0.029	0.024	0.031	0.029	0.17	NT	NT	0.0015 (B)	0.0013 (B)	0.0014 (B)	0.002 (B)	ND	0.0059 (B)	0.0038 (B)	0.0051 (B)	0.0013 (B)	ND	0.0021 (B)	ND	ND	Mo		
31	34	29	20	19	20	21	22	23	26	21	19	17	17	18	19	18	19	40	38	39	41	42	36	35	91	25	18	22	22	18	14	21	26	14	9.2	24	26	25	16	29	Na		
ND	ND	ND	TN	TN	N	N	ND	ND	ND	ND	ND	ND	ND	ND	N	N	ND	NT	TN	ND	ND	ND	ND	ND	ND	T	Π	N	ß	N	N	ND	R	N	ND	ND	ND	ND	ND	ND	Pb		
0.0049 (B)	0.0063	dN	NT	NT	ND	ND	ND	ND	ND	0.03	ND	0.0031 (B)	ND	N	ND	ND	ND	NT	NT	ND	0.0039 (B)	ND	D	ND	0.0058	NT	NT	ND	ND	ND	ND	ND	0.0066	N	0.0035 (B)	ND	ND	0.0041 (B)	ND	ND	Se		
ND	ND	ND	NT	TN	0.0014 (B)	0.0017 (B)	0.001 (B)	0.00086 (B)	0.002 (B)	ND	ND	ND	ND	ND	ND	ND	ND	NT	NT	0.00065 (B)	ND	0.00073 (B)	ND	ND	0.0009 (B)	NT	NT	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	V		
0.097	0.068	0.12	NT	NT	0.0055 (B)	0.0073 (B)	0.0075 (B)	0.0082 (B)	0.0041 (B)	0.0011 (B)	0.0092 (B)	0.0092 (B)	0.0059 (B)	0.0043 (B)	0.011 (B)	ND	0.02	NT	NT	ND	0.0033 (B)	0.0039 (B)	0.0012 (B)	ND	ND	NŢ	TN	0.057	0.048	0.049	0.038	0.017 (B)	0.048	0.03	0.015 (B)	0.049	0.052	.034	0.032	0.032	Zn		

						CSMRI-7B	CSMRI-6C				CSMRI-6B										CSMRI-5																				Sample Station	>
DRY	DRY	2/27/08	DRY	9/10/07	6/26/07	2/27/07	DRY	4/18/08	2/28/08	11/27/07	9/10/07	6/26/07	2/27/08	12/4/08	9/25/08	4/17/08	2/27/08	11/26/07	9/11/07	6/27/07	3/8/07	9/13/06	6/15/06	3/15/06	12/20/05	9/7/05	6/14/05	2/25/05	12/5/08	9/25/08	4/17/08	2/27/08	11/26/07	9/11/07	6/27/07	3/8/07	9/13/06	6/15/06	3/15/06	12/20/05	Sample Date	
NT	NT	NT	NT	NT	ND	NT	NT	ND	ND	ND	ND	ND	NT	NT	TN	ND	ND	ND	ND	D	ND	ND	ND	ND	ND	ND	ND	ND	TN	N	ND	ND	ND	Ag								
TN	NT	NT	хT	NT	ND	NT	NT	ND	ND	0.0048 (B)	0.0046 (B)	N	TN	TN	TN	ND	ND	ND	ND	ND	0.0037 (B)	ND	ND	ND	ND	ND	N	ND	NT	N	0.0063 (B)	ND	ND	0.0045 (B)	ND	0.0057 (B)	ND	0.0031 (B)	ND	ND	As	
TN	NT	N	NT	NT	0.056 (B)	TN	NT	0.17	0.17	0.17	0.15	0.12	NT	NT	NT	0.078 (B)	0.073 (B)	0.087 (B)	0.13	0.066 (B)	0.063 (B)	0.087 (B)	0.052 (B)	0.058 (B)	0.072 (B)	0.085 (B)	ND	N	NT	NT	0.089 (B)	0.073 (B)	0.081 (B)	0.089 (B)	0.067 (B)	0.072 (B)	0.043 (B)	0.055 (B)	0.042 (B)	0.056 (B)	Ba	
NT	TN	L	T	T	70	TN	TN	96	100	110	110	100	T	110	160	100	100	110	110	86	80	110	51	70	79	85	63	54	130	130	150	130	110	120	110	120	66	89	81	100	Ca	
NT	TN	TN	T	NT	ND	NL	NT	ND	ND	ND	ND	ND	NT	NT	TN	ND	ND	ND	ND	ND	ND	ND	ND	0.00037 (B)	0.00071 (B)	ND	ND	ND	NT	NT	0.00047 (B)	ND	0.00049 (B)	0.0011 (B)	ND	0.00023 (B)	DN	0.00085 (B)	ND	ND	G	
NT	NT	NT	TN	NT	ND	NT	NT	ND	ND	ND	0.00088 (B)	ND	NL	NT	TN	ND	ND	0.00089 (B)	0.00082 (B)	ND	ND	0.0022 (B)	ND	ND	ND	ND	ND	ND	NT	NT	ND	ND	ND	0.0014 (B)	ND	ND	ND	ND	ND	ND	Cr	(All r
NT	NT	NT	TN	NT	0.000006 (B)	NT	NT	ND	ND	0.000025 (B)	0.000013 (B)	0.0000059 (B)	NT	NT	NT	0.000018 (B)	ND	0.000032 (B)	0.000023 (B)	0.0000091 (B)	ND	ND	0.000012 (B)	0.000029 (B)	0.000048 (B)	ND	ND	ND	NT	NT	0.000016 (B)	0.000016 (B)	0.000035 (B)	0.000037 (B)	0.000022 (B)	0.000018 (B)	0.000016 (B)	0.0000049 (B)	0.000034 (B)	0.000045 (B)	ĐH	All results in milligrams
T	ŇŢ	TN	TN	NT	5.5	ŢN	TN	6.1	5.8	6	4.8	5.9	NT	4.8	5.5	4.6	4.3	4.5	4.9	4.5	4.5	4.5	3.6	3.5	4.1	4.2	3.3	3.4	11	13	10	8.2	10	12	11	11	8.3	8.3	ы	6.8	ズ	ns per liter)
NT	NT	NT	NT	NT	37	TN	TN	40	43	49	48	56	NT	40	61	40	40	42	44	40	31	41	19	26	30	31	23	22	54	55	66	58	50	49	46	49	27	37	35	43	Mg	ter)
NT	NT	NT	NT	NT	0.024	NT	NT	0.0059 (B)	0.004 (B)	0.0028 (B)	0.0022 (B)	0.004 (B)	NT	NT	NT	0.0011 (B)	ND	ND	0.0042 (B)	0.006 (B)	0.0019 (B)	0.0027 (B)	0.0028 (B)	0.0031 (B)	0.002 (B)	0.0042 (B)	ND	ND	NT	N	0.014	0.015	0.024	0.05	0.04	0.015	0.038	0.03	0.021	0.024	Mo	
TN	NT	NT	TN	NT	53	NT	ŃT	45	49	57	46	41	TN	47	59	41	42	47	47	40	34	50	26	29	31	35	28	27	48	50	53	45	43	41	47	47	30	31	29	34	a	
N	NT	NT	NT	NT	ND	TN	NT	ND	ND	ND	ND	ND	NL	NT	NT	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	NT	NT	ND	ND	ND	79								
NL	NT	TN	TN	TN	ND	Ρ	NT	ND	ND	0.0051	ND	ND	TN	TN	NT	ND	ND	ND	ND	ND	0.015	ND	ND	0.0035 (B)	ND	0.0037 (B)	ND	ND	TN	NL	ND	0.0034 (B)	ND	ND	ND	0.019	ND	ND	ND	ND	Se	
N	TN	TN	NT	NT	0.00061 (B)	N	NT	0.0013 (B)	dN	0.00066 (B)	0.00081 (B)	DN	TN	NT	NT	0.0011 (B)	ND	0.0012 (B)	0.0015 (B)	0.0017 (B)	ND	0.001 (B)	ND	0.00067 (B)	0.0012 (B)	0.0018 (B)	ND	ND	NT	NT	0.00078 (B)	N	0.0011 (B)	0.0012 (B)	0.00073 (B)	ND	ND	0.0011 (B)	0.00056 (B)	ND	×	
NT	NT	NT	NT	NT	0.0041 (B)	NT	TN	0.0099 (B)	0.0048	ND	0.0051 (B)	ND	NT	NT	NT	0.093	0.094	0.12	0.054	0.025	0.083	0.11	0.055	0.11	0.17	0.089	0.047	0.067	NT	NT	0.087	0.069	0.1	0.17	0.14	0.088	0.082	0.11	0.21	0.18	Zn	

 Table G-2

 Historical Summary of Metals in Groundwater (Stoller)

							(All re	All results in milligrams per liter)	s per lit	er)			
Sample	Sample	Δn	^	Ŗ	3	2	?		, ,	1.1.1			
	DRY	N	N			TN	NT	NL	N	TN	NI		
	3/807	ND	0.0053 (B)	0.068 (B)	230	ND	ND	DN	23	72	0.094	74	ND
	6/27/07	ND	ND	0.053 (B)	190	ND	ND	0.0000099 (B)	19	55	0.043	52	S
	9/10/07	ND	0.0069 (B)	0.076 (B)	160	ND	0.00074 (B)	0.000027 (B)	15	49	0.034	54	0.0018
CSMRI-8	11/27/07	ND	ND	0.091 (B)	230	ND	dN	0.000024 (B)	15	67	0.026	70	B
	2/27/08	ND	0.036 (B)	0.07 (B)	270	DN	ND	ND	15	82	0.019	100	R
	4/17/08	ND	ND	0.046 (B)	210	ND	0.0011 (B)	N	13	63	0.016	73	S
	9/25/08	NT	ΝT	NT	230	TN	NT	NT	17	68	N	70	N
	12/5/08	NT	NT	NT	400	TN	NT	NT	18	95	NT	84	N
	2/27/07	ND	ND	0.08 (B)	69	ND	0.0011 (B)	0.000024 (B)	12	31	0.045	జ	ND
	6/26/07	ND	ND	0.049 (B)	160	ND	ND	0.000002 (B)	8.5	77	0.0028	150	N
	9/10/07	ND	0.004 (B)	0.059 (B)	100	ND	0.0009 (B)	0.000016 (B)	ი	51	0.0037 (B)	49	S
CSMRI-9	11/26/07	D	ND	0.078 (B)	110	0.00051 (B)	0.0011 (B)	0.000031 (B)	5.9	56	0.0023 (B)	52	ND
	2/27/08	В	ND	0.079 (B)	110	ND	ND	ND	5.4	56	ND	49	N
	4/15/08	ND	ND	0.077 (B)	100	ND	ND	0.000013 (B)	5	52	0.0017 (B)	46	ND
	9/24/08	NT	NT	NT	110	TN	NT	NT	5.8	54	TN	50	NT
	12/5/08	NT	NT	TN	100	NT	NT	TN	5.3	48	NT	46	N
	3/1/07	0.00051 (B)	N	0.064 (B)	79	ND	0.0013 (B)	0.000024 (B)	7.3	33	0.01	36	N
	6/26/07	ND	ß	0.079 (B)	100	ND	DN	0.0000063 (B)	4.7	44	ND	37	ND
	9/10/07	ND	0.0039 (B)	0.071 (B)	68	ND	0.0012 (B)	0.00002 (B)	4.2	38	0.0014 (B)	36	ND
CSMRI-10	11/26/07	ND	ND	0.085 (B)	110	DN	ND	0.000026 (B)	4.7	43	ND	41	ND
	2/26/08	ND	ND	0.09 (B)	110	ND	ND	ND	4.6	46	ND	41	S
	4/15/08	ND	ND	0.088 (B)	100	ND	0.0044 (B)	ND	4.5	44	ND	40	ND
	9/24/08	TN	NT	TN	100	NT	NT	NT	4.6	42	T	41	T
	12/4/08	NT	NT	NT	100	NT	NT	NT	4.8	41	TN	43	-
	2/27/07	ND	ND	0.073 (B)	75	ND	0.00013 (B)	0.000023 (B)	9.7	29	0.033	33	N
	6/26/07	ND	ß	0.096 (B)	110	ND	0.0012 (B)	0.0000071 (B)	5.4	44	0.0014 (B)	39	S
CSMRI-11	9/10/07	ND	0.004 (B)	0.071 (B)	96	ND	0.00083 (B)	0.000016 (B)	4.5	39	0.0016 (B)	44	ND
	11/26/07	ND	3	0.11	110	ND	ND	0.000028 (B)	4.9	44	0.0012 (B)	40	B
	2/26/08	ND	ND	0.11	110	ND	ND	ND	4.6	42	ND	44	ND
	4/15/08	ND	ND	0.12	100	ND	ND	ND	4.7	41	ND	44	N
CSMRI-11B	DRY	TN	TN	NT	N	NT	TN	ΝT	Π	τN	NT	TN	N
Detection Limits	S	0.01	0.01	0.1	-	0.005	0.01	0.0002	-	-	0.01		0.00
MCL*		NE	0.01	2	NE	0.005	0.1	0.002	Ä	Z	NE	Z	0.01

£

NT – not tested (B) – Detected above Instrument Detection Level but below Reported Detection Level

~

015	003	VT	D	6	6	ND	5	S	TN	TN	ND	D	ND	VD	6	D	TN	NT	ND	ND	ND	ND	ND	ND	NT	NT	ß	ND	ND)18 (B)	B	ND	NT	₿
0.05	0.005	NT	ND	ND	ND	ND	0.0064	0.013	NT	NT	ND	ND	ND	ND	0.0044 (B)	0.01	NT	NT	ND	0.0033 (B)	0.0054	ND	0.0049 (B)	0.011	NT	NŢ	ND	ND	0.0046 (B)	ND	ND	0.034	NT	Se
Zm	0.01	TN	ND	ND	0.0013 (B)	0.00078(B)	0.00059 (B)	0.00073 (B)	NT	NT	0.00059 (B)	ß	ND	0.00099 (B)	0.00055 (B)	0.0011 (B)	NT	NT	0.00077 (B)	ND	0.0012 (B)	0.00071 (B)	0.00096 (B)	0.001 (B)	NT	NT	ND	ND	0.001 (B)	ND	ND	ND	NT	V
NE	0.02	TN	ND	0.0048	ND	0.0033 (B)	ND	0.0023 (B)	NT	NT	0.0018 (B)	0.0052	ND	0.0042 (B)	ND	ND	NT	NT	0.0079 (B)	0.011	0.015 (B)	0.0097 (B)	0.0096 (B)	ND	NT	NT	0.032	0.038	0.011 (B)	0.025	0.069	0.0024 (B)	NT	Zn

*																Г															lean na fe	ŗ
				Ĩ	1			SW-2	Ţ		1		1		7		1	1	1	1			SW-1		1		1	1	1	1	Sample Station	
	* 12/3/08	9/24/08	4/18/08	2/26/08	11/26/07	9/11/07	6/28/07	3/8/07	9/13/06	6/14/06	3/15/06	12/20/05	9/7/05	6/14/05	2/25/05	12/3/08	9/25/08	4/18/08	2/27/08	11/27/07	9/11/07	6/27/07	3/1/07	9/13/06	6/14/06	3/15/06	12/20/05	9/7/05	6/14/05	2/25/05	Sample Date	
	U.1 Total I	-0.16	0.13	0.1	0.11	0.1	0.02	0.12	0.11	0.03	-0.04	0.09	-0.08	0.04	0.45	-0.06	0.18	0.06	0.1	0.2	0.15	0.13	-0.1	-0.03	0.13	-0.16	-0.31	0.18	0.14	0	Ra-226 (pCi/l)	
Λd = 0	0.46	-0.02	0.58	0	0.36	0.27	0.78	0.73	0.35	0.04	-0.15	0.07	0.24	0.29	0.06	0.34	-0.01	-0.07	0.48	0.24	0.74	0.77	0.25	0.25	0.45	0.35	0.47	0.42	0.05	0.58	Ra-228 (pCi/l)	
N		TN	0.015	-0.01	0.007	0.066	0.028	0.047	0.009	0.172	0.009	-0.003	-0.013	0.071	0.011	NT	NT	-0.023	0.014	0.026	0.063	0.006	-0.038	-0.019	0.16	0.059	0.028	0.041	0.05	0.018	Th-228 (pCi/l)	storical Summary o
I 1 230 + 1	NT	NT	0.24	0.113	0	0.068	0.014	-0.055	-0.03	0.24	0.184	0.126	0.107	-0.028	-0.016	NT	NT	-0.026	0.002	0.049	0.088	0.016	0.15	-0.035	0.53	0.125	0.197	0.25	-0.025	-0.026	Th-230 (pCi/l)	of Radioisotopes in t
$\ln 230 + \ln 232 = 60^{-1}$	TN	NT	0.024	0.011	0.012	0.002	0	0	0.01	0.1	0.01	0	0.051	0.007	0.033	NT	NT	0.012	0.024	0.025	0.012	0.014	0.026	0.01	0.062	0.005	-0.005	0.102	0.016	-0.001	Th-232 (pCi/l)	Historical Summary of Radioisotopes in Surface Water (Stoller)
NT		NŢ	NT	NT	NT	NT	NT	NT	0.43	0.39	0.79	0.71	0.54	0.259	0.8	NT	NT	NT	NT	TN	NT	NT	NT	0.37	0.11	0.6	0.64	0.35	0.246	0.89	(pCi/l)	ler)
	-	-		-		-			-0.		0.	0.	0.	0	0.									-0	0	0.	0.	0.	0.	0.	Ð C	

*Maximum Contaminant Level – National Primary Drinking Water Regulations
 **5 CCR 1002-31 Reg 31 – Colorado Surface Water Standards
 pCi/1 - picoCuries per liter
 µg/1 – micrograms per liter

ĥ,

Table G-3

R	NT	NT	NT	T	T	F	NT	T	-0.006	0	0.004	0.067	0.014	0.032	0.066	NT	TN	TN	TN	TN	NT	TN	NT	-0.005	0.08	0.029	0.041	0.031	0.021	0.083	U-235 (pCi/l)
NE	NT	NT	NT	NT	TN	NT	NT	NT	0.3	0.48	0.51	0.49	0.54	0.23	0.42	NT	NT	TN	TN	NT	NT	TN	NT	0.34	0.19	0.53	0.7	0.35	0.251	0.65	U-238 (pCi/l)
30	1.5	0.99	1.8	2	1.7	0.97	0.57	1.7	0.89	1,44	1.52	1.5	1.62	0.69	1.29	1.6	1.1	1.9	2	1.8	0.94	0.6	1.7	_	0.61	1.59	2.11	1.04	0.75	1.97	(149/)

*Maximum Contaminant Level - National Primary Drinking Water Regulations ND - Non Detect NE - Not Established (B) - Detected above Instrument Detection Level but below Reported Detection Level

SW-2

9/13/06 6/14/06 3/15/06 12/20/05

3/8/07

ß

0.03 (B)

0.011 (B)

0.042 (B) 0.042 (B)

0.00053 (B)

R R

0.00043 (B)

0.000034 (B) 0.000022 (B)

1.1 ND

ND 2.8 4.4

88

0.049 (B) 0.019 (B)

0.00064 (B)

ND ND 0.0000056 (B)

ND

B

6/14/05 9/7/05

ND ND ND ND 0.0022 (B)

0.028 (B)

A B A A

ND ND ND

2/25/05

9/25/08 4/18/08

12/3/08

Detection Limits MCL*

0.01 0.01

0.01 0.01

 \sim

R

0.005 0.005

0.0002 0.002

ΝE

ŇĒ

NE

ЯE

0.01

Z NT

9/24/08

12/3/08

4/18/08

2/26/08 11/26/07

ND ND ND ND ND NT

0.044 (B)

0.051

0.0005 (B) 0.0005 (B)

0.00027 (B)

5.1 9.2

ND 0.0035 (B) 0.0027 (B)

3. 1 1.7 2.9

0.0023 (B)

0.0031 (B)

0.00001

0.93 (B)

9.8 2.6

0.0014 (B)

 1
 15
 21
 15
 21
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15
 15</

4.2

2.1

1.9 4.4

0.0045 (B) 0.0048 (B)

8.9

0.0046 (B) 0.0038 (B) 0.0037 (B)

 ∞

0.0005 (B)

AABB

3.4 1.9

9.1 5.1 7.5

44

ట

0.033 (B)

0.045 (B)

Ę

0.1

9/11/07 6/28/07

0.015	0.003	TN	NT	ND	ND	ND	ND	ND	ND	ND	ND	dN	ND	ND	ND	ND	NT	NT	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	Pb
0.05	0.005	NT	IN	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	0.0037 (B)	ND	DN	NT	NT	ND	DN	ND	ND	ND	ND	ND	ND	ND	ND	0.0045 (B)	ND	ND	Se
NE	0.01	TN	TN	ND	ND	ND	ND	ND	ND	ND	ND	0.00053 (B)	ND	ND	ND	ND	NT	TN	ND	ND	ND	ND	ND	ND	ND	ND	0.00067 (B)	ND	ND	ND	ND	V
NE	0.02	NT	NT	0.14	0.15	0.19	0.084	0.075	0.17	0.04	0.031	0.2	0.21	0.051	0.085	0.17	NT	NT	0.13	0.15	0.18	0.078	0.067	0.22	0.053	0.029	0.19	0.22	0.063	0.09	0.2	Żn

Sample Station

Sample Date

Ąg

2/25/05

6/14/05 9/7/05

88888

0.0037 (B)

0.029 (B)

B ND As

N N

Ba

Ca

Cd

ŝ

Ъ

∽

ВW

Mo

Na

Table G-4 Historical Summary of Metals in Surface Water (Stoller)

(All results in milligrams per liter)

SW-1

9/13/06 3/1/07 6/27/07

9/11/07

2/27/08 11/27/07

4488888888

4 4 8 8 8 8 8 8 8 8

0.042 (B) 0.042 (B)

0.00076 (B) ND

Ŋ ß

0.00044 (B)

L L

N N N N N N N

1.9

5.1 7.1

N N

ယ

0.032 (B) 0.018 (B) 0.049 (B)

0.044 (B)

3/15/06 6/14/06

0.0012 (B)

0.0032 (B)

0.011 (B)

0.00084 (ND

0.00047 (B) ND

0.000024 (B) 0.000034 (B)

3.7

8.5

0.0048 (B)

0.004 (B)

-

2.2 1.1 B

4.4 7.6

2.8 2.8

ND 0.0044 (B)

5.2 B

B

0.0011 (B)

0.00092 (B) ß

0.0000068 (B)

0.93 (B)

2.5

0.0046 (B)

0.0017 (B) 0.0029 (B)

4.3

0.000019

0.00027 (B)

1.7 2.8 3.3 3.4

5 8.2 9.6

0.0022 (B) 0.0032 (B)

0.0034 (B)

ND 15 23 7.4

ND

Ä

ND 0.000023 (B)

2.1

4.4

0.0042 (B) 0.0049 (B)

8.5 19 23 3.1 26 3.2

0.00057 (B)

S S S

ND ND


0.03 (B)

ß ß

0.042 (B) 0.04 (B)

12/20/05

Appendix H Anion and Cation Balances and Piper Diagram



Piper Diagram CSMRI 2009 Quarter 1

٠.

CSMRI-1	Calculated Calculated Measured	Calculated			
	325.28 mg/L	172.51 mg/L 126.58 45.932			
	Ca-Cl 326.17 mg/kg 0.99728 g/cm ³ 473 µmho/cm	,3/ 172.99 mg/kg 126.93 46.057			
	Water Type Dissolved Solids Density Conductivity Hardness (as CaCC)	Total Carbonate Non-Carbonate			

ζ,

Page 1 of 2

Printed 06/17/09

Aq•QA®

-
. F.
TT.
\geq
7
9 1
\cup
-

Not within ± 2%		OK	Within preferred range (0.9-1.1) Within preferred range (0.9-1.1) OK	OK
		0.922 0.922 ums:	1.067008 0.993392 atio 0.690 tio	bon 1.000 mg/L 0.000 mg/L
<u>Primary Tests</u> Anion-Cation Balance Anions Cations % Difference Measured TDS = Calculated TDS	Measured Calculated Ratio Measured EC = Calculated EC	Calculated Ratio <u>Secondary Tests</u> Measured EC and Ion Sums:	Anions Cations Calculated TDS to EC ratio Measured TDS un EC ratio Measured TDS unavailable	<u>Organic Mass Balance</u> DOC ≥ Sum of Organics Dissolved Organic Carbon Sum of Organics

Printed 06/17/09

Page 2 of 2

Aq•QA®

Water Type C Dissolved Solids 5 Density 0 Conductivity 4 Hardness (as CaCO ₃) Total 3 Carbonate 3	Ca-HCO ₃ 542.79 mg/kg 0.99744 g/cm ³ 43 µmho/cm) 330.63 mg/kg 330.63 0.0	541.4 mg/L 329.78 mg/L 329.78 0.0	Calculated Calculated Measured Calculated		
otal curves (as curves) (otal 3) (otal	330.63 mg/kg 330.63 0.0	329.78 mg/L 329.78 0.0	Calculated		
late					

х • • Page 1 of 2

Printed 06/17/09

		CSMRI-2
Primary Tests Anion-Cation Balance Anions Cations % Difference Measured TDS = Calculated TDS		Not within $\pm 2\%$
Measured Calculated Ratio Measured EC = Calculated EC Measured Calculated Ratio	N/A 542.789 N/A 43.000 638.817 0.067	Not within range 0.9 to 1.1
Secondary Tests Measured EC and Ion Sums: Anions Cations Calculated TDS to EC ratio Measured TDS to EC ratio	16.097630 17.629173 12.623	Not within preferred range (0.9-1.1) Not within preferred range (0.9-1.1) Not within preferred range (0.55-0.7)
Measured TDS unavailable Organic Mass Balance DOC ≥ Sum of Organics Dissolved Organic Carbon Sum of Organics	1.000 mg/L 0.000 mg/L	OK

Printed 06/17/09

CSMRI-4	Calculated Calculated Measured	Calculated	
	809.9 mg/L	435.01 mg/L 435.01 0.0	
	Ca-SO ₄ 811.81 mg/kg 0.99764 g/cm ³ 889 μmho/cm	436.04 mg/kg 436.04 0.0	
	Water TypeCDissolved Solids8Density0Conductivity8Hardness (as CaCO3)	Total Carbonate Non-Carbonate	

-- *

Page 1 of 2

		CSMRI-4
<u>Primary Tests</u> Anion-Cation Balance Anions Cations % Difference	11.3 11.7 1.645	ŊŎ
Measured TDS = Calculated TDS Measured Calculated Ratio		
Measured Calculated Ratio Secondary Tests	889.000 1073.200 0.828	Not within range 0.9 to 1.1
Measured EC and Ion Sums: Anions Cations Calculated TDS to EC ratio Measured TDS to EC ratio Macouved TDS measured	1.270385 1.312881 0.913	Not within preferred range (0.9-1.1) Not within preferred range (0.9-1.1) Not within preferred range (0.55-0.7)
Organic Mass Balance Organic Mass Balance DOC ≥ Sum of Organics Dissolved Organic Carbon Sum of Organics	3.700 mg/L 0.000 mg/L	OK

÷

Page 2 of 2

Aq•QA®

Printed 06/17/09

	· · ·			
CSMRI-5	Calculated Calculated Measured	Calculated		
	705.4 mg/L	439.39 mg/L 410.64 28.752		
	Ca-HCO ₃ 707.12 mg/kg 0.99756 g/cm ³ 1170 µmho/cm	440.46 mg/kg 411.64 28.823		
	Water Type Dissolved Solids Density Conductivity Hardness (as CaCO ₃)	Total Carbonate Non-Carbonate		

. . . ___ ^ Page 1 of 2

Printed 06/17/09

		CSMRI-5
Primary TestsAnion-Cation BalanceAnionsCationsCations% Difference% DifferenceMeasuredTDS = CalculatedMeasuredCalculatedRatioMeasuredCalculatedRatioMeasuredCalculatedRatioRatioRatioRatioRatioSecondary Tests	10 10.8 3.869 3.869 N/A N/A N/A 1170.000 974.467 1.201	OK Not within range 0.9 to 1.1
Measured EC and Ion Sums: Anions Cations Calculated TDS to EC ratio Measured TDS to EC ratio Measured TDS unavailable <u>Organic Mass Balance</u> DOC ≥ Sum of Organics Dissolved Organics Sum of Organics	0.854885 0.923698 0.604 2.100 mg/L 0.000 mg/L	Not within preferred range (0.9-1.1) Within preferred range (0.9-1.1) OK OK

Printed 06/17/09

Aq•QA®

с. -- - -

		· ·			
CSMRI-8	Calculated Calculated Measured	Calculated			
	1515 mg/L	928.98 mg/L 607.48 321.5			
	Ca-SO ₄ 1517.8 mg/kg 0.99818 g/cm ³ 2320 µmho/cm	930.68 mg/kg 608.59 322.09			
	Water Type Dissolved Solids Density Conductivity Hardness (as CaCO ₄)	Total Carbonate Non-Carbonate			

Page 1 of 2

Printed 06/17/09

		CEMPL 6
		CJNIN-0
Duimour, Torta		
<u>Arian Cation Balance</u>		
Aliton-Cation balance		
Anions	21.8	
Cations	23.1	
% Difference	2.984	OK
Measured TDS = Calculated TDS		
Measured		
Calculated	1517.769	
Ratio	N/A	
Measured EC = Calculated EC		
Measured	2320.000	
Calculated	1969.830	
Ratio	1.178	Not within range 0.9 to 1.1
Secondary Tests		
Measured FC and Ion Sums:		
	0 038672	Within meterred vance (0.9.1-1)
Cations	0 996412	Within meterred range (0.9-1.1)
Calculated 1JJS to EC ratio	0.004	QN
Measured 1DS to EC ratio		
Organic Mass Balance		
$DOC \ge Sum of Organics$		
Dissolved Organic Carbon	3.600 mg/L	:
Sum of Organics	0.000 mg/L	OK

Printed 06/17/09

Aq•QA®

~÷

			CSMRI-9	
Water Type Dissolved Solids	Ca-HCO ₃ 708.42 mg/kg	706.7 mg/L	Calculated	
Conductivity 7 Hardness (as CaCO ₃)	725 µmho/cm		Measured	
Total Carbonate Non-Carbonate	452.58 mg/kg 428.08 24.501	451.48 mg/L 427.04 24.441	Calculated	

Printed 06/17/09

Page 1 of 2

Primary Tests Anion-Cation Balance		
	743	OK
Measured TDS = Calculated TDS Measured Calculated	N/A 708 475	
	A	
d EC = Calculated EC		
Measured 725 Calculated 982	725.000 982.477	
	0.738	Not within range 0.9 to 1.1
Secondary Tests		
EC and Ion Sums:	07200	N_{of} within materical range (0.0-1.1)
Anions 1.5 Cations 1.5	1.531034	Not within preferred range (0.9-1.1) Not within preferred range (0.9-1.1)
I TDS to EC ratio	0.977	Not within preferred range (0.55-0.7)
Organic Mass Balance		
	700	
ic Carbon	1./00 mg/L	AU
Sum of Urganics	0.UUU mg/L	UN
		C I I

۰ .

• • • - Page 2 of 2

Printed 06/17/09

Aq•QA®

•

0
Ţ
_1
\mathbf{A}
Z
–
\mathcal{O}
C

Calculated Calculated Measured	Calculated
710.9 mg/L	451.74 mg/L 443.44 8.2995
Ca-HCO ₃ 712.63 mg/kg 0.99757 g/cm ³ 692 μmho/cm	452.84 mg/kg 444.53 8.3197
Water Type Dissolved Solids Density Conductivity Hardness (as CaCO ₃)	Total Carbonate Non-Carbonate

Printed 06/17/09

Page I of 2

		CSMR-10
Primary Tests		
Anion-Cation Balance Anions	10	
	11	
rence	4.780	OK
= Calculated TDS		
	N/A	
	712.633	
	N/A	
Measured EC = Calculated EC		
	692.000	
	971.137	
	0.713	Not within range 0.9 to 1.1
Secondary Tests		
d Ion Sums:		
	1.446299	Not within preferred range (0.9-1.1)
	1.591500	Not within preferred range (0.9-1.1)
I TDS to EC ratio	1.030	Not within preferred range (0.55-0.7)
Measured TDS to EC ratio		
Measured TDS unavailable		
<u>Organic Mass Balance</u>		
DOC Sum of Organics		
uoq	1.800 mg/L	
	0.000 mg/L	OK
	0.000 IIIg/ L	QP

Printed 06/17/09

Aq•QA®

··- '

Page 1 of 2

÷

Printed 06/24/09

Not within ± 2%
$n \pm 2\%$
n ± 2%
n ± 2%
Not within range 0.9 to 1.1
3
n nrafamad mnra (0 0 1 1)
ive winin preterval auge (v.7-1.1.) Net within meferred renne (0.0-1.1)
Not within preferred lange (0.52-0.1/)

Printed 06/24/09

SW-2	Calculated Calculated Measured	Calculated			
	244.2 mg/L	132.33 mg/L 95.278 37.056			
	Ca-SO ₄ 244.88 mg/kg 0.99722 g/cm ³ 288 µmho/cm 3 ₃)	132.7 mg/kg 95.544 37.159			
	Water Type Dissolved Solids Density Conductivity Hardness (as CaCO ₃)	Total Carbonate Non-Carbonate			

1

Page 1 of 2

		SW-2
Primary Tests Anion-Cation Balance Anions Cations % Difference	3.63 3.56 0.985	NA ANA
Measured TDS = Calculated TDS Measured Calculated Ratio Measured EC = Calculated EC Measured Calculated Calculated		
Secondary Tests Measured EC and Ion Sums: Anions Cations Cations Calculated TDS to EC ratio	0.740 1.260897 1.236307 0.850	Not within preferred range (0.9-1.1) Not within preferred range (0.9-1.1) Not within preferred range (0.55-0.7)
Measured TDS to EC ratio Measured TDS unavailable <u>Organic Mass Balance</u> DOC <u>> Sum of Organics</u> Dissolved Organic Carbon Sum of Organics	1.500 mg/L 0.000 mg/L	OK
		·

~~~

Page 2 of 2

Printed 06/24/09